



SIEMENS DB-11 Base Seal Instruction Manual

[Home](#) » [SIEMENS](#) » SIEMENS DB-11 Base Seal Instruction Manual 

SIEMENS

DB-11 Base Seal Instruction Manual

Contents

- [1 DB-11 Base Seal](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)
- [3 Related Posts](#)

DB-11 Base Seal

for use with FP-11, FPO-11, FPT-11, HFP-11, HFPO-11, HFPT-11 and FDOT421/OH921 Detectors

After mounting and wiring the DB-11 base according to the appropriate installation instructions, follow the steps listed below to install the DB-11 Base Seal.

1. Place the base seal (1/4" white foam) firmly into the bottom of the base. Do not cover the contact springs (See Figure 1.)
2. Rotate the detector counterclockwise while pressing on it until the detector drops into the base.
3. Rotate the detector clockwise until it stops and locks in place.




Figure 1 Installing the DB-11 Base Seal in the DB-11 Base

SIEMENS

Siemens Industry, Inc.
Building Technologies Division
Florham Park, NJ
P/N 315-096054-3
firealarmresources.com

Documents / Resources

	SIEMENS DB-11 Base Seal [pdf] Instruction Manual DB-11 Base Seal, DB-11, DB-11 Seal, Base Seal, Seal
---	---

References

- [Fire Alarm Resources | Download fire alarm documents](#)