Manuals+ — User Manuals Simplified.

SIEMENS DB-SEAL Base Seal Instruction Manual

SIEMENS

DB-SEAL Base Seal
Instruction Manual

Contents

INTRODUCTION

Use the Model DB-Seal base seal with a DB-3S base to prevent moisture from condensing and collecting on the rear of the detector used. This moisture can occur when units experience different temperatures or humidity conditions.

INSTALLATION

(See Figure 1) All wiring must comply with national and local codes.

1. Install and wire the DB-3S base by following the DB-3S Installation Instructions (PIN 315-083225). Make sure that all wires are dressed flush to the bottom of the base.
2. Position the tabs on the seal over the slots in the inner rim of the base and press the seal in place.
3. Check that the four openings for the spring contacts clear the springs and the plastic terminal supports.
4. With the seal in place, install the detector.
5. Follow the checkout procedure in the detector installation instructions.

**Figure 1
Installing the DB-Seal**

SIEMENS

Siemens Industry, Inc.
Building Technologies Division
Florham Park, NJ
P/N 315-092212-4
Siemens Building Technologies, Ltd.
Fire Safety & Security Products
2 Kenview Boulevard
Brampton, Ontario
L6T 5E4 Canada
firealarmresources.com

Documents / Resources

SIEMENS DB-SEAL Base Seal [pdf] Instruction Manual
DB-SEAL Base Seal, DB-SEAL, DB-SEAL Seal, Base Seal, Seal

References

- 🔥 **Fire Alarm Resources | Download fire alarm documents**