



## signify FBZ LED High Bay Instruction Manual

[Home](#) » [signify](#) » signify FBZ LED High Bay Instruction Manual 

### Contents

- [1 signify FBZ LED High Bay](#)
- [2 INSTALLATION](#)
- [3 warranty](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)



### signify FBZ LED High Bay




### INSTALLATION

**CAUTION:** THE INSTALLATION AND SERVICING OF THIS PRODUCT SHOULD BE PERFORMED BY A QUALIFIED ELECTRICIAN OR SERVICE PERSONNEL


1. Slide sheet metal canopy over pendant stem already attached to the ceiling. The four edge flanges should point

downward.

2. Thread cast zinc pendant stem adapter onto pendant stem.
3. Use supplied set screw to lock adapter to stem.
4. Use a #8 screws, supplied, to affix sheet metal canopy to cast zinc adapter.



5. Remove one of the 1/2" knockouts found in the top center of the central driver housing and install the plastic bushing in this hole.
6. Remove lower sheet metal driver compartment cover (see instruction sheet supplied with the FBZ unit).
7. Attach FBZ unit to pendant stem assembly using the remaining four supplied #8 screws. Route AC supply wires into the driver housing while doing this.
8. Make AC wiring connections and reattach lower driver compartment cover





**CAUTION:** Electrical luminaires are designed for permanent installation in ordinary (non-hazardous) locations in accordance with the National Electrical Code and all applicable local codes. Do not use in areas of limited ventilation or in high ambient enclosures. The lamp and luminaire operate at high temperatures. Contact with combustible materials can cause fire and personal contact can cause severe burns.

warranty

© 2021 Signify Holding. All rights reserved. This document may be subject to change. No representation or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance thereon is disclaimed. All trademarks are owned by signify holding or their respective owners.

**Signify North America Corporation**  
400 Crossing Blvd, Suite 600 Bridgewater, NJ 08807, USA  
**Telephone:** 855-486-2216

Documents / Resources

	<a href="#">signify FBZ LED High Bay</a> [pdf] Instruction Manual FBZ LED High Bay, FBZ, LED High Bay, High Bay, Bay
	<a href="#">signify FBZ LED High Bay</a> [pdf] Instruction Manual FBZ LED High Bay, FBZ, LED High Bay, High Bay, Bay