

signify RC159Z Plaster Ceiling SMB-PLC



# signify RC159Z Plaster Ceiling SMB-PLC Instruction Manual

[Home](#) » [signify](#) » signify RC159Z Plaster Ceiling SMB-PLC Instruction Manual 

## Contents

- [1 signify RC159Z Plaster Ceiling SMB-PLC](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Accessories](#)
- [5 Surface mounted](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)

# signify

## signify RC159Z Plaster Ceiling SMB-PLC



## Product Information

### Specifications:

- Model: RC159Z
- Accessories: RC159Z SMB W60L60, RC159Z SMB W62L62, RC159Z SMB W30L120

- Weight: 0.98 kg (W60L60), 1.02 kg (W62L62), 1.26 kg (W30L120)
- Mounting Type: Surface mounted
- Manufacturer: Signify
- Expiry Date: 04/2024

## Product Usage Instructions

### Installation:

1. Determine the appropriate mounting location for the RC159Z.
2. Use the provided accessories based on your specific model (W60L60, W62L62, or W30L120).
3. Ensure the surface is suitable for mounting and secure the RC159Z in place.

### Power Connection:

1. Connect the power supply to the designated input on the RC159Z.
2. Check the power requirements based on the specifications provided.

### Usage:

1. Turn on the power source to activate the RC159Z.
2. Adjust any settings or configurations as needed for your application.

### Maintenance:

1. Regularly clean the surface of the RC159Z to ensure optimal performance.
2. Check for any loose connections or damage that may affect functionality.

## Frequently Asked Questions (FAQ)


### 1. Q: Can I use the knock-out feature for all models?

A: The knock-out feature is not suitable for the W62L62 model; it is recommended only for W60L60 and W30L120.


### 2. Q: How many accessories are included with each model?

A: The W60L60 and W62L62 models come with 4 accessories, while the W30L120 model includes 6 accessories.



## Accessories






4x




W60L60/W62L62: 4x  
W30L120: 6x










| Configuration types<br>(Ceiling only) |            |  | Size type |  |
|---------------------------------------|------------|--|-----------|---|
| RC159Z SMB W60L60                     | for RC159Z |  | W60L60    | 0.98  |
| RC159Z SMB W62L62                     | for RC159Z |  | W62L62    | 1.02  |
| RC159Z SMB W30L120                    | for RC159Z |  | W30L120   | 1.26  |




## Surface mounted







## Documents / Resources



[signify RC159Z Plaster Ceiling SMB-PLC](#) [pdf] Instruction Manual

RC159Z Plaster Ceiling SMB-PLC, RC159Z, Plaster Ceiling SMB-PLC, Ceiling SMB-PLC, SMB-PLC, PLC

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.