

# SIIG 04-1054B Serial Port Parallel Port Card User Guide


[Home](#) » [SIIG](#) » SIIG 04-1054B Serial Port Parallel Port Card User Guide 

## Contents

- [1 SIIG 04-1054B Serial Port Parallel Port Card](#)
- [2 Specifications](#)
- [3 Features](#)
- [4 Package contents](#)
- [5 System Requirements](#)
- [6 Driver Installation](#)
- [7 Quick Start Guide](#)
- [8 Support](#)
- [9 FAQs](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)
- [11 Related Posts](#)



**SIIG 04-1054B Serial Port Parallel Port Card**



**Dear Valued Customer**

WE REALLY APPRECIATE YOUR PURCHASE Thank you

## **Specifications**

- Compatible Operating Systems: Windows 2012 / 2008 R2 / 2008 & 2003 (32-/64-bit), Linux kernel 2.6 and later version
- Product Number: LB-xxxxxx-S1
- Ports: Single Parallel Port

## **Features**

- Bus connector: PCI Express x1
- Compliant with PCI Express 1.1
- Baud rate (serial port): Up to 115.2 Kbps
- FIFO (serial port): 256 Bytes
- UART (serial port): 16C550

## **Package contents**

- Serial Port / Parallel Port PCIe Card
- Quick Start Guide

## **System Requirements**

1. An available PCIe slot
2. Windows® 11 / 10 / 8.1 / 7 (32-/64-bit)
3. Windows® Server 2019 / 2016 / 2012 R2 2012 / 2008 R2 / 2008 & 2003 (32-/64-bit)
4. Linux kernel 2.6 and later version

## Driver Installation

If your system has a built-in driver, you can use it directly without the need for installation.

**However, if you need to install the driver, follow these steps:**

1. Visit the SIIG website.
2. Search for product number LB-xxxxxx-S1 to find and download the driver.
3. Run Setup.exe to install the driver.
4. Follow the on-screen installation steps to complete the driver installation.

## Serial Port / Parallel Port PCIe Card

### Quick Start Guide

- LB-P00014-S1 Single Parallel port
- LB-S00014-S1 Dual Serial port
- LB-S00114-S1 Quad Serial port
- LB-SP0014-S1 Single Serial port plus Single Parallel port
- LB-SP0114-S1 Dual Serial port plus Single Parallel port

## Support

- For more info or tech support
- <http://www.siig.com/support>

**Mar, 2024 Copyright © 2024 by SIIG, Inc. All rights reserved**

## FAQs

### **Q: Do I need to install drivers for the Serial Port / Parallel Port PCIe Card?**

A: If your system does not have a built-in driver, you will need to download and install the driver from the SIIG website using product number LB-xxxxxx-S1.

### **Q: Where can I find technical support for the product?**

A: For more information or technical support, please visit <http://www.siig.com/support>.

## Documents / Resources

Dear Valued Customer

WE REALLY APPRECIATE YOUR PURCHASE

-thank you-

Features

Package contents

System Requirements

# SIIG 04-1054B Serial Port Parallel Port Card [pdf] User Guide

04-1054B, 04-1054B Serial Port Parallel Port Card, 04-1054B, Serial Port Parallel Port Card, Port Parallel Port Card, Parallel Port Card, Port Card, Card

## References

-  [SIIG Support](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.