

# SILICON LABS 6.1.3.0 GA Bluetooth Mesh Software **Development User Guide**

Home » SILICON LABS » SILICON LABS 6.1.3.0 GA Bluetooth Mesh Software Development User Guide 🖺



#### **Contents**

- 1 SILICON LABS 6.1.3.0 GA Bluetooth Mesh Software **Development**
- **2 Product Usage Instructions**
- 3 New Items
- 4 Improvements
- **5 Fixed Issues**
- 6 Known Issues in the Current Release
- 7 Deprecated Items
- 8 Removed Items
- 9 Using This Release
- 10 Documents / Resources
  - 10.1 References
- 11 Related Posts



SILICON LABS 6.1.3.0 GA Bluetooth Mesh Software Development



## **Specifications**

- Product Name: Gecko SDK Suite 4.4
- Release Date: October 23, 2024
- Bluetooth Mesh Specification Version: 1.1
- Supported SDK Versions:
  - 6.1.3.0 released October 23, 2024
  - o 6.1.2.0 released August 14, 2024
  - 6.1.1.0 released May 2, 2024
  - o 6.1.0.0 released April 10, 2024
  - o 6.0.1.0 released February 14, 2024
  - 6.0.0.0 released December 13, 2023

## **Product Usage Instructions**

#### **Compatibility and Use Notices**

For security updates and notices, refer to the Security chapter of the Gecko Platform Release notes or visit the Silicon Labs Release Notes page. Subscribe to Security Advisories for the latest information.

#### **Using This Release**

If you are new to the Silicon Labs Bluetooth mesh SDK, follow the instructions provided in the user manual to get started with the product.

## **Compatible Compilers**

Ensure that you are using the correct files and compilers as recommended for optimal performance of the product.

## **FAQ**

# • Q: Where can I find more information about security updates?

A: You can refer to the Security chapter of the Gecko Platform Release notes or visit the Silicon Labs Release Notes page for detailed security update information.

## • Q: How do I subscribe to Security Advisories for this product?

A: To subscribe to Security Advisories and receive up-to-date information, follow the instructions provided in the user manual or contact Silicon Labs support.

## • Q: What compilers are compatible with this product?

A: Refer to the user manual for a list of compatible compilers recommended for use with this product.

#### Bluetooth® mesh SDK 6.1.3.0 GA

Gecko SDK Suite 4.4 October 23, 2024

Bluetooth mesh is a new topology available for Bluetooth Low Energy (LE) devices that enables many-to-many (m:m) communication. It's optimized for creating large-scale de-vice networks, and is ideally suited for building automation, sensor networks, and asset tracking. Our software and SDK for Bluetooth development supports Bluetooth Mesh and Bluetooth 5.3 functionality. Developers can add mesh networking communication to LE devices such as connected lights, home automation, and asset tracking systems. The software also supports Bluetooth beaconing, beacon scanning, and GATT connections so Bluetooth mesh can connect to smart phones, tablets, and other Bluetooth LE devices. This release includes features supported by the Bluetooth mesh specification version 1.1.

#### **KEY FEATURES**

- Qualified implementation of Mesh 1.1
- · Added Network Lighting Control (NLC) profiles



#### These release notes cover SDK versions:

- 6.1.3.0 released October 23, 2024
- 6.1.2.0 released August 14, 2024
- 6.1.1.0 released May 2, 2024
- 6.1.0.0 released April 10, 2024
- 6.0.1.0 released February 14, 2024
- 6.0.0.0 released December 13, 2023

## **Compatibility and Use Notices**

For more information about security updates and notices, see the Security chapter of the Gecko Platform Release notes installed with this SDK or on the Silicon Labs Release Notes page. Silicon Labs also strongly recommends that you subscribe to Security Advisories for up-to-date information. For instructions, or if you are new to the Silicon Labs Bluetooth mesh SDK, see Using This Release.

## **Compatible Compilers:**

IAR Embedded Workbench for ARM (IAR-EWARM) version 9.40.1

- Using wine to build with the IarBuild.exe command line utility or IAR Embedded Workbench GUI on macOS or Linux could result in incorrect files being used due to collisions in wine's hashing algorithm for generating short file names.
- Customers on macOS or Linux are advised not to build with IAR outside of Simplicity Studio. Customers who
  do should carefully verify that the correct files are being used. GCC (The GNU Compiler Collection) version
  12.2.1, provided with Simplicity Studio.
- Link-time optimization feature of GCC has been disabled, resulting in a slight increase of image size.

#### **New Items**

#### **New Features**

Added in release 6.0.1.0

## Changes in SLC components:

- A third BT Mesh Role was added beside Provisioner and Provisionee role a Custom BT Mesh Role, where
  the application gets the freedom to implement a custom role. For example, the Provisioner or
- Provisionee role could be selected runtime.
- Added in release 6.0.0.0
- New Networked Lighting Control (NLC) example apps:
- btmesh\_soc\_nlc\_basic\_lightness\_controller for demonstration of the BT Mesh NLC Basic Lightness Controller
   Profile
- btmesh soc nlc basic scene selector for demonstration of the BT Mesh NLC Basic Scene Selector Profile
- btmesh soc nlc dimming control for demonstration of the BT Mesh NLC Dimming Controller Profile
- btmesh soc nlc sensor ambient light for demonstration of the BT Mesh NLC Ambient Light Sensor Profile
- btmesh\_soc\_nlc\_sensor\_occupancy for demonstration of the BT Mesh NLC Occupancy Sensor Profile (People count)

#### Changes in example apps:

btmesh\_soc\_sensor\_server was deleted and its functionality was split in 3 examples:

- btmesh\_soc\_sensor\_thermometer for demonstration of Sensor Server Model with a thermometer
- btmesh\_soc\_nlc\_sensor\_occupancy for demonstration of the BT Mesh NLC Occupancy Sensor Profile (people count)
- btmesh\_soc\_nlc\_sensor\_ambient\_light for demonstration of the BT Mesh NLC Ambient Light Sensor Profile
- btmesh\_soc\_switch was renamed to btmesh\_soc\_switch\_ctl, whose purpose is to demonstrate the usage of the Light CTL Client Model. The example no longer controls scenes (Scene Client)
- btmesh\_soc\_light was renamed to btmesh\_soc\_light\_ctl
- The example no longer demonstrates the LC Server model and Scene Server, Scheduler Server and Time Server Models
- btmesh\_soc\_hsl was renamed to btmesh\_soc\_light\_hsl
- The example no longer demonstrates the LC Server model and Scene Server, Scheduler Server and Time Server Models

## Changes in all example apps:

- DFU image updates are generated by a Python script instead of create\_bl\_files.bat/.sh files
- Support for Mesh Composition Data Pages 1, 2, 128, 129, 130 was added for all examples, these pages are automatically generated by the BT Mesh Configurator tool.

### **New SLC components:**

• btmesh\_nlc\_basic\_lightness\_controller for demonstration of the BT Mesh NLC Basic Lightness Controller

**Profile** 

- btmesh\_nlc\_basic\_lightness\_controller\_profile\_metadata for Composition Data Page 2 NLC support for Basic Lightness Controller Profile
- btmesh\_nlc\_basic\_scene\_selector for demonstration of the BT Mesh NLC Basic Scene Selector Profile
- btmesh\_nlc\_basic\_scene\_selector\_profile\_metadata for Composition Data Page 2 NLC support for Basic Scene Selector Profile btmesh\_nlc\_dimming\_control for demonstration of the BT Mesh NLC
- · Dimming Controller Profile
- btmesh\_nlc\_dimming\_control\_profile\_metadata for Composition Data Page 2 NLC support for Dimming Controller Profile btmesh\_nlc\_ambient\_light\_sensor for demonstration of the BT Mesh NLC Ambient Light Sensor Profile
- btmesh\_nlc\_ambient\_light\_sensor\_profile\_metadata for Composition Data Page 2 NLC support for Ambient Light Sensor Profile btmesh\_nlc\_occupancy\_sensor for demonstration of the BT Mesh NLC Occupancy Sensor Profile (People count)
- btmesh\_nlc\_occupancy\_sensor\_profile\_metadata for Composition Data Page 2 NLC support for Occupancy Sensor Profile
- btmesh\_generic\_level\_client\_ext for extending the Generic Base component with Generic Move
   Unacknowledged and Generic Delta Unacknownledged messages
- ncp\_btmesh\_ae\_server for enabling the Silabs Configuration Server vendor model for the node to allow data transfer over Advertisement Extension
- ncp\_btmesh\_ae\_server for enabling the Silabs Configuration Client vendor model for the node.
- ncp\_btmesh\_user\_cmd for demonstrating the communication between an NCP host and NCP target using BGAPI user messages, responses and events.

## **New APIs**

Added in release 6.1.0.0

## **BGAPI** additions:

New commands have been added to the node class to associate scan response data with Mesh provisioning and Mesh proxy service advertisements. The scan response data associated with Mesh proxy service advertisements can be set individually for each network key, so it can contain data encrypted with that key, but it is up to the application to manage that. The new commands are:

- sl\_btmesh\_node\_set\_proxy\_service\_scan response: Set scan response data for proxy service advertisement
- sl\_btmesh\_node\_clear\_proxy\_service\_scan\_response: Clear scan response data for proxy service advertisement
- sl\_btmesh\_node\_set\_provisioning\_service\_scan response: Set scan response data for provisioning service advertisement
- sl\_btmesh\_node\_clear\_provisioning\_service\_scan\_response: Clear scan response data for provisioning service advertisement

A new command has been added to the vendor model class to set model behavior options. Currently there is one option that controls whether a work buffer is allocated from the heap for each vendor model for message reception reporting. The default value (1) allocates a buffer, which increases event reporting resilience when a device is under high load at the expense of additional heap memory usage. The new command is:

• sl btmesh vendor model set option: Set a vendor model behavior option

# New commands have been added to the diagnostic class to report friendship-related events. The new commands are:

- sl\_btmesh\_diagnostic\_enable\_friend: Enable generation of friendship-related diagnostic events
- sl\_btmesh\_diagnostic\_disable\_friend: Disable generation of friendship-related diagnostic events
- sl btmesh diagnostic get friend: Retrieve friendship-related diagnostic counters

## New events added to the diagnostic class are as follows:

- sl\_btmesh\_diagnostic\_friend\_queue: Event for message being added to friendship message queue
   sl\_btmesh\_diagnostic\_friend\_relay: Event for message being relayed to a LPN
- sl\_btmesh\_diagnostic\_friend\_remove: Event for message being removed from friendship message queue

#### Added in release 6.0.0.0

## Changes in SLC components:

- ncp btmesh dfu component's ncp btmesh dfu.h has a new API
  - void sl\_btmesh\_ncp\_dfu\_handle\_cmd(void \*data, bool \*cmd\_handled);
- btmesh\_provisioning\_decorator component doesn't restart provisioning after provisioning is failed btmesh\_lighting\_server's sl\_btmesh\_lighting\_server.h has a new API
  - void sl\_btmesh\_update\_lightness(uint16\_t lightness, uint32\_t remaining\_ms);
- btmesh event log has more granular configurability options
- btmesh\_ctl\_client's sl\_btmesh\_ctl\_client.h has an API change instead of
  - void sl\_btmesh\_set\_temperature(uint8\_t new\_color\_temperature\_percentage); the new APi is
  - void sl\_btmesh\_ctl\_client\_set\_temperature(uint8\_t temperature\_percent); void sl\_btmesh\_ctl\_client\_set\_lightness(uint8\_t lightness\_percent);

## **BGAPI** additions:

A new BGAPI class for device diagnostics has been added. It provides the application with Mesh stack statistics counters and an event-based reporting of network PDU relaying and proxying, which can be activated and deactivated as needed.

## The BGAPI commands in the diagnostic class are:

- sl\_btmesh\_diagnostic\_init: Initialize the diagnostic component
- sl btmesh diagnostic deinit: Deinitialize the diagnostic component
- sl\_btmesh\_diagnostic\_enable\_relay: Enable event-based reporting of network PDU relaying/proxying activity
- sl\_btmesh\_diagnostic\_disable\_relay: Disable event-based reporting of network PDU relaying/proxying activity
- sl\_btmesh\_diagnostic\_get\_relay: Get the number of relayed/proxied network PDUs so far
- sl\_btmesh\_diagnostic\_get\_statistics: Get mesh stack statistics counters
- sl\_btmesh\_diagnostic\_clear\_statistics: Zero mesh stack statistics counters

## The BGAPI event in the diagnostic class is:

sl\_btmesh\_diagnostic\_relay: Event reporting that a network PDU has been relayed or proxied by the stack

## **Improvements**

## Changed in release 6.1.0.0

The diagnostic class BGAPI command for retrieving statistics has been changed to retrieve chunks of data instead of retrieving all data at once. The caller should supply the size of the chunk it requests along with the offset of the chunk in the statistics data, and the call will return with as much data as can be supplied, given the request constraints.

## Changed in release 6.0.0.0

- A provisioner or a node can now configure itself using the configuration client model and its own primary address as the destination for the messages. This can replace self-configuration by test BGAPI commands.
- Code optimization can result in slightly smaller firmware images than before, depending on the feature set used.
- Code optimization can result in slightly smaller RAM usage than before, depending on the feature set used.
- The Mesh stack no longer requires or supports the deprecated BLE advertiser and scanner components.
   Instead, it uses the current versions of each (legacy advertiser and legacy scanner for non- extended advertisements, and extended advertiser and extended scanner for extended advertisements). Applications that use both the BLE and the Mesh BGAPIs should no longer use the deprecated BLE advertiser and scanner components either.

## **Fixed Issues**

## Fixed in release 6.1.3.0

| ID#      | Description   |
|----------|---|
| 1331888, |   |
| 1338088, | Fixed a number of unhandled memory allocation failures that could potentially lead to a crash when the device is overloaded with traffic. |
| 1338090  | If the device is overloaded with traffic.   |
| 1345827  | Fixed loss of the informative DFU distributor BGAPI event for node removal.   |
| 1351464  | Fixed link layer reporting of closing connections in an overload situation.   |
| 1354679  | Optimized memory usage when sending legacy advertisements.  |
| 1356050  | Fixed GATT proxy restarting issue when the underlying connection closes unexpectedly.   |

## Fixed in release 6.1.2.0

| ID#     | Description  |
|---------|--|
| 1251498 | Fixed when a Lighting message, including transition time, leads to an incorrect error message in lo gs.          |
| 1284204 | Fixed an issue that could prevent saving the replay protection list when using sl_btmesh_node_power_off command. |
| 1325267 | Fixed element sequence number writing when the configured write interval exponent is set to zero.                |
| 1334927 | Fixed an issue that could cause a hard fault when GATT proxy server receives data during resourc e starvation.   |

# Fixed in release 6.1.0.0

| ID#     | Description   |  |
|---------|---|--|
| 1235337 | Made GATT service discovery more robust on an overloaded device.  |  |
| 1247422 | Made vendor model reception more robust on an overloaded device.  |  |
| 1252252 | Fixed when a Generic Move message leads to a dim up, which could overflow to a dim down.                          |  |
| 1254356 | Fixed a regression with friend subsystem deinitialization.  |  |
| 1276121 | Fixed application key index truncation at BGAPI level when embedded provisioner invokes a key r efresh procedure. |  |

# Fixed in release 6.0.1.0

| ID#     | Description   |
|---------|---|
| 1226000 | Extended Provisioner BGAPI function for checking node identity to also check private node identity.                                 |
| 1206620 | Fixed problems caused by missing BGAPI events during high load to correct firmware verification p roblems.                          |
| 1230833 | Fixed friend subsystem deinitialization so that reinitialization works without resetting the device.                                |
| 1243565 | Fixed crash that could occur if provisioner initialization failed, for example because of malformed D CD.                           |
| 1244298 | Fixed reporting of spurious extra octets in the Register Status event of the Scene Client model.                                    |
| 1243556 | Automatic node initialization removed for BT Mesh application components. Now all components c an be used also in Provisioner role. |

## Fixed in release 6.0.0.0

| ID#     | Description  |
|---------|--|
| 360955  | The interval between first and second attention timer event could be other than one second.        |
| 1198887 | Private beacon random advertiser address is the same for all subnets while it should be different. |
| 1202073 | Btmesh_ncp_empty example does not have enough RAM on BRD4182 with GCC compiler.                    |
| 1202088 | Btmesh_soc_switch example does not have enough RAM on BRD4311 and BRD4312 with IAR compiler        |
| 1206714 | Proxy server should emit a beacon over proxy connection when a subnet is added to the proxy server |

| ID#      | Description  |  |
|----------|--|--|
| 1206715, |  |  |
| 1211012, | Support for device composition data page 2, 129 and 130 should be present in configuration server                  |  |
| 1211022  | model as well as large composition data server model when remote provisioning is supported                         |  |
| 1211017  | Periodic publishing of location information should alternate between global and local location when both are known |  |
| 1212373  | Resource leak in proxy connection handling after several hundred proxy connections have been o pened and closed    |  |
| 1212854  | Pull mode MBT transfer to an LPN does not complete successfully  |  |
| 1197398, |  |  |
| 1194443  | DFU distributor application is currently not able to handle more than 60 nodes successfully                        |  |
| 1202088  | Btmesh_soc_switch_ctl example compiles on all boards with IAR compiler.  |  |

# **Known Issues in the Current Release**

Issues in bold were added since the previous release.

| ID#     | Description   | Workaround  |  |
|---------|---|---|--|
| 401550  | No BGAPI event for segmented message handling failure.  | Application needs to deduce failure from timeout / lac<br>of application layer response; for vendor models an A<br>PI has been provided.  |  |
| 454059  | A large number of key refresh state chan ge events are generated at the end of K R process, and that may flood NCP queue. | Increase NCP queue length in the project.   |  |
| 454061  | Slight performance degradation compared to 1.5 in round-trip latency tes ts was observed.                                 |   |  |
| 624514  | Issue with re-establishing connectable a dvertising if all connections have been active and GATT proxy is in use.         | Allocate one more connection than is needed.  |  |
| 841360  | Poor performance of segmented message transmission over GATT beare r.   | Ensure that the underlying BLE connection's Connection interval is short; ensure that ATT MTU is large enough to fit a full Mesh PDU; tune the minimum connection event length to allow multiple LL packets to be transmitted per connection event. |  |
| 1121605 | Rounding errors may cause scheduled e vents to trigger at very slightly different ti mes than expected.                   |   |  |
| 1226127 | Host provisioner example can be stuck when it starts to provision a second node .   | Restart the host provisioner app before provisioning the second node.   |  |
| 1204017 | Distributor is not able to handle parallel s elf FW Update and FW Upload.   | Don't run self FW update and FW upload in parallel.   |  |
| 1338936 | GATT proxy might not resume service advertisement after disconnection in an overload situation.                           | Ensure that enough buffers are reserved for traffic handling. Plan the network and communication patterns so that no node is overwhelmed with traffic.  |  |
| 1344809 | Proxying to advertisement bearer stalls in an overload situation with higher than usual delays in forwarding data.        | Ensure that enough buffers are reserved for traffic handling. Plan the network and communication patterns so that no node is overwhelmed with traffic.  |  |

# **Deprecated Items**

## Deprecated in release 6.0.0.0

The BGAPI command sl\_btmesh\_node\_get\_networks() has been deprecated. Use sl\_btmesh\_node\_key\_key\_count() and sl\_btmesh\_node\_get\_key() instead.

The BGAPI commands sl\_btmesh\_test\_set\_segment\_send\_delay() and sl\_btmesh\_test\_set\_sar\_config() have been deprecated. Use sl\_btmesh\_sar\_config\_set\_sar\_transmitter() and sl\_btmesh\_sar\_config\_server\_set\_sar\_receiver() instead.

## **Removed Items**

## Removed in release 6.0.0.0

The BGAPI commands sl\_btmesh\_test\_set\_local\_config() and sl\_btmesh\_test\_get\_local\_config() have been

removed. The BGAPI commands sl\_btmesh\_node\_get\_statistics() and sl\_btmesh\_node\_clear\_statistics() have been removed.

## **Using This Release**

## This release contains the following

- · Silicon Labs Bluetooth mesh stack library
- · Bluetooth mesh sample applications

If you are a first time user, see QSG176: Silicon Labs Bluetooth Mesh SDK v2.x Quick-Start Guide.

#### Installation and Use

The Bluetooth mesh SDK is provided as part of the Gecko SDK (GSDK), the suite of Silicon Labs SDKs. To quickly get started with the GSDK, install Simplicity Studio 5, which will set up your development environment and walk you through GSDK installation. Simplicity Studio 5 includes everything needed for IoT product development with Silicon Labs devices, including a resource and project launcher, software configuration tools, full IDE with GNU toolchain, and analysis tools. Installation instructions are provided in the online Simplicity Studio 5 User's Guide. Alternatively, Gecko SDK may be installed manually by downloading or cloning the latest from GitHub. See <a href="https://github.com/Sili-conLabs/gecko\_sdk">https://github.com/Sili-conLabs/gecko\_sdk</a> for more information.

The GSDK default install location has changed with Simplicity Studio 5.3 and higher.

- Windows: C:\Users\<NAME>\SimplicityStudio\SDKs\gecko\_sdk
- MacOS: /Users/<NAME>/SimplicityStudio/SDKs/gecko\_sdk

Documentation specific to the SDK version is installed with the SDK. Additional information can often be found in the knowledge base articles (KBAs). API references and other information about this and earlier releases is available on <a href="https://docs.silabs.com/">https://docs.silabs.com/</a>.

## **Security Information**

#### **Secure Vault Integration**


This version of the stack is integrated with Secure Vault Key Management. When deployed to Secure Vault High devices, mesh encryption keys are protected using the Secure Vault Key Management functionality. The table below shows the protected keys and their storage protection characteristics.

| Key            | Exportability on a node | Exportability on Provisioner | Notes  |
|----------------|-------------------------|------------------------------|--|
| Network key    | Exportable              | Exportable                   | Derivations of the network key exist only in R<br>AM while network keys are stored on flash          |
| Application ke | Non-exportable          | Exportable                   |  |
| Device key     | Non-exportable          | Exportable                   | In Provisioner's case, applied to<br>Provisionerr's own device key as well as other<br>devices' keys |

Keys that are marked as "Non-Exportable" can be used but cannot be viewed or shared at runtime. Keys that are marked as "Exportable" can be used or shared at runtime but remain encrypted while stored in flash. For more information on Secure Vault Key Management functionality, see AN1271: Secure Key Storage.


## **Security Advisories**

To subscribe to Security Advisories, log in to the Silicon Labs customer portal, then select Account Home. Click HOME to go to the portal home page and then click the Manage Notifications tile. Make sure that 'Software/Security Advisory Notices & Product Change Notices (PCNs)' is checked, and that you are subscribed at minimum for your platform and protocol. Click Save to save any changes. The following figure is an example:



#### **Support**

Development Kit customers are eligible for training and technical support. Use the Silicon Labs Bluetooth mesh web page to obtain information about all Silicon Labs Bluetooth products and services, and to sign up for product support. Contact Silicon Laboratories support at <a href="http://www.silabs.com/support">http://www.silabs.com/support</a>.











#### IoT Portfoliowww.silabs.com/IoT

- SW/HW www.silabs.com/simplicity
- · Quality www.silabs.com/quality
- Support & Community <u>www.silabs.com/community</u>

#### **Disclaimer**

Silicon Labs intends to provide customers with the latest, accurate, and in-depth documentation of all peripherals and modules available for system and software implementers using or intending to use the Silicon Labs products. Characterization data, available modules and peripherals, memory sizes and memory addresses refer to each specific device, and "Typical" parameters provided can and do vary in different applications. Application examples described herein are for illustrative purposes only. Silicon Labs reserves the right to make changes without further notice to the product information, specifications, and descriptions herein, and does not give warranties as to the accuracy or completeness of the included information. Without prior notification, Silicon Labs may update product firmware during the manufacturing process for security or reliability reasons. Such changes will not alter the specifications or the performance of the product. Silicon Labs shall have no liability for the consequences of use of the information supplied in this document.

This document does not imply or expressly grant any license to design or fabricate any integrated circuits. The products are not designed or authorized to be used within any FDA Class III devices, applications for which FDA premarket approval is required or Life Support Systems without the specific written consent of Silicon Labs. A "Life Support System" is any product or system intended to support or sustain life and/or health, which, if it fails, can be reasonably expected to result in significant personal injury or death. Silicon Labs products are not designed or authorized for military applications. Silicon Labs products shall under no circumstances be used in weapons of mass destruction including (but not limited to) nuclear, biological or chemical weapons, or missiles capable of delivering such weapons. Silicon Labs disclaims all express and implied warranties and shall not be responsible or liable for any injuries or damages related to use of a Silicon Labs product in such unauthorized applications.

#### **Trademark Information**

Silicon Laboratories Inc.®, Silicon Laboratories®, Silicon Labs®, SiLabs® and the Silicon Labs logo®, Bluegiga®, Bluegiga Logo®, EFM®, EFM32®, EFR, Ember®, Energy Micro, Energy Micro logo and combinations thereof, "the world's most energy friendly microcontrollers", Redpine Signals®, WiSeConnect, n-Link, EZLink®, EZRadio®, EZRadioPRO®, Gecko®, Gecko OS, Gecko OS Studio, Precision32®, Simplicity Studio®, Telegesis, the Telegesis Logo®, USBXpress®, Zentri, the Zentri logo and Zentri DMS, Z-Wave®, and others are trademarks or registered trademarks of Silicon Labs. ARM, CORTEX, Cortex-M3 and THUMB are trademarks or registered trademarks of ARM Holdings. Keil is a registered trademark of ARM Limited. Wi-Fi is a registered trademark of the Wi-Fi Alliance. All other products or brand names mentioned herein are trademarks of their respective holders.

Silicon Laboratories Inc. 400 West Cesar Chavez Austin, TX 78701 USAwww.silabs.com

**Documents / Resources** 



<u>SILICON LABS 6.1.3.0 GA Bluetooth Mesh Software Development</u> [pdf] User Guide 6.1.3.0 GA Bluetooth Mesh Software Development, 6.1.3.0 GA, Bluetooth Mesh Software Development, Mesh Software Development, Development

## References

- Silicon Labs
- Silicon Labs
- <a>IoT Internet of Things Silicon Labs</a>
- Simplicity Studio Silicon Labs
- <a>Technical Support Silicon Labs</a>
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.