





# SILICON LABS RAIL SDK Complete Software User Guide

Home » SILICON LABS » SILICON LABS RAIL SDK Complete Software User Guide 1




#### **Contents**

- 1 SILICON LABS RAIL SDK Complete
- **2 Product Usage Instructions**
- **3 RAIL Applications**
- **4 Using This Release**
- 5 Installation and Use
- 6 FAQ
- 7 Documents / Resources
  - 7.1 References
- **8 Related Posts**



SILICON LABS RAIL SDK Complete Software



# **Specifications**

• Product Name: RAIL SDK 2.18.2.0 GA

• Simplicity SDK Suite Version: 2024.12.2 April 1, 2025

• Features: Complete software development suite for proprietary wireless applications, supports both proprietary and standards-based wireless protocols, supplied with extensive documentation and sample applications

# **Product Usage Instructions**

# **RAIL Applications**

# **New Items**

- Receiver node (only).
- Runtime PHY change: During measurement, the user can switch between more Profiles/PHYs. To ensure this, more PHYs must be added to the particular Range Test application with the Radio Configurator UI.

# **Improvements**

Changed in release 2.18.0.0

# **Fixed Issues**

Fixed in release 2.18.0.0

- ID # 1322797
- ID # 1375449
- ID # 1401181

# **Known Issues in the Current Release**

- ID # 1268208
- ID # 1268301
- ID # 1274248

ID # 1375450

# **Description:**

- The power consumption of DK2600 can't be optimized if configuration time for EM2 if UART is being used, as the value of SL\_IOSTREAM\_USART\_{instance}\_BAUDRATE doesn't take effect.
- · Range Test DMP instabilities in case of LTO.
- Wi-SUN HAN phys aren't supported by Standard packet assembler and Packet Assistant components.

**Workaround:** Update UART baud rate to 9600 bps at Simplicity Studio Admin Console. This is necessary for EM2.

Do not use LTO. Do not use Wi-SUN HAN phys with RAIL SDK sample applications.

# **Deprecated Items**

Deprecated in release 2.18.0.0 None.

# **Removed Items**

Removed in release 2.18.0.0 None.

## **Using This Release**

- This SDK depends on the Simplicity Platform. The Simplicity Platform code provides functionality that supports
  protocol plugins and APIs in the form of drivers and other lower layer features that interact directly with Silicon
  Labs chips and modules.
- Simplicity Platform components include EMLIB, EMDRV, RAIL Library, NVM3, and mbedTLS.
- Simplicity Platform release notes are available through Simplicity Studio's Documentation tab.

# **RAIL Applications**

#### **New Items**

#### Added in release 2.18.0.0

- simplicity\_sdk/app/flex is splitt into two:
  - simplicity\_sdk/app/rail (RAIL SDK)
  - simplicity\_sdk/app/connect (CONNECT SDK)
- RAIL SDK Services are documented at <a href="https://docs.silabs.com/rail/latest/rail-start/">https://docs.silabs.com/rail/latest/rail-start/</a>

# **Improvements**

# Changed in release 2.18.0.0

- The Range Test Applications are extended with 2x new features:
  - Remote Control: The receiver node can configure the transmitter node. Also, the measurement can be started by the re-ceiver node (only).

- Runtime PHY change: During measurement, the user can switch between more Profiles/PHYs. To
  ensure this, more PHYs must be added to the particular Range Test application with the Radio
  Configurator UI.
- Improve sleep by using Power Manager Integration component for all sleeping capable applications

#### **Fixed Issues**

#### Fixed in release 2.18.0.0

ID#	Description
1322797	Absolute time overflow has been fixed for Wireless M-Bus – Meter.
1375449	Support for Long Range phy has been fixed for Range Test and Simple TRX applications.
1401181	Fixed OFDM PA setting in Range Test Application for XG25 boards.

# **Known Issues in the Current Release**

ID#	Description	Workaround
126820812683 01	The power consumption of <i>DK2600</i> can't be op timized if configuration time for EM2 if UART is being used, as the value of <i>SL_IOSTREAM_US ART_{instance}_BAUDRATE</i> doesn't take effec t. The default value used instead is 115200 bps . Typical use case is RAIL – SoC Wireless M-bus Meter with DK2600 board.	Update UART baud rate to 9600 bps at Simp licity Studio Admin Console. This is necessary for EM2.
1274248	Range Test DMP instabilities in case of LTO.	Do not use LTO.
1375450	Wi-SUN HAN phys aren't supported by Standar d packet assembler and Packet Assistant components.	Do not use Wi-SUN HAN phys with RAIL SD K sample applications.

# **Deprecated Items**

Deprecated in release 2.18.0.0 None.

# **Using This Release**

This release contains the following:

- RAIL and Connect Sample Applications
- RAIL and Connect Components and Application Framework

This SDK depends on the Simplicity Platform. The Simplicity Platform code provides functionality that supports protocol plugins and APIs in the form of drivers and other lower layer features that interact directly with Silicon Labs chips and modules. Simplicity Platform components include EMLIB, EMDRV, RAIL Library, NVM3, and mbedTLS. Simplicity Platform release notes are available through Simplicity Studio's Documentation tab.

For more information about the Flex SDK v3.x see UG103.13: RAIL Fundamentals and UG103.12: Silicon Labs Connect Fundamentals. If you are a first time user, see QSG168: Proprietary Flex SDK v3.x Quick Start Guide.

## Installation and Use

The Proprietary Flex SDK is provided as part of the Simplicity SDK, the suite of Silicon Labs SDKs. To quickly get started with the Simplicity SDK, install Simplicity Studio 5, which will set up your development environment and walk you through Simplicity SDK installa-tion. Simplicity Studio 5 includes everything needed for IoT product development with Silicon Labs devices, including a resource and project launcher, software configuration tools, full IDE with GNU toolchain, and analysis tools. Installation instructions are provided in the online Simplicity Studio 5 User's Guide.

Alternatively, Simplicity SDK may be installed manually by downloading or cloning the latest from GitHub. See <a href="https://github.com/Sili-conLabs/simplicity\_sdk">https://github.com/Sili-conLabs/simplicity\_sdk</a> for more information.

Simplicity Studio installs the GSDK by default in:

- (Windows): C:\Users\<NAME>\SimplicityStudio\SDKs\simplicity sdk
- (MacOS): /Users/<NAME>/SimplicityStudio/SDKs/simplicity sdk

Documentation specific to the SDK version is installed with the SDK. Additional information can often be found in the knowledge base articles (KBAs). API references and other information about this and earlier releases is available on <a href="https://docs.silabs.com/">https://docs.silabs.com/</a>.

# **Security Information**

## **Secure Vault Integration**

When deployed to Secure Vault High devices, sensitive keys are protected using the Secure Vault Key Management functionality. The following table shows the protected keys and their storage protection characteristics.

Wrapped Key	Exportable / Non-Exportable	Notes
Thread Master Key	Exportable	Must be exportable to form the TLVs
PSKc	Exportable	Must be exportable to form the TLVs
Key Encryption Key	Exportable	Must be exportable to form the TLVs
MLE Key	Non-Exportable	
Temporary MLE Key	Non-Exportable	
MAC Previous Key	Non-Exportable	
MAC Current Key	Non-Exportable	
MAC Next Key	Non-Exportable	


- Wrapped keys that are marked as "Non-Exportable" can be used but cannot be viewed or shared at runtime.
- Wrapped keys that are marked as "Exportable" can be used or shared at runtime but remain encrypted while stored in flash.

For more information on Secure Vault Key Management functionality, see AN1271: Secure Key Storage.

## **Security Advisories**

To subscribe to Security Advisories, log in to the Silicon Labs customer portal, then select Account Home. Click HOME to go to the portal home page and then click the Manage Notifications tile. Make sure that 'Software/Security Advisory Notices & Product Change Notices (PCNs)' is checked, and that you are subscribed at minimum for your platform and protocol. Click Save to save any changes.

The following figure is an example:



# **Support**

Development Kit customers are eligible for training and technical support. Use the Silicon Labs Flex web page to obtain information about all Silicon Labs Thread products and services, and to sign up for product support. You can contact Silicon Laboratories support at <a href="http://www.silabs.com/support">http://www.silabs.com/support</a>.

## **SDK Release and Maintenance Policy**

For details, see SDK Release and Maintenance Poilcy.



#### **Disclaimer**

Silicon Labs intends to provide customers with the latest, accurate, and in-depth documentation of all peripherals and modules available for system and software imple-menters using or intending to use the Silicon Labs products. Characterization data, available modules and peripherals, memory sizes and memory addresses refer to each specific device, and "Typical" parameters provided can and do vary in different applications. Application examples described herein are for illustrative purposes only. Silicon Labs reserves the right to make changes without further notice to the product information, specifications, and descriptions herein, and does not give warranties as to the accuracy or completeness of the included information. Without prior notification, Silicon Labs may update product firmware during the manufacturing process for security or reliability reasons. Such changes will not alter the specifications or the performance of the product. Silicon Labs shall have no liability for the consequences of use of the infor-mation supplied in this document. This document does not imply or expressly grant any license to design or fabricate any integrated circuits. The products are not designed or authorized to be used within any FDA Class III devices, applications for which FDA premarket approval is required or Life Support Systems without the specific written consent of Silicon Labs. A "Life Support System" is any product or system intended to support or sustain life and/or health, which, if it fails, can be reasonably expected to result in significant personal injury or death. Silicon Labs products are not designed or authorized for military applications. Silicon Labs products shall under no circumstances be used in weapons of mass destruction including (but not limited to) nuclear, biological or chemical weapons, or missiles capable of delivering such weapons. Silicon Labs disclaims all express and implied warranties and shall not be responsible or liable for any injuries or damages related to use of a Silicon Labs product in such unauthorized applications.

#### **Trademark Information**

Silicon Laboratories Inc.®, Silicon Laboratories®, Silicon Labs®, Silabs® and the Silicon Labs logo®, Bluegiga®, Bluegiga Logo®, EFM®, EFM32®, EFR, Ember®, Energy Micro, Energy Micro logo and combinations thereof, "the world's most energy friendly microcontrollers", Redpine Signals®, WiSeConnect, n-Link, EZLink®, EZRadio®, EZRadioPRO®, Gecko®, Gecko OS, Gecko OS Studio, Precision32®, Simplicity Studio®, Telegesis, the Telegesis Logo®, USBXpress®, Zentri, the Zentri logo and Zentri DMS, Z-Wave®, and others are trademarks or registered trademarks of Silicon Labs. ARM, CORTEX, Cortex-M3 and THUMB are trademarks or registered trademarks of ARM Holdings. Keil is a registered trademark of ARM Limited. Wi-Fi is a registered trademark of the Wi-Fi Alliance. All other products or brand names mentioned herein are trademarks of their respective holders.

- Silicon Laboratories Inc.
- 400 West Cesar Chavez Austin, TX 78701

- USA
- www.silabs.com

## **FAQ**

- Q: Where can I find more information about security updates and notices?
  - A: For information about security updates and notices, see the Security chapter of the Platform Release
    Notes installed with this SDK or on the TECH DOCS tab on <a href="https://www.silabs.com/developers/flex-sdk-connect-networking-stack">https://www.silabs.com/developers/flex-sdk-connect-networking-stack</a>. Silicon Labs also strongly recommends that you subscribe to Security
    Advisories for up-to-date information.
- Q: What compilers are compatible with the RAIL SDK?
  - A: Compatible Compilers: GCC (The GNU Compiler Collection) version 12.2.1, provided with Simplicity Studio.

#### **Documents / Resources**



SILICON LABS RAIL SDK Complete Software [pdf] User Guide RAIL SDK, RAIL SDK Complete Software, Software

### References

- Software Developer Docs Silicon Labs
- Silicon Labs
- Silicon Labs Community
- loT Internet of Things Silicon Labs
- Simplicity Studio Silicon Labs
- Technical Support Silicon Labs
- Software Developer Docs Silicon Labs
- Silabs Documentation Search
- User Manual

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.