


# SILVER MONKEY SMXC038 Splitter PWM Kable ATX i Molex User Manual

[Home](#) » [SILVER MONKEY](#) » SILVER MONKEY SMXC038 Splitter PWM Kable ATX i Molex User Manual 

## SILVER MONKEY X

User Manual  
SMXC038



### Contents

- [1 SMXC038 Splitter PWM Kable ATX i Molex](#)
- [2 Safety information](#)
- [3 Package contents](#)
- [4 Intended use and construction](#)
- [5 How to use the product](#)
- [6 Specification](#)
- [7 Warranty and technical support](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)

**SMXC038 Splitter PWM Kable ATX i Molex**

Carefully read these instructions before using the product. Keep it for future reference.

## Safety information

- Avoid direct contact with water and other liquids.
- Do not use the device in a humid environment
- Keep the device out of the reach of children They may swallow some parts
- Use the device only in accordance with the operating instructions
- If the device stops working properly – contact us.

## Package contents

- Splitter PWM
- User manual

## Intended use and construction

SMxX Bise is a cable that allows easy connection and speed control of up to 4 PWM fans.

(A) 1x 4-pin PWM connector

(B) 4x 4-pin PWM socket

## How to use the product

**NOTE:** Before you start assembling the fans, make sure the computer is turned off and unplugged from the power supply.

1. Connect the 4-pin fan connectors to the splitter, The fans should be connected to the output connectors (connected with a shorter cable), while the input connector should be plugged into the appropriate connector on the motherboard\*. Fan speed is transmitted only from the input connector.

\* Most often this is CPU\_Fan, but we recommend checking the motherboard manufacturer's manual

## Specification

SMxC038	
Input port	1
Output ports	4

## Warranty and technical support


Your product is covered by a 24-month manufacturer's warranty.

For more information go to [www.silvermonkey.com/support](http://www.silvermonkey.com/support) If you have questions about using the product – contact us at [kontakt@silvermonkey.com](mailto:kontakt@silvermonkey.com).

### Manufacturer:

Silver Monkey sp. z o.o., ul. Twarda 18, 00-105 Warszawa, Poland.

## Disposal and the EU compliance statement

 We, as the manufacturer of this equipment, declare that it meets the rules of the appropriate EU directives. If you need a copy of the EU Declaration of Conformity – contact us.



Do not throw this equipment out with other household waste This equipment is made from materials that may be harmful to the environment and human health, if the product is disposed of in the wrong way. When you need to throw away an old product, take it to a designated collection point.

# SILVER MONKEY

---

## Documents / Resources



[SILVER MONKEY SMXC038 Splitter PWM Kable ATX i Molex](#) [pdf] User Manual  
SMXC038 Splitter PWM Kable ATX i Molex, SMXC038, Splitter PWM Kable ATX i Molex, PWM Kable ATX i Molex, Kable ATX i Molex, i Molex

## References

- [User Manual](#)

### [Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.