



SIMPLi HOME AXCAMH19-GR Multi Cube Bookcase and Storage Unit User Guide

[Home](#) » [SIMPLi HOME](#) » SIMPLi HOME AXCAMH19-GR Multi Cube Bookcase and Storage Unit User Guide 

Contents

- [1 SIMPLi HOME AXCAMH19-GR Multi Cube Bookcase and Storage Unit](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 For the Fastest Customer Service](#)
- [5 Safety Information](#)
- [6 Care & Maintenance](#)
- [7 Pre-Assembly Information](#)
- [8 Hardware Description](#)
- [9 Components – Key Diagram](#)
- [10 Assembly](#)
- [11 Furniture Tip-Over Restraint Assembly](#)
- [12 Furniture Anti-Tipping Restraint Instructions](#)
- [13 Documents / Resources](#)
 - [13.1 References](#)

SIMPLiHOME

SIMPLi HOME AXCAMH19-GR Multi Cube Bookcase and Storage Unit



Product Information

The Amherst / Halifax / Washington Multi Cube Bookcase and Storage Unit is a high-quality furniture product from Simpli Home, America's top brand for high-value furniture. The model number of the product is AXCAMH19-GR.

Product Usage Instructions

1. Assembly: This product may require the help of two people to assemble for ease. The Pre-Assembly Information section of the user manual provides detailed information on the parts required for assembly.
2. Care and Maintenance: This furniture is designed for indoor use. To maintain it, determine the annual average relative humidity for your space and try to keep it as close to that average as possible, generally within about 10% up or down. De-humidify in the summer and humidify in the winter. Furniture that is sealed and lacquered will lose moisture more slowly than an unfinished piece while pieces with veneer finishes are not only stronger but lose moisture more slowly than other finishes.
3. Contacting Customer Service: For any issue with the product, customers can contact Simple Home's customer service by scanning the QR code present in the user manual or by emailing them at customerservice@simpli-home.com. Customers can also visit their website or call them at 1-866-518-0120 between Monday to Friday 9 am to 5 pm EST.


Great quality is a right.

Thank you for shopping with Simpli Home, America's top brand for high-value furniture.

It's time to register your product warranty.

It's quick and easy. And you'll be happy you did.

- Activate your 1-year warranty
- Automatic entry to win a \$500 gift certificate
- Earn instant rewards and save



- simpli-home.com/product-registration

Review your product and collect rewards!


Thank you for your purchase! We hope you enjoy it. We'd love your feedback. Please share a review and get instant rewards!



simpli-home.com/product-review

Share photos and get your cash back!

Send us images or share them on social and qualify for instant rewards. You may even receive a store credit on your entire purchase!



For the Fastest Customer Service



1. Open your phone's camera.
2. Point your phone's camera at the QR code to scan.
3. Click on the popup.
4. You'll be taken to our customer service page.
5. Fill out the form with your order information and issue.
6. Submit the form.
7. A customer service associate will contact you.

Other ways to contact us...

- customerservice@simpli-home.com
- Visit our site directly at
- www.simpli-home.com
- 1-866-518-0120 Monday to Friday 9am to 5 pm EST
- If you've purchased from a retailer and you wish to return the product, please contact the retailer directly.

- **IMPORTANT:** Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

Safety Information

- **CAUTION:** Injuries and damage can occur from furniture tip over if product is not properly anchored to the wall. Use the Furniture Anti-Tipping Restraint provided with the product. Consult our assembly instructions for help.
- If the Furniture Anti-Tipping Restraint kit is not in the box, please contact our customer service department in order to obtain another kit before using the furniture.
- Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required. Hardware package may have spare parts.
- **WARNING:** This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.
- May require 2 people for ease of assembly.

Care & Maintenance

- This furniture is designed for indoor use.
- Perhaps the greatest environmental damage to wood furniture comes from wide swings in relative humidity (RH) in our homes. Wood absorbs and desorbs water as relative humidity rises and falls, and in doing so it swells and shrinks. Making matters worse, it expands and contracts unequally along different grain directions. As humidity changes, the components of wooden objects are continually pushing and pulling against each other. This pressure often results in parts of furniture no longer fitting together closely or becoming distorted or breaking from their own internal stresses.
- The response to relative humidity changes begins with determining the annual average RH for your particular space. Then try to keep the RH in the space where your furniture is as close to that average as possible, generally within about 10% up or down. De-humidify in the summer and humidify in the winter.
- Be aware that raising the temperature lowers the humidity and vice versa. Thus, modern heating systems, which can drive down interior RH in the winter, almost invariably cause problems for furniture. To counteract their effect, you can either modify the RH by keeping furniture containing spaces cooler in the winter or most importantly, have a good working humidifier for your home. A humidistat automatically works to balance the humidity in your home so it is constant. Dry indoor air can suck enough moisture from its surroundings to do permanent damage to wood, causing it to crack or split.
- Remember, that not all woods are created equal. Two factors that help determine how rapidly a wood will lose moisture are pore size and surface hardness. A piece made from a dense and hard wood will dry less rapidly than pieces made from softer woods.
- Furniture that is sealed and lacquered will lose moisture more slowly than an unfinished piece while pieces with veneer finishes are not only stronger but lose moisture more slowly than other finishes.

To help protect your wood furniture, take these steps:










- Use a humidifier, preferably one with an automatic control system that can sense the humidity level and adjust







itself accordingly

- Don't over-humidify; that can damage wood by causing it to expand and contract
- Keep furniture out of direct sunlight, which can cause it to dry out, crack and warp
- If you can avoid it, don't put furniture near heating vents; if you can't, keep the item 3 to 4 inches away from the wall, giving the heat and air space to circulate
- Dust with soft dry cloth
- Do not use liquid or aerosol products
- To avoid marking, do not place rubber on surface (foot pads, etc.)
- For soil build-up, wipe with damp cloth & dry
- Do not use abrasive cleaners










Pre-Assembly Information


Part Description

A  TOP QTY 1	B  LEFT SIDE QTY 1	C  RIGHT SIDE QTY 1
D  BOTTOM SHELF QTY 1	E  CENTRE SHELF QTY 1	F  DIVIDER QTY 1
G1  DIVIDER QTY 1	G2  DIVIDER QTY 1	H  BOTTOM DIVIDER (L&R Same) QTY 2

I  DIVIDER QTY 1	J  Warning Label TOP BACK PANEL QTY 1	KL  LEFT BACK PANEL QTY 1
KR  RIGHT BACK PANEL QTY 1	K1  MIDDLE BACK PANEL QTY 1	K2  BOTTOM BACK PANEL QTY 1

Hardware Description


1  ALLEN KEY SCREW M6 X 30mm QTY 15	2  CAM LOCK PIN CAM LOCK QTY 10 SETS	3  ALLEN KEY QTY 1
4  WOOD DOWEL Ø8 X 30mm QTY 27	5  PHILLIPS SCREW ROUND HEAD M4 X 15mm QTY 37	6  a.  M4 X 25mm - QTY 2 (1 is extra) b.  M4 X 15mm - QTY 1 c.  M4 X 25mm - QTY 1 FURNITURE TIP OVER RESTRAINT QTY 1 SET



Required -
 Flathead screwdriver
 Phillips screwdriver
 Rubber mallet
Not Included




Components – Key Diagram




Assembly

Step 1




1. Insert four Dowels 4 into guide holes on each part F , G1 , G2 , H , I .
2. Use rubber mallet to tap Dowels 4 into bottom of holes securely. 1/2 length of Dowels should be exposed.

Step 2




1. Align Wood Dowels with guide holes on part H , G and attach parts I , H to part G2 .

Step 3




1. Align Wood Dowels with guide holes on part E and attach parts I , H to part E .

Step 4.




1. Attach Bottom Dividers H to Bottom Shelf D using six Allen Key Screws 1 through guide holes.
2. Use Allen Key 3 to tighten Screws. Do not over-tighten

Step 5




1. Align Wood Dowels with guide holes on part E and attach part F to part E .

Step 6




1. Align Wood Dowels with guide holes on part F and attach part G1 to part F

Step 7




1. Attach five Cam Lock Pins 2 into pre-drilled holes on each Side B, C.
2. Use a Phillips screwdriver to secure Cam Lock Pins. Do not over-tighten.

Step 8




1. Align Cam Lock Pin with guide holes on parts E, and D and attach Right Side C to parts D, and E.




2. Insert two Cam Locks 2 into guide holes on part E .
3. Insert three Cam Locks 2 into guide holes on part D .
4. Use Phillips screwdriver to secure Cam Locks.

Step 9




1. 1. Align Cam Lock Pin and Wood Dowels with guide holes on parts E , D , B and attach Left Side B to parts D , E , G1 .
2. Insert two Cam Locks 2 into guide holes on part E .
3. Insert three Cam Locks 2 into guide holes on part D .
4. Use Phillips screwdriver to secure Cam Locks.

Step 10




1. Attach Top A to B , C , F using Allen Key Screws 1 through guide holes.
2. Use Allen Key 3 to tighten Screws. Do not over-tighten.

Step 11



Note:

- The back of the bookcase frame does not have pre-drilled holes to attach the back panels.




1. Attach the Back Panels J , KL ,KR , K1 , K2 to back of the cube using Phillips Screws Round Head 5 into guide holes.
2. Use Phillips Screwdriver to tighten screws.

Furniture Tip-Over Restraint Assembly


WARNING

- Serious or fatal crushing injuries can occur from furniture tip-over.
- If the furniture tip-over restraint kit is not in the box, please contact our customer service department in order to obtain another kit before using the furniture.




Furniture Anti-Tipping Restraint Instructions


1. Attach one of the mounting brackets securely to the back edge of the furniture. Use the shorter screw.



- Determine where furniture is to be placed and mark location on the wall for mounting bracket screw hole approximately 2 inches below the bracket mounted to the furniture.




- Drill a 3/16 inch hole in the wall. Press the plastic anchor into the hole and gently tap until the flange on the anchor is against the wall surface.
- Position the bracket over the anchor and use the longer screw to securely attach the bracket to the wall.
- Place the furniture so the back edge is in line with the bracket on the wall.
- Lace an end of the nylon zip-tie strap down through each bracket. Bring both ends together and slide the smooth side upright through the square-shaped end and pull through to create the "locked" position.
- Check to make sure the strap is securely laced and locked to the brackets.




- DO NOT put a TV or other heavy objects on top of furniture not intended for use with a TV
- DO NOT place heavy objects in top drawers or on top shelves
- DO NOT let children climb or hang on drawers, doors or shelves

simpli-home.com/product-registration

Documents / Resources

	<p>SIMPLI HOME AXCAMH19-GR Multi Cube Bookcase and Storage Unit [pdf] User Guide AXCAMH19-GR, AXCAMH19-GR Multi Cube Bookcase and Storage Unit, Multi Cube Bookcase and Storage Unit, Bookcase and Storage Unit, Storage Unit</p>
---	---

References

-  [Fairway Independent Mortgage Corporation](#)
-  [Online Furniture Store | Home Furniture | Simpli Home](#)

Manuals+.