Skip to content

Manuals+

User Manuals Simplified.



SimpliSafe CMOB1 Wireless
Outdoor Security Camera
User Guide

Home » SimpliSafe » SimpliSafe CMOB1 Wireless
Outdoor Security Camera User Guide

Contents hide

- 1 SimpliSafe CMOB1 Wireless Outdoor Security Camera
- 2 CMOB1 FCC Statement Procedure
- **3 Federal Communication Commission Interference**

Statement
4 Industry Canada Statement
5 Documents / Resources
6 Related Posts



SimpliSafe CMOB1 Wireless Outdoor Security Camera



CMOB1 FCC Statement Procedure

1. Quick Start Guide in Box tells users to download app

1

Use the included cable to charge your battery

Charging takes around 5 hours. The 3 LEDs will light up when it's fully charged.




2. App links to FCC Statement Main Menu > Setting > FCC Statement 2

Set up your camera using the mobile app

Download the SimpliSafe mobile app, tap "Set up a camera," and follow the instructions.





Federal Communication Commission Interference Statement

The devices listed above comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) The devices may not cause harmful interference, and (2) the devices must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment

should be installed and operated with minimum distance 20cm between the radiator & your body.

Industry Canada Statement

This device complies with ISED's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement:

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with greater than 20cm between the radiator & your body.

Documents / Resources



<u>SimpliSafe CMOB1 Wireless Outdoor Security Camera</u> [pdf] User Guide CM3000, U9K-CM3000, U9KCM3000, CMOB1 Wireless Outdoor Security Camera, CMOB1, Wireless Outdoor Security Camera

Manuals+.

- home
- privacy