



SIMPLYRFID CS108 Wave RFID Handheld Reader User Guide

[Home](#) » [SIMPLYRFID](#) » SIMPLYRFID CS108 Wave RFID Handheld Reader User Guide 



Contents

- [1 SIMPLYRFID CS108 Wave RFID Handheld Reader User Guide](#)
- [2 Install the battery in your handheld:](#)
- [3 Now it's time to configure your iPhone](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

SIMPLYRFID CS108 Wave RFID Handheld Reader User Guide



This guide provides simple steps to let you quickly start using your new Wave RFID handheld reader.

Please begin by checking the contents of this box.
It should include:


- CS108 RFID Sled Handheld Reader
- CS108B Battery
- USB Type C to USB Type A cable
- This guide



Install the battery in your handheld:


Step 1

To access the battery compartment, remove the battery cover:



Step 2

To insert the battery pack into the battery compartment:




Step 3

The battery should be fully secured by the battery spring-loaded clip as shown.



Step 4

Replace the battery cover. Make sure that the locking tabs at the front of the battery cover are fully inserted into the slots.



Step 5

Fully rotate to close the metal latches to secure the battery cover in position.



Now it's time to configure your iPhone

Step 1

First, scan this QR code using your iPhone to download the Wave app:



Or you can search "SimplyRFID" in the app store to locate the Wave Enterprise app.

Step 2

Once the Wave app is installed, be sure to enable Bluetooth by opening the Settings app and switching Bluetooth to On.



Note: Do not use the Bluetooth pairing screen to connect the CS108 to your iPhone, that step comes later.

Step 3

To power on CS108, press and hold the power button for 3 seconds and then release, after that the GREEN LED will light up continuously.




Finally, configure the Wave app

Tap on the Wave icon on your iPhone to launch the app. The first time the app runs, you will be prompted to connect to your scanner. If the scanner is powered on it will show up in the list of devices. Identify your handheld by comparing the serial number of your device to the number displayed on the screen.



On the next screen you'll be prompted to check your email for a QR code. You'll need to use the CS108 handheld to scan this code. Once the code is scanned the handheld will be ready to use!



Read More About This Manual & Download PDF:

Documents / Resources



[SIMPLYRFID CS108 Wave RFID Handheld Reader](#) [pdf] User Guide
CS108, Wave RFID Handheld Reader, CS108 Wave RFID Handheld Reader, RFID Handheld Reader, Handheld Reader, Reader

[Manuals+.](#)