



SimRush AC3 Indoor Wireless Controller Installation Guide

[Home](#) » [SimRush](#) » SimRush AC3 Indoor Wireless Controller Installation Guide 



Contents

- [1 SimRushAC3](#)
- [2 Indoor Unit \(Controller\)](#)
- [3 Outdoor Unit \(ODU\)](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

SimRushAC3

The Sim Rush AC3 is an indoor wireless controller I router for your network. It is pre-configured out of the box and managed through the Sim Rush web portal CPanel. To get online, simply plug in your Sim Rush Outdoor unit (ODU) as instructed below.

Indoor Unit (Controller)


Make sure you follow the following steps to get online.

1. Connect the ethernet cable to Ethernet Port 5 (Highlighted in GREEN)
2. Connect the Controller to the power adaptor supplied (24v 1.2a DC)
3. Connect your PC to the LAN (Highlighted in ORANGE)
 - a. Ethernet port 2, 3 or 4
 - b. Wireless- Default wireless is "SimRush-xx0ox" and the Serial number as the password, e.g AABBC112233
 - Serial number is located on the box or back of the controller, all characters before the "/123
4. To make changes to the LAN address or Wireless settings, please visit sPanel <https://portal.simrush.com/>



<https://portal.simrush.com/>

5. (OPTIONAL) Connect your alternative broadband to utilize the built-in Load-Balancing feature, connect Ethernet Port1 (Highlighted in RED) to your alternative broadband network Please ensure your alternative broadband router is providing the following network via DHCP: Gateway: [192.168.1.1](#), Subnet: 255.255.255.0



Outdoor Unit (ODU)

Please see ODU Guide

SimRush Redefining Superfast

Registered Address: Quartermaster House, Dewing Road, Rackheath, Norfolk NR13 6PS, UK Company Reg: 10237 486 I VAT Reg: 273687952

T. 0330 0563 11 0
E: hello@simrush.com
W: www.simrush.com

Documents / Resources

<div><div><div><div><div><div></div><div>SimRush</div></div></div><div><div><div>Indoor AC3</div><div>Indoor Wireless Controller</div></div><div><div>1. Unpack the controller from the shipping container and remove the protective foam.</div><div>2. Connect the controller to the power source.</div><div>3. Connect the controller to the antenna.</div><div>4. Connect the controller to the antenna.</div><div>5. Connect the controller to the antenna.</div><div>6. Connect the controller to the antenna.</div><div>7. Connect the controller to the antenna.</div><div>8. Connect the controller to the antenna.</div><div>9. Connect the controller to the antenna.</div><div>10. Connect the controller to the antenna.</div></div></div><div><div><div>Indoor AC3</div><div>Indoor Wireless Controller</div></div><div><div>1. Unpack the controller from the shipping container and remove the protective foam.</div><div>2. Connect the controller to the power source.</div><div>3. Connect the controller to the antenna.</div><div>4. Connect the controller to the antenna.</div><div>5. Connect the controller to the antenna.</div><div>6. Connect the controller to the antenna.</div><div>7. Connect the controller to the antenna.</div><div>8. Connect the controller to the antenna.</div><div>9. Connect the controller to the antenna.</div><div>10. Connect the controller to the antenna.</div></div></div></div></div><div><div><div>SimRush AC3 Indoor Wireless Controller [pdf] Installation Guide</div><div>AC3, Indoor Wireless Controller, AC3 Indoor Wireless Controller</div></div></div></div>

References

- [!\[\]\(746d018fdf6ab02bf5fb7681133e8b29_img.jpg\) SimRush Login](#)