

Singke EP033A4 Wireless Microphone Type C Receiver User Manual

[Home](#) » [Singke](#) » Singke EP033A4 Wireless Microphone Type C Receiver User Manual 

Contents

- [1 Single EP033A4 Wireless Microphone Type C Receiver](#)
- [2 Introduction](#)
- [3 ID Diagram](#)
- [4 How to use](#)
- [5 About UI](#)
 - [5.1 Microphone Transmitter](#)
 - [5.2 Type-C Receiver](#)
 - [5.3 The indicator light of case](#)
- [6 Packing List](#)
- [7 Documents / Resources](#)

Singke


Single EP033A4 Wireless Microphone Type C Receiver




Introduction

Thanks for choosing our product. This product is a smart wireless microphone that provides professional-grade recording output. Plug and play, no app required. It can be used in different circumstances such as Live, Video Recording, Interviewing, Online Teaching and others. The wireless Microphone consists of two parts, one is a Microphone transmitter *4, and the other one is a Type-C receiver. (See as below picture)

- (Microphone Transmitter *4)





- (Type-(Receiver)



ID Diagram

1. The indicator light of case
2. Type-c port of the case
3. The indicator light of microphone
4. Reset the key of microphone

5. Microphone clip
6. Metal contact of microphone
7. Type-c port
8. Indicator light of receiver
9. Reset key of receiver





Note:

1. The indicator light Lt) faces outward when put the microphone into charging case, otherwise it can' t be charged normally.
2. The indicator light faces outward when putting the receiver into the charging case, otherwise it can' t be magnetized (built-in magnet} and will cause shaking.


some Android phones may have incompatibility problems due to system, please consult your dealer for details

How to use

- **First:** Open the storage case. The microphone will be turned on and the green light will flash slowly. The Type-(receiver has no light indicating.



- **Secondly:** Connect the Type-(receiver to phone . It is paired successfully when the green light of receiver and the green light of microphone keeps always on. Then open the phone camera, live Apps or others to use the microphone to receive sound.



Note: If the mobile phone has OTG function, please manually open OTG to use

About UI

Microphone Transmitter

| | | | |
|-------------------|---|---|-----------------------------|
| Power on | Open the case | | Green light on |
| Power off | <p>a.t'UI n mm me case ana oose me cover</p> <p>bl \\iif/:er off if no reconnection</p> | | / |
| Charging | Put it into the case | — | / |
| Low battery alarm | Battery is below 20% | | |
| Pairing | Automati(ally search for pairing once starting-up | | Blue light flashes slowly |
| | | | Green light flashes slowly |
| Paired | Auto pairing | | Green light on |
| Clea r pairing | Press reset key twi ce quickly | | Green light flashes quickly |

Type-C Receiver

| Function | How to use | Light |
|------------------------------|---|-----------------------------|
| Power on | Plug in the device | Green light on |
| Power off | Plug off the device | / |
| Pairing | Automatic 1 search for pairing once start in -up | Green light flashes slowly |
| Paired | Auto pairing | Green light on |
| Clear pairing | Press reset key twice quickly | Green light flashes quickly |
| Paired (connect to 1 mic) | / | Green light always on |

The indicator light of case

| Function | Light |
|---|---|
| Case charging | Charging : red light always keeps on Fully charged: red light off |
| Put the microphone into the first compartment | Charging: green light flashes slowly Fully charged: green light off |
| Case recharge microphones*1 | Fully charged: light off |
| Battery level of case indicating | Green light on: 100%-75% Blue light on: 74%-36% Red light flashes: 35%-0% |

Packing List

1. 1 Microphone transmitter
2. 1 Type-(receiver
3. Storage case
4. 1 Type-C charging cable
5. 1 User manual
6. 1 Windproof wool

Documents / Resources


Wireless Microphone

Quick Manual




Introduction

Thank you for purchasing this product. Please read this manual carefully before using the product to avoid damage to the product and ensure safe use. This manual contains important information about the product and its use. Please read this manual carefully before using the product.




Diagram



1. Connect the transmitter to the receiver.
2. Connect the receiver to the power source.
3. Connect the transmitter to the power source.
4. Connect the receiver to the power source.

How to use



About Us

| Model | EP033A4 |
|--------------------|-------------------------------------|
| Product Name | Wireless Microphone Type C Receiver |
| Product Type | Microphone |
| Product Color | Black |
| Product Weight | 1.2kg |
| Product Dimensions | 100mm x 50mm x 20mm |

Specifications

| Parameter | Value |
|-----------|--------|
| Frequency | 2.4GHz |
| Power | 10W |
| Range | 100m |
| Channel | 1 |

Packing List

- 1. Transmitter
- 1. Receiver
- 1. Power Adapter
- 1. User Manual

[Singke EP033A4 Wireless Microphone Type C Receiver](#) [pdf] User Manual
EP033A4 Wireless Microphone Type C Receiver, EP033A4, Wireless Microphone Type C Receiver, Microphone Type C Receiver, Type C Receiver, Receiver