



siren marine SM-ACC-INFR Infrared Motion Sensor Instructions

[Home](#) » [siren marine](#) » siren marine SM-ACC-INFR Infrared Motion Sensor Instructions 




Contents

- [1 SM-ACC-INFR Infrared Motion Sensor](#)
- [2 Installation Instructions:](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

SM-ACC-INFR Infrared Motion Sensor

Infrared Motion Sensor Wiring Diagram (12 VDC System Only)




Installation Instructions:

1. Connect white sensor wire to Security 1 (pink) on the wiring cable.
2. Connect green sensor wire to DC common ground.
3. Connect black sensor wire to DC common ground.
4. Connect red sensor wire to +9VDC to +16VDC power source.
(DO NOT EXCEED +16V DC).

Product SKU: SM-ACC-INFO

Documents / Resources



[siren marine SM-ACC-INFR Infrared Motion Sensor](#) [pdf] Instructions
SM-ACC-INFR Infrared Motion Sensor, SM-ACC-INFR, Infrared Motion Sensor