

sistema KLIP IT PLUS 1L Rectangle Container Instructions

<u>Home</u> » <u>Sistema</u> » sistema KLIP IT PLUS 1L Rectangle Container Instructions

sistema KLIP IT PLUS 1L Rectangle Container



KLIP IT PLUS™ modular stacking for an organised pantry and fridge. Sistema's distinctive easy locking clips and flexible seal ensure food stays fresher for longer. The Sistema® KLIP IT PLUS™ range is versatile, durable, and hard wearing, resolving all food storage needs. The rectangular range is designed with corner shoulders on the base for perfect compact nesting when not in use. Food safe, freezer safe, microwave safe (without lid) and dishwasher safe (top rack).

Contents

- 1 Use and Care
 - 1.1 Care Guidelines
 - 1.2 Microwaving
 - 1.3 Freezing
 - 1.4 Warnings
- **2 CUSTOMER SUPPORT**
- 3 Documents /

Resources

- 3.1 References
- **4 Related Posts**

Use and Care

To keep your Sistema® KLIP IT PLUS™ container looking its best, the following are recommended:

Care Guidelines

- Remove all labels/packaging and wash before use.
- Sistema® KLIP IT PLUS™ containers are safe for normal household dishwashers (top rack only). Ensure the
 containers are secure on the top rack, this prevents them from contacting the heating element and avoids
 melting.
- Warm soapy water can also be used to wash the containers.
- Do not use abrasive cleaners or scrubbers as they may cause dullness to the finish.
- Do not use utensils with sharp edges (e.g., knives) in the container. They could scratch or scuff the container surface.

Microwaving

- Sistema® KLIP IT PLUS™ containers can be used to reheat pre-cooked foods (without lid).
- Follow the recommended food storage directions, use, or heating instructions, based on the knowledge about
 the food or the information on the food label. Also follow the microwave manufacturer's recommendation when
 defrosting or reheating foods.
- When microwaving, remove the lid to allow steam to vent. To prevent splattering, cover with a paper towel.
 Sealing plastic lids while heating may create extra pressure causing the lid to warp or create dangerous steam build-up.

Freezing

- Sistema® KLIP IT PLUS™ containers are safe for freezer use.
- Foods containing water expand when frozen. Leave sufficient space in container when freezing to allow for expansion.
- Containers can become stiff after freezing. Allow the container to rest for a few minutes at room temperature or run under warm water before opening or microwaving.

Warnings

- These containers may stain when reheating foods like tomato based sauces, beetroot, curries, food seasoned with the herb turmeric, or foods with high fat or high sugar content.
- Reheating and/or melting butter or foods high in salt, oil, fat or sugar content (i.e. chocolate, candies, syrup) could lead to severe damage and potentially melt the container.
- Avoid using plastic wrap on or inside the container during microwave use. The plastic wrap could heat, melt, and adhere to the container walls.
- These containers are not intended for cooking. Excessive reheating time in the microwave may damage the container.











CAUTION: Remove lid when in microwave to avoid dangerous steam build-up. Do not use in a conventional oven, on a hot plate, under the grill, on the stove top or in convection microwave oven using convection settings. Use care when handling a container with hot contents or after reheating in the microwave

CUSTOMER SUPPORT



www.sistemaplastics.com



Documents / Resources



sistema KLIP IT PLUS 1L Rectangle Container [pdf] Instructions

KLIP IT PLUS 1L Rectangle Container, KLIP IT, PLUS 1L Rectangle Container, Rectangle Container, Container

References

• Sistema® Plastics: Lunch Boxes | Kitchen Storage Containers

Manuals+, home privacy