

SKYLIGHT FS.30 Deck Mounted Fixed Step Flashing



SKYLIGHT FS.30 Deck Mounted Fixed Step Flashing Instruction Manual

[Home](#) » [Skylight](#) » SKYLIGHT FS.30 Deck Mounted Fixed Step Flashing Instruction Manual 

Contents

- 1 SKYLIGHT FS.30 Deck Mounted Fixed Step Flashing
- 2 Product Specifications
- 3 Product Usage Instructions
- 4 Installation and safety manual
- 5 SAFETY INSTRUCTIONS
- 6 WARRANTY CARD
- 7 Documents / Resources
 - 7.1 References
- 8 Related Posts

**SKYLIGHT
HYPERBAR F**

SKYLIGHT FS.30 Deck Mounted Fixed Step Flashing



Product Specifications

- **Model:** FXS.15, FS.30, FM.45, FL.60, FXL.75
- **Dimensions:** 15×13 cm, 30×13 cm, 45×13 cm, 60×13 cm, 75×13 cm
- **Power:** 16 W, 32 W, 48 W, 64 W, 80 W
- **Luminous Flux:** 1350 lm, 2700 lm, 4050 lm, 5400 lm, 6750 lm
- **Color Temperature:** 3000-30000K adjustable
- **Voltage:** 12 V DC
- **Cable Length:** 1.5 m
- **Water-Resistance Class:** IP67
- **Wi-Fi Frequency:** 2.4 GHz
- **Wi-Fi Security Standard:** WPA2
- **Minimum OS Version:** Android 10 or iOS 15

Product Usage Instructions

Cleaning and Maintenance

- The PMMA glass cover of the LED module should be cleaned with a soft cloth and no chemicals. Do not clean the lamp while it is turned on.

Power Supply Compatibility

- Use only compatible power adapters listed in the manual to prevent damage to the lamp or power supply.

Installation

- The lamps come with standard holders (H version) for placement on the aquarium edges or NH version for integration with other holders/stands. Refer to Table 1 for electrical specifications based on the model.

Repairs and Disposal

- Do not attempt to repair a damaged lamp yourself. Contact your supplier for lamp servicing. LED modules should only be replaced by qualified personnel. Dispose of the product following local regulations.

Frequently Asked Questions (FAQ)

Q: Can I use a power adapter not listed in the manual?

A: Using an incompatible power supply can damage the lamp or power supply. Stick to the listed compatible adapters for safe operation.

Q: How do I adjust the color temperature of the light?

A: The color temperature is adjustable within the range of 3000-30000K. Refer to the manual for instructions on adjusting the color temperature.

Q: What should I do if my lamp is not working properly?

A: If you encounter issues with the lamp's functionality, first check the power supply and connections. For further troubleshooting or repairs, contact your supplier.

Installation and safety manual

- The HYPERBAR series lamps are manufactured in various versions to suit different aquarium dimensions.
- They are supplied with a set of standard holders (H version) to be placed on the edges of the aquarium or in the NH version for integration with other types of holders/stands.
- The electrical specifications of the different versions are shown in Table 1.

Model	FX S.1 5	FS.30	FM. 45
Dimension	15 × 13 cm	30 × 13 cm	45 × 13 cm
Power rating	16 W	32 W	48 W
Luminous flux	1350 lm	2700 lm	4050 lm
Model	FL.60		FXL.75
Dimension	60 × 13 cm		75 × 13 cm
Power rating	64 W		80 W
Luminous flux	5400 lm		6750 lm
Colour temperature	3000-30000K adjustable		
Voltage rating	12 V DC		
Cable length	1,5 m*		
Water-resistance class	IP67		
Wi-Fi frequency	2,4 GHz		
Wi-Fi security standard	WPA2		
Minimum operation system version	Android 10 or iOS 15		

Table 1.a. HYPERBAR – specification.

SAFETY INSTRUCTIONS

- The product is only intended to be used for aquarium lighting, indoors and at room temperature.
- Follow the installation instructions.
- Keep children and pets other than your aquarium animals away from the lamp.
- Do not use a mechanically damaged device, do not modify the construction.
- Do not switch on the device if any cable(including the power supply)is damaged.
- Only intended to be used with one of the dedicated power supplies*).
- Do not exceed electrical ratings!
- Do not look directly into the light source.
- Turn the lamp on only after it is installed over the aquarium.
- Do not cover the lamp with rugs or blankets.

GENERAL INSTRUCTIONS AND HANDLING

- The PMMA glass cover of the LED module should be cleaned using a soft cloth and with no chemicals.
- Do not clean the lamp when it is turned on or other power supplies with identical parameters.

List of compatible power adapters:

FXS.15	ESPE2412
FS.30	ESPE3612
FM.45	ESPE6012
FL.60	ESPE9012
FXL.75	ESPE9012

CAUTION:

- Using an inappropriate power supply will result in damage to the lamp or power supply itself!

REPAIRS AND UTILIZATION

- Do not try to repair a damaged lamp. For information about lamp service contact your supplier. The LED module in this lamp is not intended to be replaced by unqualified personnel.
- LED modules are available from your supplier, contact them for details. The product cannot be disposed of as unsorted municipal waste. According to the directive 2012/19/UE, the device should be disposed of at designated collection points.
- WARRANTY SKYLIGHT warrants this product to be free of defects in material and workmanship under normal use for 2 years from the date of purchase.
- The obligation of this warranty is limited to the repair or replacement of defective elements.
- No claim shall be allowed under this warranty if, in the opinion of SKYLIGHT, this product has been subject to

accident or improper usage, including, but not limited to: damage, improper storage, accidental dropping, etc.

- Please send the damaged device to your supplier including the power supply and cables, the completed warranty card, and receipt.
- The serial number on the device has to be the same as on the warranty card.
- The obligation of this warranty is limited to the device bought, and no claim shall be allowed under this warranty due to damage or loss of any other objects.

WARRANTY CARD

Model

- HYPERBAR FXS.15
 - HYPERBAR FS.30
 - HYPERBAR FM.45
 - HYPERBAR FL.60
 - HYPERBAR FXL.75
 - Serial number(s): _____
 - Date of purchase: _____
 - Name: _____
 - Address: _____
 - e-mail: _____
 - My signature below acknowledges, that I have fully read, understand and accept this limited warranty agreement.
Date _____
 - Signature _____
-

Documents / Resources



[SKYLIGHT FS.30 Deck Mounted Fixed Step Flashing](#) [pdf] Instruction Manual
FS.30 Deck Mounted Fixed Step Flashing, FS.30, Deck Mounted Fixed Step Flashing, Fixed Step Flashing, Step Flashing, Flashing

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.