

SKYROCKET Faction Battle System App User Guide

Home » SKYROCKET » SKYROCKET Faction Battle System App User Guide 🖺

Contents

- 1 SKYROCKET Faction Battle System App
- **2 INITIAL SET-UP**
- 3 THE HAVOC GEL BEAD BLASTER
- **4 PREPARING GEL BEADS**
- **5 LOADING THE AMMO CLIP**
- **6 SMART BEACON ASSEMBLY**
- 7 PLAYING TARGET PRACTICE {WITHOUT APP}
- **8 TRDUBLESHOOTING**
- 9 CLEARING A JAM
- 10 Documents / Resources
- 11 Related Posts



SKYROCKET Faction Battle System App



SCAN FOR INSTRUCTIONS



This blaster has been disabled for safety and will not fire. It will flash yellow/red until unlocked. FOLLOW STEPS 1 THRU 3 TO UNLOCK & RE-ENABLE YOUR BLASTER

IT'S A BLAST! - WITH DR WITHOUT THE APP


Once unlocked, the Faction Havoc works like any other gel bead blaster. It will not require any further connection to a phone or app to work. Just turn it on, load it up with gel bead ammo and blast away!

Connecting with the app is highly recommended however, as it will take your blasting game experience to a whole new level. When connected to the app, certain blaster functions (such as Firing Mode selection, LED lights, and the ability to fire] may be controlled by the app during gameplay. Full control may be restored at any time by closing the app and powering your blaster on and off.



INITIAL SET-UP

1. CHARGING YOUR BLASTER



2. DOWNLOAD THE FREE FACTION BATTLE SYSTEM APP

Scan or visit FactionBattle.com to download and install the FREE Faction Battle System app. Update your phone to its most current operating system for best performance.



3. PAIR & UNLOCK YOUR BLASTER THROUGH THE APP

Ensure your phone's Bluetooth is on. Launch app, then turn blaster on to initiate pairing.

(If blaster is already on, but not flashing blue, quickly turn off then on again to re-initiate pairing). Follow in-app instructions to select Faction Havoc. Blaster will pair, automatically unlock and be ready for use. Once paired, blaster will auto-pair to your phone whenever both the app is open and blaster is turned on. Should pairing fail, turn blaster off then on again and re-attempt connection.



NOTE: Faction blasters ONLY connect through the app. Blaster will not appear in your phone's Bluetooth settings. It can only connect when app is open and running and it will automatically disconnect when app is closed. You can pair a blaster to a different phone by following the same steps. Just be sure to close app on original phone until blaster has successfully paired with new phone.

APP SUPPORTED FUNCTIONS REQUIRE PAIRING AND CELLULAR DATA.


THE HAVOC GEL BEAD BLASTER



• Pour dehydrated beads into water.




• Soak 3 hours for full hydration.



Too little water may prevent beads from fully expanding and cause jams, misfires and poor performance. If in doubt, add more water.

LOADING THE AMMO CLIP


• Scoop beads and drain water through fingers.



• Open flap at top of clip and carefully fill with beads.



• Slide ammo clip onto rail and push upward, until locked into position.




CLEAR BLASTER AND CLIP WHEN FINISHED: Uncleared beads will dry, stick, and cause jams next time you battle. After emptying ammo clip, reattach to blaster, turn blaster upside down, and fire blaster until the feed tube in the ammo clip is clear of all beads.

SMART BEACON ASSEMBLY



PLAYING TARGET PRACTICE {WITHOUT APP}

Turn beacon on. Blast the beacon when it turns BLUE, but don't blast it when the light turns off.



TRDUBLESHOOTING

- Blaster is flashing yellow and red.
 - Blaster is still locked. Download Faction app and follow instructions for one-time pairing and unlocking.
- Blaster is solid blue, but blaster does not fire.
 - Check firing mode switch to ensure the safety lock is not selected.
 - Firing ability may be suspended by app control. Close app and turn blaster off and on to regain full control.
 - Blaster may be jammed. Follow instructions for clearing a jam.
- · Blaster works fine, but app is not connecting or cannot see it.
 - If still unresponsive, turn blaster off then on again.
- · Blaster is firing slowly.
 - Ensure your phone's Bluetooth is turned on and the app has permission to use it. With the app open and running, turn blaster off the on again to restart the pairing process. If previously paired, blaster should auto-pair. Blaster power is running low. Follow instructions for charging.
- Gel beads aren't firing correctly or are rolling out of the blaster barrel.
 - Gel beads may not be fully hydrated. Allow more hydration time and add water if partially hydrated beads are floating above the water level

CLEARING A JAM

Turn power off and remove ammo clip. Shake blaster sharply 3 or 4 times to clear chamber, then fire the blaster to ensure the jam is resolved. Smack ammo clip against your hand to free any clip jam. If still jammed, spray canned air into upper chamber to loosen until jam drains down barrel. Never stick any object into barrel, upper chamber or ammo clip as it may worsen jam or cause damage.

STORING HYDRATED BEADS:

Keep ammo hydrated and ready for action for up to 1 week. Submerge in water and seal in a container with lid out of direct sunlight.

ADULT SUPERVISION REQUIRED:

or EYEWEAR careless use REQUIRED: may cause 00 NOT serious AIM injury, AT EYES especially DR FACE. to the Misuse eye. Gel Impact beads from may gel stain. beads Eye may protection cause must temporary be worn marks by on user and any Use only person clean within tap range. water to Use only hydrate gel Faction beads. brand Do gel not bead freeze ammo. or modify Faction gel gel beads. blasters. Included eyewear intended only for use with Never remove the googles while using gel bead blasters. Wear the near an goggles area where whenever gel using bead a gel blasters bead are blaster being and used. whenever Check in the or any lens

cracks before are and observed use and anywhere replace in the the lens. goggles Do not play immediately with if gel a bead crack or blasters if fracture the or lens is damage subject of any a kind direct and impact replace and the develops goggles suitable immediately. for age Clean 14+. the Not goggles for use with in low tap light water. The conditions. goggles are DO PRODUCT NOT IN BRANDISH PUBLIC IN as it PUBLIC: may cause 00 NOT confusion BRANDISH and may THIS be a crime. authorities This and product or other may be law mistaken enforcement for an agencies. actual Any firearm by of state or federal recommended product markings, appear coloration, more or realistic is dangerous alterations in and order may to be a make crime the state CHECK & federal LOCAL law LAWS: from use Criminal of a penalties replica may firearm be in a possible prohibited under or threatening the manner. local Consumers authorities should before using confirm in the public lawful spaces use of as this laws may product view.

UPGRADE YOUR ARSENAL



BLASTER

THIS PRODUCT CONTAINS A LITHIUM-ION BATTERY:

Lion batteries have a severe risk of fire and e. C. injury Do Read if not they all open, are directions crush improperly or regarding modify handled this use, or product care Do and misused. not disposal. They incinerate Read may or all heat explode, following above overheat 113'F precautions or / ignit45a nd instructions regarding the care and use of Lion batteries.

- Keep away from flammable materials. Do not expose to direct sunlight.
- Do not place in a fire or leave in hot places.
- Do not drop or make subject to strong impact.
- Keep dry and away from water.
- The supply terminals are not to be short circuited. Never throw into a fire or attempt to open outer case.
- Do not stress, press or drop.
- ID Never or charge the charging unattended. process When and charging react ID you potential should problems remain that in may constant occur. observation
- Disconnect charging cable if fully charged.
- Never temperature store or could charge ignite inside fire. a car in extreme temperatures, since extreme Use
 caution to avoid puncture. Puncture of battery may cause a fire.

Lion Battery Disposal: Lion batteries must be recycled or etc. Check disposed your of local properly. They regulations should for not be correct disposed recycling of with and/or other battery household disposal was battery disposal.

BEACON

AAA BATTERY WARNINGS & SPECIFICATIONS:

Do not use rechargeable batteries.

- Non-rechargeable batteries are not to be recharged.
- Do not mix old and new batteries and Do not mix alkaline, standard (carbon-zinc] or rechargeable (ni-cad, ni-mh, etc.] batteries.
- Batteries are to be inserted using correct polarity. Remove exhausted batteries as soon as possible and discard properly.
- Remove all batteries from compartment il beacon is not used for a long period of time. The supply terminals are not to be short circuited. Batteries should be replaced by an adult.
- Never throw batteries in a fire or attempt to open the outer casing.

WARNING: Batteries are harmful if swallowed. Please keep away from children.

Battery Disposal:

Dispose of batteries according to the local laws and regulations of your region. Some batteries may be recycled, and may be accepted for disposal at your local recycling center.

• If you are not able to identity the application rules in your areas, please check the instructions of the battery manufacturer.

This device complies with PART 15 of the FCC Rules. Operation is subject to the following two conditions.

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/ TV technician for help.

WARNING: This produces flashes that may trigger epilepsy in sensitized individuals. Google Play is a trademark of Google Inc. -Apple, the Apple logo, the iPhone and the App Store are trademarks of Apple Inc., registered in the U.S. and other countries. The App Store is a service mark of Apple inc. 02023 Skyrocket LLC, Los Angeles, CA 90292 USA. All Rights Reserved. Faction and the Skyrocket logo are trademarks of Skyrocket LLC. Other trademarks and trade names are those of their respective owners, and there is no relationship express or implied with Skyrocket LLC. MADE IN CHINA

HAVOC FCC ID: O531858724G **BEACON FCC ID:** O5318586824G

Questions or comments?

Please email skyrockettoys.com

Documents / Resources



SKYROCKET Faction Battle System App [pdf] User Guide 1858724G, O531858724G, O531858724G, 1858724G, Faction Battle System App, Faction Battle System, App

Manuals+,