



SKYVIK Fixed MagPad Wireless Charger User Manual

[Home](#) » [SKYVIK](#) » SKYVIK Fixed MagPad Wireless Charger User Manual 

Contents

- [1 OVERVIEW](#)
- [2 PRODUCT SPECIFICATIONS](#)
- [3 PART OF THE PACKAGE](#)
- [4 PRODUCT CARE AND MAINTENANCE](#)
- [5 SECURITY MEASURES](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



SKYVIK Fixed MagPad Wireless Charger



- Thank you for purchasing the FIXED MagPad wireless charger that supports MagSafe magnets.
- It is suitable for iPhones 12 and all newer models.

OVERVIEW

1. Charging surface with MagSafe magnet attachment support and up to 15 W of power.
2. Tipping stand
3. Integrated 1.2m cable with USB-C connector

Read this manual before use. Instructions for use:

1. Plug the USB-C cable of the wireless charger into a charging adapter with PD3.0 support and a minimum of 20W.
2. Now you can connect a MagSafe-enabled device to the charger's surface, and thanks to the magnets in the
3. station, it will automatically snap on and start charging.
4. If necessary, flip out the stand on the back of the charger. To prevent the stand from being jammed by the weight of the phone, the hinge of the stand must be on the top side, see Fig. Figure
5. For proper magnet attachment function, a compatible MagSafe cover must be used

PRODUCT SPECIFICATIONS

- **Input:** 5V/2A, 9V/2A, 12V/2A (PD, QC Protocol)

- **Output:** 5W, 7.5W, 10W, 15W
- **Material:** ABS- Zinc alloy
- **Dimensions:** 60x60x8 Integrated cable
- **length:** 1.2m
- **Weight:** 62g 6pcs of neodymium magnets N52 with thickness 2mm

PART OF THE PACKAGE

- **1x** Wireless charger FIXED MagPad
- **1x** User manual
- **1x** USB-C cable

NOTES:

- The product is warranted according to the legal regulations in force in the countries where it is sold. In case of service problems, please contact the dealer from whom you purchased the equipment.
- FIXED assumes no responsibility for damages caused by improper use of the product.

PRODUCT CARE AND MAINTENANCE

Use a soft cloth to clean the body of the wireless charger.


SECURITY MEASURES

- Do not expose the device to rain or snow or immerse it in water.
- Do not leave the wireless charger in the car in the sun.
- Do not expose the device directly to sunlight or leave it near heat sources.
- Do not use the wireless charger if it has been heavily impacted, dropped, or damaged in any way.
- Do not disassemble the device, there is a risk of electric shock and/or burns. Do not modify the power cord.
- Keep the wireless charger out of the reach of children. Unauthorized opening or modification of product parts will result in forfeiture of warranty.
- **Product storage temperature:** 0 to 35 °C
- **Product operating temperature:** 0 to 40 °C

PRODUCT DISPOSAL

- (Applies in countries with separate collection systems for recyclable materials).
- Old products must not be disposed of with household waste! If the product no longer works, dispose of it in accordance with the applicable regulations in your country.
- This ensures that old products are recycled in a professional manner and also eliminates negative environmental consequences. For this reason, electrical equipment is marked with the symbol shown here.
- This product is CE marked in accordance with EMC Directive 2014/30/EU and RoHS Directive 2011/65/EU. FIXED.zone a.s.
- hereby declares that this product complies with the essential requirements and other relevant provisions of the

Documents / Resources

	SKYVIK Fixed MagPad Wireless Charger [pdf] User Manual Fixed MagPad Wireless Charger, Fixed, MagPad Wireless Charger, Wireless Charger, Charger
---	--