



SKYWIN iTalk PRO Conference Speaker with Microphone User Guide

[Home](#) » [SKYWIN](#) » SKYWIN iTalk PRO Conference Speaker with Microphone User Guide 

SKYWIN iTalk PRO Conference Speaker with Microphone User Guide



Contents

- [1 Specifications:](#)
- [2 Questions?](#)
- [3 iTalk PRO Quick Start Guide](#)
- [4 Charging](#)
- [5 Connect to Bluetooth](#)
- [6 Connect to USB](#)
- [7 Keypad Layout](#)
- [8 FCC Caution](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)


Specifications:

- Bluetooth version: V5.0
- USB version: USB 2.0 Plug and Play
- Charging: 2 Hours by 5V/1A by USB-C
- Battery: 2000mAH@3.7V
- Work Time: 8 Hours phone call/conference, 5 Hours music play
- Speaker: 2x3W
- Microphone Sensitivity: -36dB
- Microphone Pickup Range: 5 meters
- Speaker Frequency Range: 120Hz-20KHz


Questions?

Please contact us by email: christina@golds-in.com. 7/24, 365days work for you

iTalk PRO Quick Start Guide



Charging



Before start to use, please full charge the unit. Use Type-C cable to charge it. Charge current 5V/1A, charge time 2 hours.

Connect to Bluetooth

Turn On/Off the unit:

Press  2 seconds to turn on the unit, the unit will search last connected equipment to connect. After use, press  4 seconds turn off the unit.

Pairing:

When the unit is on, Press the Bluetooth button once  to enter pairing mode, the  and  light red/blue flash, turn your mobile or laptop Bluetooth on and find “iTalk PRO” to connect. At any time, press the Bluetooth button once , it will enter pairing mode, you can use it to pair new device or 2nd device.

Make a call/Conference:

Use your mobile to dial or laptop to make a call /conference, use “+” “-” button to up/down the volume. Use  button to mute the microphone. Use  in the center to answer and end telephone calls by mobile (only for telephone calls, not activated for other apps like TEAMS, Skype, Wechat etc.).

Play Music:

Use    buttons to control music play.

Connect to USB


Turn On/Off the unit:

measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources

	<p>SKYWIN iTalk PRO Conference Speaker with Microphone [pdf] User Guide iTalk PRO, iTalk PRO Conference Speaker with Microphone, Conference Speaker with Microphone, Speaker with Microphone, Microphone</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.