



SM Tek Group SB22 Funbox Portable Speaker with Microphone User Manual

[Home](#) » [SM Tek Group](#) » SM Tek Group SB22 Funbox Portable Speaker with Microphone User Manual 

Contents

- [1 SM Tek Group SB22 Funbox Portable Speaker with Microphone](#)
- [2 INTRODUCTION](#)
- [3 PACKAGE CONTENTS](#)
- [4 PRODUCT OVERVIEW](#)
- [5 SPECIFICATIONS & FEATURES](#)
- [6 HOW TO USE](#)
- [7 CARE AND SAFETY](#)
- [8 BATTERY DISPOSAL:](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)



SM Tek Group SB22 Funbox Portable Speaker with Microphone




INTRODUCTION

This portable speaker is the best for any on the go adventure. It is extremely lightweight for moving and grooving. Its so small you'll forget the power that can come out of it. With a 4 inch Woofer, this bad boy has a pOwer of S00 watts. It can go up to 33 feet away from you in case you need to step away. The best part about this speaker? It has a microphone! For on the go karaoke! Just pull up a video on your phone with the lyrics and get to Singing with your friends!

PACKAGE CONTENTS

- 1x Speaker
- 1x Microphone
- 1x Charging Cable

PRODUCT OVERVIEW



2

1. Mode
2. Previous/Volume Down
3. Play/Pause (Short press for play and pause)/Scan
4. Next/Volume Up
5. LED Indicator
6. USB Slot
7. TF/Micro SD Card
8. Charging Port
9. AUX-In Slot
10. Power ON/OFF Switch,,

SPECIFICATIONS & FEATURES

- Speaker is approx 9 in x 6 in x 3.5 in
- Bluetooth: v5.3
- Woofer Size: 4"
- Woofer Output: 500W
- Range: 33ft
- Battery:1200mAh
- Playing time: Up to 5 hours
- Charge Time: 3 hours
- True Wireless Capabilities
- FM Radio
- Inputs: AUX/ USB / MicroSD
- Karaoke Mic

HOW TO USE

Using MicroSD (TF) Card Slot – Max Capacity is 16GB

1. Insert the Micro SD (TF) Card or USB Drive preloaded with songs.
2. Speaker will automatically start playing songs
3. During playback, short press the Previous button to go back to the previous track, press the Next button to skip to the next track.

Using Bluetooth

1. Power on the product to enter into BT mode.
2. Search for and select “Funbox” on your external Bluetooth device.
3. The speaker will issue an indication tone after successful connection.

Using Radio

1. Press the mode button and choose FM mode.
2. Short press Play/Pause button to begin scanning for all available stations.
3. Short press it again to stop searching.
4. Press Next button to select the next stations.

Using AUX

1. Power on the unit, and cycle through Modes to the AUX IN selection.
2. Plug your AUX Cable in the AUX IN Port and use device to select/play music.

Using Karaoke

1. Insert the plug of the Microphone into the unit's MIC jack.

CARE AND SAFETY

- Do not use this unit for anything other than its intended use.
- Keep the unit away from heat source, direct sunlight, humidity, water or any other liquid.
- Do not expose the device to extremely high or low temperatures, as it may damage the battery.
- Do not operate the unit if it has been wet or moist to prevent against electric shock and/or injury to yourself and damage to the unit
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Keep the unit out of reach of children.
- This unit is not a toy.

BATTERY DISPOSAL:

This product contains a lithium polymer battery. Lithium polymer batteries are environmentally safe when fully discharged. Please refer to your local and state laws for battery disposal procedures.


OSM TEK GROUP INC, All rights reserved.

Bluestone is a trademark of SM TEK GROUP INC.

New York, NY 10001

www.smtekgroup.com

Documents / Resources



INTRODUCTION

This portable speaker is designed to be used as a portable music player. It is designed to be used in a variety of settings, including outdoor events, parties, and gatherings. The speaker is designed to be used in a variety of settings, including outdoor events, parties, and gatherings. The speaker is designed to be used in a variety of settings, including outdoor events, parties, and gatherings.

PACKAGE CONTENTS

- 1 x SB22 Funbox Portable Speaker with Microphone
- 1 x User Manual

PRODUCT OVERVIEW

The SB22 Funbox Portable Speaker with Microphone is a portable music player. It is designed to be used in a variety of settings, including outdoor events, parties, and gatherings. The speaker is designed to be used in a variety of settings, including outdoor events, parties, and gatherings.

SPECIFICATIONS & FEATURES

- Speaker: 4 x 4" (100mm) x 4" (100mm) x 4" (100mm)
- Power: 40W (2 x 20W)
- Frequency: 20Hz - 20kHz
- Impedance: 16Ω
- Input: 3.5mm (1/8")
- Output: 3.5mm (1/8")
- Weight: 1.5kg (3.3lb)
- Dimensions: 150mm (6") x 150mm (6") x 150mm (6")

HOW TO USE

Setup:

1. Connect the power cable to the power source.
2. Connect the audio cable to the audio source.
3. Turn on the power switch.

Usage:

1. Press the play button to start the music.
2. Press the stop button to stop the music.
3. Press the volume up/down buttons to adjust the volume.

CARE AND SAFETY

Do not use the speaker in a wet or damp environment. Do not use the speaker in a hot or cold environment. Do not use the speaker in a dusty or sandy environment. Do not use the speaker in a corrosive environment. Do not use the speaker in a flammable environment. Do not use the speaker in a hazardous environment. Do not use the speaker in a restricted area. Do not use the speaker in a restricted area. Do not use the speaker in a restricted area.

SM Tek Group SB22 Funbox Portable Speaker with Microphone [pdf] User Manual

SB22 Funbox Portable Speaker with Microphone, SB22, Funbox Portable Speaker with Microp hone