



SM Tek Group SB24 Beatbox Personal Portable Dual Speaker User Manual

[Home](#) » [SM Tek Group](#) » SM Tek Group SB24 Beatbox Personal Portable Dual Speaker User Manual 

Contents

- 1 SM Tek Group SB24 Beatbox Personal Portable Dual Speaker
- 2 INTRODUCTION
- 3 PACKAGE CONTENTS
- 4 PRODUCT OVERVIEW
- 5 SPECIFICATIONS & FEATURES
- 6 HOW TO USE
- 7 CARE AND SAFETY
- 8 BATTERY DISPOSAL:
- 9 Documents / Resources
- 10 Related Posts



SM Tek Group SB24 Beatbox Personal Portable Dual Speaker




INTRODUCTION

A speaker for on the go! Say no more! This speaker has some serious power that you wouldn't expect from a speaker of this size. It has a tweeter located on the front that allows for different sound frequencies that not all other speakers can achieve. This speaker is extremely compact for its amount of power. It has a beautiful front design that makes it pleasing to look at. Never just play your music out loud from your phone anymore, play it with style and distinction.

PACKAGE CONTENTS

- 1x Speaker
- 1x Charging Cable

PRODUCT OVERVIEW



1. Power ON/OFF Switch
2. AUX-In Slot
3. Mode
4. Previous/Volume Down
5. Play/Pause (Short press for play and pause)/Scan
6. TF/Micro SD Card
7. Next/Volume Up
8. LED Indicator
9. Charging Port
10. USB Slot

SPECIFICATIONS & FEATURES

- Speaker is approx 11.5 in x 5 in x 5 in
- Bluetooth: v5.3
- .Woofer Size: 2 x 4"
- Woofer Output: 1000W
- Range: 33ft
- Battery: 1200mAh
- Playing time: Up to 5 hours
- Charge Time: 2 hours
- True Wireless Capabilities
- FM Radio
- Inputs: AUX / USB/ MicroSD

HOW TO USE

Using MicroSD (TF) Card Slot – Max Capacity is 16GB

1. Insert the Micro SD (TF) Card or USB Drive preloaded with songs.
2. Speaker will automatically start playing songs
3. During playback, short press the Previous button to go back to the previous track, press the Next button to skip to the next track.

Using Bluetooth

1. Power on the product to enter into BT mode.
2. Search for and select “BeatBox” on your external Bluetooth device.
3. The speaker will issue an indication tone after successful connection.

Using Radio

1. Press the mode button and choose FM mode.
2. Short press Play/Pause button to begin scanning for all available stations.
3. Short press it again to stop searching.
4. Press Next button to select the next stations.

Using AUX

1. Power on the unit, and cycle through Modes to the AUX IN selection.
2. Plug your AUX Cable in the AUX IN Port and use device to select/play music.

CARE AND SAFETY

- Do not use this unit for anything other than its intended use.
- Keep the unit away from heat source, direct sunlight, humidity, water or any other liquid.
- Do not expose the device to extremely high or low temperatures, as it may damage the battery.
- Do not operate the unit if it has been wet or moist to prevent against electric shock and/or injury to yourself and damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Keep the unit out of reach of children.
- This unit is not a toy.

BATTERY DISPOSAL:

This product contains a lithium polymer battery. Lithium polymer batteries are environmentally safe when fully discharged. Please refer to your local and state laws for battery disposal procedures

OSM TEK GROUP INC, All rights reserved.
Bluestone is a trademark of SM TEK GROUP INC
New York, NY 10001
www.smtekgroup.com

Documents / Resources

