



## SMARTIFY Nintendo Switch Controller User Manual

[Home](#) » [SMARTIFY](#) » SMARTIFY Nintendo Switch Controller User Manual



### User manual for SMARTIFY Nintendo Switch Controller

1. Direction Pad (D-pad)
2. Action Buttons
3. Left Analog Stick (L2)
4. Right Analog Stick (R2)
5. HOME Button(Power on/off)
6. LED Indicator 1,2,3,4,
7. Turbo Button
8. Capture
9. Menu selection –
10. Menu selection +
11. Left triggers
12. Right triggers



## Contents [ [hide](#)

- [1 Functions of the controller](#)
- [2 Turbo function and connecting](#)
- [3 LED function indicators](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

## Functions of the controller

1. Compatible with Nintendo Switch, Windows, Android, and Nintendo Switch Lite
2. Two double shock motors for optimal vibration function
3. Turbo function, screen capture function and home function
4. Comes with 0.7m USB charging cable
5. Two high quality analogue sticks, without deadzone
6. Wireless controller firmware 2.1 EDR
7. Built-in 550 mAh Li-ion battery, supports up to 10 hours of play time.
8. With Sensor, no NFC, and no wake-up function



## Turbo function and connecting

Turbo function

- 1) Press a button of choice and press the Turbo button respectively.
- 2) For example: hold button A pressed and press the Turbo button. Button A will keep going as if it is continuously pressed. Button A is now being spammed without the user actually pressing it.

### How do I connect the controller?


1. Place the Switch in the Switch station. Connect the Smartify controller using the USB cable to the Switch Station.
2. Press the H button on the Smartify controller.
3. Go to system settings and go to controllers and sensors. Next press disconnect all controllers.
4. Wait until the controller is paired.
5. Disconnect USB from Smartify controller.
6. The controller is now connected.

**Attention: a reset button is located on the bottom of the controller. Use a needle to press the button. Use this button when the controller is unable to connect.**

### LED function indicators

1. The LED light indicates the following meaning:
  - 1) The first led light indicates that he or she is player 1.
  - 2) The second led light indicates that he or she is player 2.
  - 3) The third led light indicates that he or she is player 3.
  - 4) The fourth led light indicates that he or she is player 4.
2. Charging led indicator:
  - 1) 4 LED light that blink slowly indicate that the controller is empty, and needs to be charged.
  - 1) 4 LED lights that blink slowly indicate the controller is charging correctly.

### Documents / Resources

	<a href="#">SMARTIFY Nintendo Switch Controller</a> [pdf] User Manual Nintendo Switch Controller
---	---