




smartwares CIP-37350 Privacy Camera Instruction Manual

[Home](#) » [smartwares](#) » smartwares CIP-37350 Privacy Camera Instruction Manual 

Contents

- 1 [smartwares CIP-37350 Privacy Camera](#)
- 2 [BOX CONTENT](#)
- 3 [PARTS DESCRIPTION](#)
- 4 [BEFORE THE FIRST USE](#)
- 5 [INSTALLATION](#)
 - 5.1 [PRIVACY MODE](#)
- 6 [TROUBLESHOOTING](#)
 - 6.1 [Camera LED indicator information](#)
- 7 [MORE INFORMATION](#)
- 8 [SPECIFICATION](#)
 - 8.1 [Information for power adapter](#)
- 9 [CONTACTS](#)
 - 9.1 [EU address](#)
 - 9.2 [UK address](#)
- 10 [Documents / Resources](#)
 - 10.1 [References](#)
- 11 [Related Posts](#)



smartwares CIP-37350 Privacy Camera



BOX CONTENT

- Camera
- USB cable
- USB power adapter
- Instruction manual
- Window sticker

PARTS DESCRIPTION

1. Camera lens
2. Day-night sensor
3. Microphone
4. Indication LED
5. Speaker + SD-card slot
6. USB cable
7. USB power adapter
8. USB port
9. Reset button

BEFORE THE FIRST USE

Follow the instructions below to quickly get started with your camera. For more instructions and info please visit our website, www.smartwares.eu. Please search for "CIP-37350".

Inserting a MicroSD card (not included)

- First make sure your camera is not connected to the power adapter.
- Insert your Micro-SD card all the way in the MicroSD card slot on the camera. Only use a class 10 MicroSD card (max 256GB).
- A MicroSD card is required for recording footage.

Download the app

- Download the HomeWizard cameras app from the Appstore or Google Playstore.

INSTALLATION

- Plug one side of the USB cable into the camera and the other side into the power adapter.
- Place the power adapter in a wall socket.
- The camera will now start booting. This will take about 1 minute. Wait until the indication LED flashes red/white.
- Open the HomeWizard cameras app.
- Follow the instructions in the app to configure the camera.

NOTE: Only 2,4 GHz Wi-Fi network is supported.

PRIVACY MODE

- Privacy mode (Image 1) will give you a peace of mind when you are at home, as you don't have to worry about your privacy. The camera will close and disable viewing, recording and microphone functions. Schedule
- Define times when you want the camera to be in privacy mode. You can add multiple times for different days to suit your needs. For example, you can close the camera during the day and open it at night.
- You can create schedules in the HomeWizard cameras app menu.

TROUBLESHOOTING

In-app

- Check the in-app help function to for more details and information.

Reset

- If needed, you can reset your camera by pressing and holding the reset button for at least 6 seconds.

NOTE: If the camera is in privacy mode, the reset button will be covered. You need to switch the camera off and on again. During the reboot, the reset button will be uncovered for about 30 seconds.

Camera LED indicator information

- **Solid white:** Normal operation
- **Solid red:** No internet connection
- **Flashing red/white:** pairing mode
- **Flashing white:** booting

MORE INFORMATION

For more instructions and information, please visit one of our websites, www.smartwares.eu or camera.homewizard.net. Please search for “CIP-37350”.

SPECIFICATION

- **Wireless technology:** Wi-Fi
- **Operating frequency:** 2,4 GHz
- **Max. radio-frequency power:** 19.79 dBm

Information for power adapter



- **Model:** XH005W050100EUCU
- **Input:** 100-240V 50/60Hz
- **Output:** 5.0V 1A

Only use the supplied power adapter

Requirements

- iOS 11 or higher
- Android 5.1 or higher

CONTACTS

EU address

smartwares Europe





- Jules Verneweg 87 5015 BH Tilburg The Netherlands
- www.smartwares.eu

UK address

smartwares Safety and Lighting Ltd.

- Meriden House, 6 Great Cornbow Halesowen, West Midlands, B63 3AB United Kingdom

Documents / Resources

	smartwares CIP-37350 Privacy Camera [pdf] Instruction Manual CIP-37350, Privacy Camera, CIP-37350 Privacy Camera, Camera
	Smartwares CIP-37350 Privacy Camera [pdf] Instruction Manual CIP-37350 Privacy Camera, CIP-37350, Privacy Camera, Camera
	smartwares CIP-37350 Privacy Camera [pdf] Instruction Manual CIP-37350 Privacy Camera, CIP-37350, Privacy Camera, Camera
	smartwares CIP-37350 Privacy Camera [pdf] Instruction Manual CIP-37350 Privacy Camera, CIP-37350, Privacy Camera, Camera

References

-  [Smartwares - Alles voor een veilig en een comfortabel huis!](#)