

smeg FMI320X2 Built In Microwave Instruction Manual

Home » Smeg » smeg FMI320X2 Built In Microwave Instruction Manual



Contents

- 1 smeg FMI320X2 Built In
- **Microwave**
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 FAQ
- **5 Programs / Functions**
- **6 Controls**
- 7 Options
- **8 Technical Features**
- 9 Accessories Included
- **10 Electrical Connection**
- 11 PRODUCT DIMENSION
- 12 Symbols glossary
- 13 Documents / Resources
 - 13.1 References



smeg FMI320X2 Built In Microwave



Product Information

Specifications:

Usable volume: 20 I

• Product Family Category: Microwave

· Installation: Built-in With frame

• Power supply: Electric

· Cooking Method: Microwave with grill

Control: ElectronicDisplay / Clock: TFT

• Type of control setting: Touch control

• Timer: Electronic

Time-setting options: End cookingEnd of cooking acoustic alarm: Yes

• No. of functions: 5

· Full grill: Yes

Defrost by time: YesDefrost by weight: Yes

· Microwave: Yes

• Microwave + grill: Yes

· Automatic programmes: Yes

 Other Microwave functions: 3 Memory, Showroom demo option, Controls Lock / Child Safety, Quick start option, Limited Power Consumption Mode

Technical Features:

· Cavity material: Stainless steel

Shelf positions: 2Shelves type: Rack

• No. of lights: 1

· Light type: Incandescent

Light power: 20 W

• Turntable: Yes

Turntable dimensions: 24.5 cmLight when door is opened: Yes

· Grill type: Quartz

• Grill - power: 1000 W

· Door opening: Side-opening

• Total no. of door glasses: 2

• Cooling system: Tangential

• Microwave screen protection: Yes

· Microwave stops when door is opened: Yes

• Usable cavity space dimensions (HxWxD): 210x305x280 mm

Microwave effective power: 850 W

• Frame: Yes

• Frequency (Hz): 50 Hz

• Power supply cable length: 150 cm

Accessories Included:

• Grid: 1

Product Usage Instructions

Using the Microwave:

- 1. Open the door of the microwave.
- 2. Place the food or container on the turntable or rack inside the microwave.
- 3. Close the door securely.
- 4. Set the desired cooking time using the touch control setting.
- 5. Press the Start button to start the microwave cooking process.
- 6. The microwave will automatically stop when the cooking time is finished. Open the door and remove the food or container carefully.

Using the Grill:

- 1. Open the door of the microwave.
- 2. Place the food on the rack inside the microwave.
- 3. Close the door securely.
- 4. Set the desired cooking time using the touch control setting.
- 5. Press the Grill button to activate the grill function.
- 6. Press the Start button to start the grill cooking process.
- 7. The grill will automatically stop when the cooking time is finished. Open the door and remove the food carefully.

Using Microwave + Grill:

- 1. Open the door of the microwave.
- 2. Place the food on the rack inside the microwave.
- 3. Close the door securely.
- 4. Set the desired cooking time using the touch control setting.
- 5. Press the Microwave + Grill button to activate the microwave and grill functions.
- 6. Press the Start button to start the cooking process.
- 7. The microwave and grill will automatically stop when the cooking time is finished. Open the door and remove the food carefully.

FAQ

What is the capacity of this microwave?

The usable volume of this microwave is 20 liters.

Can I defrost food by weight?

Yes, you can defrost food by weight with this microwave. Set the weight of the food using the touch control setting, and themicrowave will automatically determine the defrosting time.

Is there a child lock feature?

Yes, this microwave has a child lock feature. It allows you to lock the programme/cycle so it cannot be accidentally changed.

What is the power consumption of this microwave?

The nominal power of this microwave is 1300 W. Please refer to the user manual for detailed information on power consumption in different modes.

Can I use the microwave and grill functions together?

Yes, this microwave allows you to use the microwave and grill functions together. Press the Microwave + Grill button to activate both functions.

FMI320X2

Usable volume 201

Product Family Microwave
Category Built-in

Installation With frame

Power supply Electric

Cooking Method Microwave with grill

Control Electronic

Programs / Functions

No. of functions

Full grill

Defrost by time

Defrost by weight

Microwave

Microwave + grill

Automatic programmes

Other Microwave functions









3

Memory

Controls

Electrical button Display / Clock **Opening TFT**

Type of control setting Touch control

Options



Electronic Showroom demo option Yes

Controls Lock / Child Time-setting options End cooking Yes

Safety End of cooking acoustic

alarm Quick start option Yes

Technical Features





Cavity material Stainless steel Grill type Quartz Shelf positions Grill - power 1000 W Shelves type Rack Door opening Side-opening

No. of lights Total no. of door glasses 2

Light type Incandescent Cooling system **Tangential** Yes

20 W Light power Microwave screen protection Turntable Yes

Microwave stops when Yes **Turntable dimensions** 24.5 cm

door is opened Light when door is Yes

opened

210x305x280 mm Usable cavity space dimensions (HxWxD)

Microwave effective 850 W

power


Accessories Included

Grid 1 Frame Yes Nominal power (W) 1300 W Current 5,2 A Voltage (V) 230 V

Frequency (Hz)
Power supply cable length

50 Hz 150 cm

PRODUCT DIMENSION



Symbols glossary

• Child lock: some models are fitted with a device to lock the programme/cycle so it cannot be accidentally changed.


• Defrost by time: with this function the time of thawing of foods are determined automatically.

Double glazed doors: Number of glazed doors.

• Microwave: Penetrating straight into the food, microwaves cook very quickly and with considerable energy savings. Suitable for cooking without fat, they are also able to thaw and heat food without altering its original appearance and aroma. The microwave function can also be combined with conventional functions with all the resulting advantages. Ideal for all types of food.

The oven cavity has 2 different cooking levels

• The capacity indicates the amount of usable space in the oven cavity in litres.



Defrost by weight: With this function the defrosting time is determined

• Grill element: Using of grill gives excellent results when cooking meat of medium and small portions, especially when combined with a rotisserie (where possible). Also ideal for cooking sausages and bacon.

• Microwave + grill element: The use of the grill results in a perfect browning of the surface of the food.

The action of microwaves allows instead of cooking in a short time the internal part of the food.

• Touch controls: Easy to use touch controls allow the appliance to be programmed at the touch of a button.

Documents / Resources



smeg FMI320X2 Built In Microwave [pdf] Instruction Manual
FMI320X2 Built In Microwave, FMI320X2, Built In Microwave, In Microwave, Microwave

References

User Manual

Manuals+, Privacy Policy