



SOAR BOOST Smart True Wireless Earbuds User Manual

[Home](#) » [Soar](#) » SOAR BOOST Smart True Wireless Earbuds User Manual 

SOAR[®]

SR-SEBTA – BOOST Sport Earbuds Acrylic Box
User Manual – Black and White Printing



Wireless Earphone

FIL INTELLIGENTS USER MANUAL

Contents


- 1 BOOST Smart True Wireless Earbuds
- 2 PRODUCT KEY
- 3 SPECIFICATIONS
- 4 ON/OFF – MISE EN MARCHÉ
- 5 PAIRING
- 6 CHARGING
- 7 TELEPHONE FUNCTION
- 8 MUSIC OPERATION
- 9 WARRANTY
- 10 Documents / Resources
- 11 Related Posts

BOOST Smart True Wireless Earbuds

Thank you for choosing the SGAR BOOST Smart True Wireless Earbuds. High quality audio for an active lifestyle. Please familiarize yourself with the Bluetooth functionality of your smartphone or device before use.

Contents : True Wireless Earbuds, Charging Case, USB-C Charging Cable, Extra Ear Gels, User Manual

PRODUCT KEY



- | | |
|------------------------|-------------------------|
| 1. USB-C Input | 5. Multifunction Button |
| 2. Charging Case | 6. Ear Gels |
| 3. Ear Hook | 7. Microphone |
| 4. LED Indicator Light | |

SPECIFICATIONS

Earbuds Ecouteurs :

Battery – 30mAh

Driver – 8mm

Charging Time -1.5 Hours

Playtime – Up to 4 Hours
Charging Case :
Battery – 300mAh
Charging Time – 2 Hours



ON/OFF – MISE EN MARCHÉ

The earbuds will automatically enter pairing mode when removed from the charging case. If they have been previously paired with a device that's Bluetooth® functionality is on they will automatically connect. When placed back into the case they will automatically begin to charge. To manually turn the earbuds on or off press and hold the multifunction button (5) for 4 seconds.



PAIRING

To pair your earbuds to a device, remove them from the case, They should automatically enter pairing mode. This is shown by the LED indicator lights (4) blinking red and blue. If they do not press and hold the multifunction button (5) for 3 seconds. The buds will pair to each other automatically.

When this happens only one earbud will blink red and blue. Select “Boost TWS” from your devices Bluetooth” menu. Once successfully paired both earbuds will slowly flash blue. The next time you remove the buds from their case they will automatically connect to this device.



CHARGING

To charge the earbuds place them in the corresponding slots within the charging case. When properly inserted the earbuds will automatically begin charging. While charging the LED indicator lights (4) will be red, and the indicator light on the case will be blue. Once fully charged both lights will turn off. To charge the case use the provided charging cable. Plug the USB-C end into the corresponding input on the back of the case (1). Plug the USB end into a SY wall outlet or suitable USB port. When charging the indicator light on the case will flash red. The light will stop flashing when completely charged.



TELEPHONE FUNCTION

To answer an incoming call tap the multifunction button (5) on either earbud. To reject an incoming call press and hold the multifunction button (5) for 1.5 seconds. To call back the last call made double click the multifunction button (5). Single click the multifunction button (5) during a call to hang up.



MUSIC OPERATION

Press the multifunction button (5) on either earbuds to pause the music. Press again to resume. To skip a track press and hold the multifunction button (5) for 1.5 seconds.



WARNING

Adjust the volume carefully when using the earbuds to prevent hearing damage. Please avoid listening at a volume that prevents you from hearing what is around you.

Put this product and its accessories somewhere out of reach of children. The small parts may be a choking hazard.

Prevent water from entering the case or earbuds. This may cause damage and degrade the sound quality of the earbuds.

Stop using the earbuds if you feel obvious discomfort, irritation or have any other adverse reactions.

The earbuds should not be stored or used at temperatures below 0° C (32 F) or above 45° C (113 F) as this may

shorten the battery life.

WARRANTY

This product has a 1 year warranty against defects in manufacturing under regular consumer use, For instructions about how to obtain warranty service for your product, please contact Customer Service: info@primebrandsgroup.com.



<https://a.smart321.com/pbgssh>

To access your earbuds smart app features download the app using the QR code to the left, or search "SOAR smart" on the google play /iOS app store. Follow the simple on screen instructions to link your buds. Access extensive EQ adjustments, device settings, and GPS lost bud locator.



SMART APP
APPLICATION



©2022 Prime Brands Group. All rights reserved.

All trade names are registered trademarks of the respective manufactures listed.

Made in China.

©2022 Prime Brands Group.

Prime Brands Group • Brooklyn, NY 11232 • [SHOPSOAR.COM](https://shopsoar.com)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction



Documents / Resources

	<p>SOAR BOOST Smart True Wireless Earbuds [pdf] User Manual 2A5ZM-SRSEBTABLK, 2A5ZMSRSEBTABLK, srsebtablk, BOOST Smart True Wireless Earbud s, BOOST, Smart True Wireless Earbuds, BOOST Smart, True Wireless Earbuds, Wireless Ear buds, Earbuds</p>
---	---