

# **SOAR SR-WCST Wireless Charging Tray User Manual**

Home » Soar » SOAR SR-WCST Wireless Charging Tray User Manual 🖫





#### **Contents**


- 1 Power On
- 2 Charging
- **3 TROUBLESHOOTING**
- **4 SPECIFICATIONS**
- **5 WARRANTY**
- **6 Product Key**
- 7 Documents /
- Resources
- **8 Related Posts**

## **Power On**



To power on the wireless charging tray use the included USB-C cable. Plug the USB-C end into the USB-( power input port on the side of your wireless charging tray, Plug the USB end into a suitable 5V wall charger or port. When the product is on the LED indicator light will light up red.

# Charging



Once your wireless charging tray is plugged in and the LED indicator light is activated, simply place your smartphone or device onto the wireless charging area.

# **TROUBLESHOOTING**

If your device won't charge, please try removing your phone case. While our wireless charger is case friendly, a very thick case (above .25" thick,) can disrupt charging transmission. Additionally, if you have any mounting magnets on your phone, that may also disrupt an effective charge.

#### **SPECIFICATIONS**

Input: 5V/2A - 9V/2A

Output: 5V/IA 9V1.1A 9V1.67A Transmission Distance: ≤6MM

Wireless Charger Output: 15W/10W/7.5W/5W

**USB-C Charging Cable: 3.28FT** 

#### Warning


This device is not a toy and should be kept away from children. The product must not he dropped or subjected to impact. Do not use the device in humid environments or in extremely hot / cold temperatures. Do not use chemicals or abrasive detergents to clean the product. Please return for repairs if the product is defective. The warranty is invalid if the product has metal rust, water damage, or other natural oxidation.

#### WARRANTY

This product has a 1 year warranty against defects in manufacturing under regular consumer use. For instructions about how to obtain warranty service for your product, please contact Customer <a href="mailto:Service:info@primebrandsgroup.com">Service:info@primebrandsgroup.com</a>.

Supports all wireless charging and 0i enabled devices. sans filet compatibles 01. Comprenant: iPhone 14/14 Plus/14 Pro/14 Pro Max/iPhone 13/13 mini/13 Pro/13 Pro Max/iPhone 12/12 mini/12 Pro/12 Pro Max/11/11 Pro/11 Pro Max/XS MAX/XR/XS/X 1818 Plus/SE2; Samsung Galaxy S20/520+/S10/S10+/S10E/S9Galaxy Note 20/20+110/10+/S9/S9+/S8/S8+; Google Pixel 4/4XL/3/3XL, Google Nexus 7; LG 67/6/6 plus/S6/S6 Edge/S6 Edge Plus/Moto Droid Turbo, Nexus 5/1/4, Nokia Lumia 1020/920/928 Droid Mini

# **Product Key**



- 1. USB-C Input
- 2. LED Indicator Light
- 3. Wireless Charging Area
- 4. Snap Buttons
- 5. USB-C Cable

To assemble your tray simply connect the snap buttons at all 4 corners. Pull apart to release and flatten.

## **FCC Warning**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# FCC RF exposure statement:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body

#### **Documents / Resources**



SOAR SR-WCST Wireless Charging Tray [pdf] User Manual SR-WCST Wireless Charging Tray, SR-WCST, Wireless Charging Tray, Tray

Manuals+