Manuals+ — User Manuals Simplified.

Software s Upgrade Software Instruction Manual

**Upgrade software
operating instructions**

Contents

Upgrade Software

Updater download address **https://stogagame.com/downloads/**

1. Download the program upgrade package and unzip it to the current folder
2. Open the program upgrade folder Open the upgrade program

3. Click "OPEN" of the upgrade program to load the program

Firmware File :   OPEN
Firmware Checksum :
Firmware Product Name:
Firmware Model :
Firmware Parameter :
Firmware Version :

Device Product Name :
Device Model :
Device Parameter :
Device Version :
Device Status : OFFLINE

                                                    0%

                    DOWNLOAD

名称   修改日期   类型   大小
swtich_2019_12_13_L.jocn   2019年12月13日 星期... JOCN 文件   318 KB
swtich_2019_12_13_R.jocn   2019年12月13日 星期... JOCN 文件   318 KB

(N):   ∨   All supported file(*jocn) ∨
   打开(O)   取消

4. Long press the 3D button on the handle for about 5 seconds. The lights NO.1 and NO.3 on the handle are always on (don't let go) and the lights go out after about 3 seconds, and the handle enters the upgrade state.

5. Use the USB cable to connect the computer and the handle, the OFFLINE on the upgrade program becomes ONLINE

Firmware File   : E:/Send_sv   Firmware File   : E:/Send_swtich
Firmware Checksum : B316-77B9C   Firmware Checksum : B316-77B9CE18
Device Status   : OFFLINE   Device Status   : ONLINE

6. Click DOWNLOAD to upgrade the software to upgrade the program

7. After the upgrade is completed, the handle is disconnected from the upgrade software and the 4 LED lights on the controller flash

Documents / Resources

	Software s Upgrade Software [pdf] Instruction Manual Upgrade Software

References

- ▼ **Downloads - StogaGame**