

SOGO
SS-5185 Citrus
Juice Extractor
Press Handle



Sogo SS-5185 Citrus Juice Extractor Press Handle User Manual

[Home](#) » [SOGO](#) » Sogo SS-5185 Citrus Juice Extractor Press Handle User Manual 

Contents

- [1 Sogo SS-5185 Citrus Juice Extractor Press Handle User Manual](#)
- [2 DESCRIPTION](#)
- [3 TECHNICAL INFORMATION](#)
- [4 CLEANING](#)
- [5 DECLARATION OF CONFORMITY](#)
- [6 References](#)

SOGO

Sogo SS-5185 Citrus Juice Extractor Press Handle User Manual



Caution: Please read and preserve these important instructions.

SAFETY ADVICE AND CAUTIONS

- This instruction manual can also be downloaded from our website, www.sgo.es
- Read these instructions carefully before switching on the appliance and keep them for future reference.
- Failure to follow and observe these instructions could lead to an accident.
- Clean all the parts of the product that will be in contact with food, as indicated in the cleaning section, before use.
- Do not use the appliance if the cable or plug is damaged.
- Ensure that the voltage indicated on the nameplate matches the mains voltage before plugging in the appliance.
- The appliance's plug must fit into the mains socket properly. Do not alter the plug. Do not use a plug adaptor.
- Do not use or store the appliance outdoors.
- Do not use the appliance if it has fallen on the floor, if there are visible signs of damage or if it has a leak.
- Do not force the electrical connection wire. Never use the electric wire to lift, carry, or unplug the appliance.
- Ensure that the electric cable does not get trapped or tangled.
- Check the state of the electric cable. Damaged or knotted cables increase the risk of electric shock.
- Do not touch the plug with wet hands.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or a lack of experience and knowledge. Unless they have been given supervision or
- Instructions concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified

persons to avoid a hazard.

- Fully unroll the appliance's power cable before each use.
- Disconnect the appliance from the mains when not in use and before undertaking any cleaning task.
- This appliance is for household use only, not professional or industrial use.
- This appliance is not a toy.
- Store the appliance in a dry place, free from dust and out of direct sunlight.
- Never leave the appliance unattended while in use.
- This appliance can be used by children aged 8 years and above if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children unless they are older than 8 years and supervised.
- Keep the appliance and its cord out of reach of children aged less than 8 years.
- Do not use this appliance with a programmer, counter, or another device that can operate automatically.
- Turn it on because it is dangerous.
- If you apply too much pressure to the cone while juicing, the motor may seize.
- To protect against electrical shock, do not immerse the cord, plug, or appliance itself in water or other liquids.

DESCRIPTION



1. Big Rotating head
2. Small Rotating head
3. Strainer
4. Juice Container
5. Axis of rotation
6. Main machine

TECHNICAL INFORMATION

- Model: SS-5185
- Voltage / Frequency:
- 220 – 240V~ 50/60Hz
- Power Consumption: 160W

INSTRUCTIONS FOR USE

Cautiolf if you apply too much pressure to the juicing cone and it clogs, the motor may stop working.

1. Fit the appropriate cone onto the drive shaft.
2. If you wish to collect the juice in the container, press the spout upwards to close it.
3. If you want the juice to run straight into a glass, press the spout downwards to open it and place a glass under it.
4. Cut a citrus fruit in half and press the cut end of one fruit half onto the cone. Bring down the liver to press the fruit over the cone.
5. The juicer switches on automatically when you press the fruit down, and the cone starts to turn. The juicer automatically switches off as soon as you reduce pressure on the cone.
6. The cone scrapes the pulp out and squeezes the juice from the fruit.
7. The juice flows through the strainer into the juice container, from where it can run into a glass (the spout must be open). The strainer keeps back thick pulp and seeds.
8. To maximize the quantity of juice extracted from A fruit, press the fruit onto the cone several times.

CLEANING

- Unplug the appliance from the mains and let it cool before starting any cleaning.
- Except for the power unit and the mains connection, all the parts can be cleaned with detergent and water, or washing-up liquid.
- Rinse thoroughly to remove all traces of detergent.
- Clean the equipment with a damp cloth with a few drops of washing-up liquid and then dry.
- Do not use solvents such as bleach or abrasive products for cleaning the appliance.
- Do not submerge the appliance in water or any other liquid, or place it under a running tap.
- It is advisable to clean the appliance regularly and remove any food remains.
- The following parts can be cleaned in the dishwasher: Cone, Strainer, nd Middle container.

JUICING ADVICE

1. Citrus fruit juices should be consumed immediately and never stored in a metal container.
2. Citrus juices are ideal for mixing. For example, You can mix orange juice with lemon juice for extra vitamin C kick.
3. Freshly squeezed juice gives cocktails a better flavor. Lemon juice is also delicious in hot tea and additionally helps you build up your defences when you have a cold.



DECLARATION OF CONFORMITY

This device complies with the Low Voltage Directive 2014/35/EC, Electromagnetic Compatibility Directive 2014/30/EU, Directive 2015/863/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment and the Directive 2009/125/EC on the eco-design requirements applicable to energy-related products.



— This symbol means that in case you wish to dispose of the product once its working life has ended, take it to an authorised waste disposal site agent for the selective collection of waste electrical and electronic equipment (WEEE).

Imported by

Sanysan Appliances S.L., NIF: B98753056
C/ Barcas 2, 2
46002 Valencia, Spain
Product made in P.R.C. – Designed by
SOGO based on the European Quality

Standards

Customer Service: www.sogosat.com
sogosat@sogosat.com / 0034 902 222 161

Download PDF: [Sogo SS-5185 Citrus Juice Extractor Press Handle User Manual](#)

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.