




SOLAX Pocket Wifi 2.0 For Panel Monitoring User Manual

[Home](#) » [SOLAX](#) » SOLAX Pocket Wifi 2.0 For Panel Monitoring User Manual 



Please read this user manual carefully before use.

Contents


- [1 Installation](#)
- [2 Enter setting page](#)
- [3 Introduction](#)
- [4 Safety Instructions](#)
- [5 Warranty Regulation and Liability](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

Installation




Cut off all power of inverter before installation!
Wait for 5 minutes after power off.

1. Plug Pocket Wifi port or “WiFi/Lan/ GPRS” port at the bottom of inverter.



***Notes:** Inserting Pocket Wi“RF” port or “Upgrade” port may lead to system failure.

2. Screw it tightly.



3. Power inverter on, then set the wifi

Step1: signal from the inverter.

(The SSID : Solax_xxxxxxx)

Step2: Connect to WIFI signal .

Step3: Open a browser(IE, Firefox, Chrome) and type in “http://5.8.8.8/.”

Step4: Type in username and password. (username: admin, password: admin)

Step5: Enter setting page.

5.1 Connect to home router by clicking “Find AP”

or manually input home router’s SSID.

5.2 Input password of home router as “key”.

5.3 Click “Save”.

Enter setting page

The screenshot shows a web-based configuration interface for a router. It has three tabs: 'DHCP', 'Static IP', and 'Firmware upload'. The 'Static IP' tab is selected. Below the tabs are several input fields: 'Firmware Version' (2.20), 'MAC address' (C8-03-46-C7-29-58), 'SN' (SUNX000FTN), 'IP address' (192.168.1.100), 'SSID' (solaXpower1), and 'Key' (masked with dots). A 'Find AP' button is located to the right of the SSID field. At the bottom right, there is a 'Save' button. Three orange arrows point to specific elements: arrow 5.2 points to the 'Key' field, arrow 5.1 points to the 'Find AP' button, and arrow 5.3 points to the 'Save' button.

5.4 Make sure save con.

Save Config Done! Please wait 15 seconds!!!Return

Notes and troubleshooting for WIFI setting!

Notes

The signal strength will be affected by barriers between inverter and home router. Please keep the distance between inverter and home router within 10 meters (open space).

SolaX suggests that smartphone is more suitable than computer to do WIFI setting.

Please make sure that home router is under normal working condition. Any problems of router may cause wie. (The home router should support 802.11b/g/n.)

Troubleshooting

Wimal is too weak to connect when searching it by smartphone.

Please check the wifi and shorten the distance between operator and wi module.

Browser shows " This page can not be displayed" after typing <http://5.8.8.8/>.

Please use smartphone to do this step instead of laptop.

After clicking Save& Reboot and entering IP Address page, the IP address shows all "0".

It means the wifi.

Please check the signal strength of home router. (strength of signal must be over 3 bar) Check SSID and password again.

Check whether home router is under normal working condition.

FCC Caution

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modishly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reason able protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

***RF warning for Mobile device:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

- RF output power(ERP/EIRP) : 11b: 18.4dBm 11g: 14.6dBm 11n20: 14.6 dBm
- Frequency band (MHz) : 2412-2472
- Modulation : DSSS/OFDM

Registration on Monitoring website.

Conn wiconhas done

Step1: successfully, and make sure Internet service is accessible on the laptop or smartphone.


Input “<https://www.solaxcloud.com>” on web

Step2: browser.

Step3: Click “Sign up” as shown below.



Fill up all information shown on sign up page, then click “Save”. The registration is completed. (Users can the “Registration No.” on the label of Pocket Wi2.0)




Fill up station information on the “Add power

Step4: station” pop-up window. The options with “*” are compulsory . Mark you site on the map and click “Complete”.

The screenshot shows a web interface for adding a power station. The form is titled "Add power station". It contains the following fields: Site Name (filled with "solax0072site"), Address, Timezone (filled with "UTC+08:00(Beijing,Chongqing)"), Country (filled with "China"), Province (filled with "北京市"), City (filled with "东城区"), County, Introduction, and Remark. To the right of the form is a map showing a location in Beijing. At the bottom of the form, there are two buttons: "Cancel" and "Complete". The "Complete" button is highlighted with a red rectangular box.


Make sure the power stations has been added successfully.



Step5: then click "Login". Input user name, password and viricide,

The screenshot shows the SOLAX login page. At the top, there are links to the Google Play and App Store, and a "Select language" dropdown. The SOLAX logo is prominently displayed. Below the logo, there are three input fields: a username field (filled with "storn1@solax.com"), a password field (filled with "*****"), and a verification code field (filled with "7D5K"). Below these fields are two buttons: "Login" and "Sign up". The "Login" button is highlighted with a red rectangular box. At the bottom of the page, there is a footer with links for "About us", "Service and support", "Common problem", and "Contact us", along with a copyright notice.


Click **overview page**, user can monitor inverter and check the data.




Notes: Pocket Wi2.0 will upload the SN number of For future use matching inverter automatically after powering the inverter on (after 2 minutes).

Click Inverters on the menu bar, user can check if Pocket Wi2.0 is online with Online Status.

Add a new site —click “Add” under the option “Site” on the menu bar and the setting page is similar to **Step4**.



Add a new inverter on a site—Choose site and click “+”, input “Registration No.,” then click “Save” to finish.




Introduction

Pocket Wi.0 makes the long-term monitoring of PV systems feasible and efficient by collecting information from inverter including status, performance and updating information to monitoring website.

- Quick installation with “Plug & Play” function
- IP 65 dust prevention water proofing
- Stable data transmission and good reliability

- Low profile and nice exterior

Appearance and Demission



Technical Data

Product Name	Pocket Wifi
Model	Pocket Wifi
Supply Voltage	+3.3 V
Frequency	2.400~2.472GHz
Antenna Gain	3dB
Interface	UART/USART
Protocol	TTL
Wireless mode	802.11b/g/n
Degree of protection	IP 65
Demission	82 40 24.5mm
Weight	<35g

Safety Instructions

- Before installation, all power of inverter must be cut off.
- Keep away from ammable, explosive materials.
- Do not dismantle or scrap by force.
- Children should be supervised to ensure that they do not play with this appliance.

Warranty Regulation and Liability

Terms and conditions

SolaX grants a warranty of 12 months as standard. Starting from the date of the purchase invoice marked. SolaX

will only perform warranty service when the faulty unit is returned to SolaX together with a copy of invoice and warranty card which were issued by the dealer to the users. In addition, the type label of the unit must be fully legible. If these requirements are not fulfilled, Satellite reserves the right to deny warranty service.

Exclusion of liability

Warranty claims are excluded for direct or indirect damage due to:

1. Use of unit in ways not intended, improper installation and installation that does not comply with standards, improper operation and unauthorized mode repair attempts.
2. Without warranty card and serial number.
3. Operating the units with defective protective equipment.
4. Inorbing objects and force majeure.
5. Inadequate ventilation.
6. Non-observance to relevant safety instructions.

Warranty Registration Form

Please retain this page as proof of your purchase and your guarantee.

Name
Country.....
Phone Number.....
Zip Code.....
Email.....
Address.....
Product Serial Number.....
Date of Commissioning.....
Installation Company Name.....
Date of Delivery.....
Signature.....

To register your SolaX product, please mail this warranty card to:

ADD: Room 220, West Building A Sci. and Tech Park of
Zhejiang University No.525, Xixime Road, Hangzhou
Zhejiang Province, China 310007

Tel: +86 571 56260011

Fax: +86 571 56075753

Email: service@solaxpower.com

Web: <http://www.solaxpower.com/>




Online warranty registration is available at <http://www.solaxpower.com/en/warranty-registration/>



Documents / Resources

	SOLAX Pocket Wifi 2.0 For Panel Monitoring [pdf] User Manual Pocket Wifi 2.0 For Panel Monitoring, Pocket Wifi 2.0, For Panel Monitoring, Panel Monitoring, Monitoring
--	--

References

-  [SolaX Power: Solar Inverter, Battery System, EV Charger](#)
-  [SolaX Power: Solar Inverter, Battery System, EV Charger](#)
-  [Solax Cloud System](#)

Manuals+.