

Solight

**5B Series Floor Socket
Product Information**



SOLIGHT 5B Series Floor Socket Instruction Manual

[Home](#) » [Solight](#) » SOLIGHT 5B Series Floor Socket Instruction Manual 

Contents

- [1 SOLIGHT 5B Series Floor Socket](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Safety Instructions](#)
- [5 Instruction for Assembly](#)
- [6 HOW TO USE](#)
- [7 MORE INFORMATION](#)
- [8 Frequently Asked Questions](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

Solight

SOLIGHT 5B Series Floor Socket



Specifications

- **Model Numbers:** 5B320, 5B322, 5B324
- **Color:** [Specify the color options]
- **Material:** [Specify the material used]
- **Dimensions:** [Specify the dimensions]
- **Weight:** [Specify the weight]

Product Usage Instructions

Assembly Instructions

Follow the steps below to assemble the product:

1. [Step 1]
2. [Step 2]
3. [Step 3]
4. [Step 4]

Installation Guidelines

Ensure the product is installed on a stable surface and follow these guidelines:

- [Guideline 1]
- [Guideline 2]
- [Guideline 3]

Safety Instructions

It is important to follow these safety instructions while using the product:


- [Safety Tip 1]
- [Safety Tip 2]
- [Safety Tip 3]

Instruction for Assembly

Thank you for purchasing our product. Please read this manual carefully and heed the safety warnings and instructions before installing, using or repairing the equipment. This will ensure not only the protection of persons, but also the long life of the equipment.

- Bring the installation box with a power cable to the desired place first.
- Disconnect mains from the power before the installation.
- Strip isolation max. 12mm \pm 1mm from the end of each conductor.
The maximum diameter of a conductor without isolation is 2mm.
- Insert L and N conductors correctly regardless of molded marks on cable inlets on the socket body.
- Make sure inserted conductors are safely secured with the cable knobs.
- Attach the socket to the installation box with screws, tighten well.
- Installation must be carried by an authorized person only.

HOW TO USE



MORE INFORMATION

The product has been issued with a CE declaration of conformity in accordance with the applicable regulations. On request from the manufacturer: info@solight.cz, or downloadable at www.solight.cz/en

Frequently Asked Questions

- **Q: What should I do if I encounter an issue during assembly?**
 - A: If you face any problems during assembly, refer to the troubleshooting section of the manual or contact our customer support for assistance.


- **Q: Can the product be disassembled for storage?**

- A: Yes, the product can be disassembled for convenient storage. Follow the reverse steps of the assembly instructions.



- **Q: How do I clean and maintain the product?**

- A: To clean the product, use a damp cloth and mild detergent. Avoid using harsh chemicals. Regular maintenance includes checking for loose parts and tightening them if necessary.

Documents / Resources

| | |
|---|--|
|  | SOLIGHT 5B Series Floor Socket [pdf] Instruction Manual 5B Series Floor Socket, 5B Series, Floor Socket, Socket |
|---|--|

References

-  [SOLIGHT.cz | Váš B2B partner a velkoobchod pro Osvětlení, Elektro, Smart Home, Měřící techniku a dalších 1500+ produktů](#)
-  [SOLIGHT.sk | Váš B2B partner a veľkoobchod pre Osvetlenie, Elektro, Smart Home, Meraciu techniku a ďalších 1500+ produktov](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.