



SOLIGHT WN34 Torch Instruction Manual

[Home](#) » [Solight](#) » SOLIGHT WN34 Torch Instruction Manual 



Contents

- [1 Solight WN34 torch operating instructions](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

Solight WN34 torch operating instructions

Dear customer, thank you for purchasing our product. Please read and follow these instructions carefully to serve you safely and to your full satisfaction. This will prevent misuse or damage. Avoid improper handling of this appliance and always observe the principles of using electrical appliances. Keep the instructions for use carefully.

Battery: Li-Ion 3.7V, 2800mAh

Battery life: 3 – 4 hours

Charging time: 4 – 5 hours

Lighting modes: 100%, 30%, 10%, flashing, SOS

Charge indication: The flashlight indicates the charge level by four diodes of 25% each.

Charging: Charge the flashlight using the microUSB cable (supplied) and the 5V adapter (not supplied). The LED flashes while charging. It is steady when the lamp is charged.

Before using or charging for the first time, remove the paper insulating ring located in the battery compartment.

The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole

