



SONGYANG SY073B Handle Remote Control User Manual

[Home](#) » [SONGYANG](#) » SONGYANG SY073B Handle Remote Control User Manual 

SONGYANG

SY073B Handle Remote Control Manual

Contents

- [1 Product list](#)
- [2 Remote control battery installation](#)
- [3 Function introduce](#)
- [4 Function instructions](#)
- [5 Charging instructions](#)
- [6 Spray operation method](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

Product list




Remote control battery installation

Remote controller: 1.Open the battery cover of the remote control and load 1.5V AA battery according to the positive and negative polarity of the battery compartment.


2.Cover the battery box and lock the screws.

Remote control car: 1.Open the bottom battery cover and connect the rechargeable battery to the power outlet and load it into the bottom of the car.

2.Cover the battery box and lock the screws.



Function introduce




Function instructions

Forward/Backward	The joystick push to forward and backward the car go forward and backward.
Rotate Left/Rotate Right	Push the left/right rotation key of the remote control, and the car will rotate (left/right) .
Turn left and right sides	Push the remote control (forward/back) button and press the (left/right) spin button at the same time to turn left/right.
Forearm rise/descend	Press and hold the forearm up/down button to make the remote control forearm up/down.
Rear arm rise/descend	Press and hold the rear arm up/down button to make the remote control rear arm up/down.
360°rotate	Press the 360° rotation button to make the remote control car rotate 360° (any key to exit).
Spray Key	Press the spray button and the Radio-controlled car will start spray. (In spray mode, please fill the water to injection hole of the rear of car in advance).
One key Demo	Press the demo button, the remote control car enters the automatic demo mode.

Charging instructions

1. This 3.7V lithium battery is new , before playing please charge the battery.
2. Connect the battery plug to the USB cable plug, press the correct pole to connect, and then plug the charging cable into the socket to charge.
3. It takes 180 minutes to fully charge the battery,Charging plug with indicator light, red light on when charging, light off when full. Please don't overcharge,Charging for a long time will not increase the power.
4. Check toys and batteries regularly. If accessories, batteries, charging cables, etc. are damaged, stop using them immediately.After repair or renewal, can continue to use.



Operation tip

- 1. When you are in operation, the power switch is in the “ON” position, such as the power switch is in “OFF”, the car is turned OFF.
- 2. When the battery power is consumed, the left and right steering will fail and the forward and backward speed will also slow down. The battery needs to be removed and recharged.
- 3. The effective control distance of the remote control car is about 25 meters. When the distance exceeds the distance, the remote control car may appear to stop or uncontrolled phenomenon.

Spray operation method

Turn off the accessory and use the water bottle to inhale the water into the hole of the car.

Turn on the accessory

Pay attention not to fill the bottle mouth when injecting water, water does not leak to the body, to prevent circuit board short circuit.

Add water hole



FCC Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Documents / Resources



[SONGYANG SY073B Handle Remote Control](#) [pdf] User Manual
SY073B Handle Remote Control, SY073B, Handle Remote Control, Remote Control

References

- [User Manual](#)

