




SONNEMAN 3542 Shells Table Lamp Instruction Manual

[Home](#) » [SONNEMAN](#) » SONNEMAN 3542 Shells Table Lamp Instruction Manual 

SONNEMAN 3542 Shells Table Lamp



Contents

[1 Shells](#)

[2 Product Information and Warnings](#)

[3 Instructions D'Installation](#)

[4 Documents / Resources](#)

[5 Related Posts](#)

Shells

3542, 3544, 3545

Table Lamp,
Small Floor Lamp,
Large Floor Lamp

Product Information and Warnings


IMPORTANT

- Always disconnect the power before installing or replacing Luminaires and before cleaning or other maintenance.
- Please read all included assembly instructions and warnings carefully before installation. Contact Customer Service if you have any questions or concerns. Before installation, please confirm that the fixture is compatible


with your supply voltage and dimming system, if present.

- LEDs are highly sensitive electronic devices, and must be treated with care. Do not open any factory sealed compartments, and avoid touching the LEDs with your hands or any object.
- Although all our fixtures are equipped with protective devices, LED electronic systems are vulnerable to power surges and supply variations. Do not install LED fixtures on the same circuit as any motors, appliances, or HVAC systems.
- Do not remove or bypass any LED Driver or Transformer that is provided with the fixture, and do not replace or substitute with another power supply.
- Fixtures must be wired in parallel on independent leads; do not “daisy chain” multiple fixtures together or wire them in series.
- All factory-made splices and connections must remain intact. LED circuits are carefully designed and built, and improper connections may damage the fixture.
- The ends of coaxial pendant cords have been precisely stripped and split at the factory and must not be field cut. Excess cord or cable should be neatly coiled and reserved in the fixture canopy.
- Any mounting hardware is provided for your convenience and should be used with discretion. Always use the appropriate hardware for the mounting surface.

Instructions D'Installation




1. For 3544, 3545: Thread the bottom weight (M) to the lamp base (B), then thread the lamp stems (A) and the base (B) together.
2. Fit the Small shade (C) over the lamp body (D), then place at the base (B).
3. Fit the Medium shade (E) over the lamp body (D), then place at the base (B).
4. Place Shade hangers (F) on the lamp body, in the designated shade hanger slots.
5. Place the Large shade (G) on the lamp body, and fasten with top finial (H).
6. Bring the Medium shade (E) up, and position the hangers (F) so the middle notch catches the shade.
7. Bring the Small shade (C) up, and position the hangers (F) so the bottom hook catches the shade.
8. Connect power supply plug adapter (I) to lamp cord (J).
Insert power supply plug into wall outlet.
9. For 3542: Rotate the in-line dimmer switch (K) to turn the lamp on and off, and to adjust the brightness.
For 3544, 3545: Press the foot switch (L) to turn the lamp on and off. Press and hold the switch to adjust brightness.



Care Instructions:

Use a clean, dry cloth when dusting. To protect the finish, avoid any harsh abrasives or chemicals.

SONNEMAN®
A WAY OF LIGHT

<div><div>Assembly Instructions</div><div></div><div>Model: 3542, 3544, 3545 3542 (Lamp) 3544 (Table Lamp) 3545 (Table Lamp) Product Information and Warnings</div></div>	<div><div>SONNEMAN 3542 Shells Table Lamp [pdf] Instruction Manual</div><div>3542, 3544, 3545, 3542 Shells Table Lamp, Shells Table Lamp, Table Lamp, Lamp</div></div>
--	--