



SONOFF MINI-RBS Smart Roller Shutter Switch User Manual

July 21,
2025

Contents [[hide](#)]

- [1 MINI-RBS Smart Roller Shutter Switch](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
 - [3.1 Installation](#)
- [4 Frequently Asked Questions \(FAQ\)](#)
 - [4.1 Q: How do I reset the device?](#)
 - [4.2 Q: Can I use this switch with a motor that exceeds 1A current?](#)
 - [4.3 Documents / Resources](#)
 - [4.3.1 References](#)

MINI-RBS Smart Roller Shutter Switch

“

Specifications

- **Model:** MINI-RBS
- **MCU Rating:** ESP32
- **Wireless Connectivity:** Wi-Fi IEEE 802.11 b/g/n
2.4GHz

- **Net Weight:** 25.1g
- **Product Dimension:** 39.5x33x16.8mm
- **Color:** White
- **Casing Material:** PC
- **Applicable Place:** Indoor
- **Working Temperature:** -10°C to 40°C
- **Working Humidity:** 5-95% RH,
non-condensing
- **Working Height:** Less than 2000m
- **Certification:** CE/FCC/RoHS
- **FCC ID:** 2APN5-MINIRBS
- **Pollution Degree:** 2
- **Rated Impulse Voltage:** 4kV
- **Automatic Action:** 10000 Cycles
- **Control Type:** Type 1.B
- **Diameter of Wiring (Recommend):** 18AWG to 14AWG
SOL/STR copper conductor only

Product Usage Instructions

Installation

1. **Power off:** Please ensure the power is off before installation.
2. **Wiring Instructions:** Follow the wiring instructions provided in the manual carefully.

- Momentary Switch Wiring:



- Three-Position Rocker Switch Wiring:



*Make sure all wires are connected correctly.

- **Power on:** After installation, power on the device. It will enter pairing mode automatically.

Frequently Asked Questions (FAQ)

Q: How do I reset the device?

A: To reset the device, press and hold the reset button for 10 seconds until the LED indicator flashes.

Q: Can I use this switch with a motor that exceeds 1A current?

A: No, this switch is designed to support motors with a maximum current of 1A only. Using it with a higher current motor may cause damage to the switch.

“

[View Fullscreen](#)

U R S ser Manual MINI- B (EN)

Smart Roller Shutter Switch

User Manual V1.1

Introduction

This compact smart curtain retrofit is designed to fit perfectly into an EU-type mounting box and supports motors with a maximum current of 1A as a load. It offers WiFi remote control and is compatible with the Matter platform, enabling seamless integration across multiple smart home systems. Simply connect the device to the switch and motor correctly to easily upgrade ordinary electric roller shutters to smart systems.

Remote Control

Percentage Control

Timer Schedule

Deviation Calibration

1

Voice Control

eWeLink Remote

Smart Scene

Direction Reverse

Button

- Press and hold for 5 seconds: Device enters the pairing mode. (Pairing time 10 minutes)
- Short press three times: Switch the external switch type.

LED indicator (Blue)

- Keeps on: Online. · Flashes once: Offline · Flashes twice: LAN · Flashes two short and one long: Device is in pairing mode.
- Breathing mode (press and hold the button for 10 seconds): The device successfully marks the “fully open” position of the curtain.
- Flashes three times (short press the button once while in breathing mode): The device successfully marks the curtain in the “fully closed” position.
- Flashes three times: The switch type is successfully switched.

Matter-compatible Ecosystem

2

Specification

Model MCU Rating Wireless connectivity Net weight Product dimension Color Casing material Applicable place Working temperature Working humidity Working height Certification FCC ID Pollution degree Rated impulse voltage Automatic action Control type Diameter of wiring(recommend)

MINI-RBS ESP32 100-240V~ 50/60Hz 1A Max Wi-Fi IEEE 802.11 b/g/n 2.4GHz 25.1g 39.5x33x16.8mm White PC Indoor 10T40 (-10 ~40) 5-95%RH, non-condensing Less than 2000m CE/FCC/RoHS 2APN5-MINIRBS 2 4kV 10000 Cycles Type 1.B 18AWG to 14AWG SOL/STR copper conductor only

3

Installation 1. Power off

WARNING

Please install and maintain the device by a professional electrician. To avoid electric shock hazards, do not operate any connection or contact the terminal connector while the device is powered on!

2. Wiring instructions

To ensure the safety of your electrical installation, it's essential that either a Miniature Circuit Breaker (MCB) or a Residual Current operated Circuit-breaker with Integral Overcurrent protection(RCBO) with an electrical rating of 1A has been installed before the MINI-RBS. Momentary Switch Wiring:

4

Three-Position Rocker Switch Wiring:

*Make sure all wires are connected correctly.

Instructions for wiring symbols 5

Terminals N L L out1 L out2 S1 S2

Neutral Line Live Line Live Output Terminal__1(100~240V) Live Output
Terminal__2(100~240V) Switch_1 (Forward Control) Switch_2 (Reverse Control)

Wires

N

Neutral Line

L

Live Line 100~240V

Forward Line

Motor Forward Line

Reverse Line

Motor Reverse Line

3. Power on

When the device is used for the first time, it will enter pairing mode by default after being powered on. At this time, the LED indicator will flash in a pattern of “two short and one long”.

*The device will exit the Pairing Mode if not paired within 10mins. If you want to enter this mode, please long-press button for about 5s until the LED indicator changes in a cycle of two short and one long flash and release. *As the maximum one-way allowable continuous operation time for the motor in this

6

device is 2mins, please pause the operation before the curtain reaches its limit position to avoid damaging the motor.

Check the Device Status

1. External switch type

The types of external switches supported are

three-position rocker switches and

momentary switches, with the default setting from the factory being the rocker switch

(Edge Mode).

The method to switch the external switch type: Short-press the button three times and

the blue light flashes 3 times, then the switch type is switched successfully.

External switch trigger mode switching sequence (cycle): Edge Mode

Pulse Mode

Following Mode

2. Roller shutter direction test

Press the external switch to check if the roller shutter moves in the correct direction. If it does not, power off the device, swap the Lout1 and Lout2 wires, and test again.

Important Prerequisite Confirmation: Please select the appropriate section based on the ecosystem you are using (Matter or eWeLink). Follow the corresponding steps to complete the “Add Device” and “Travel Calibration” operations.

Matter Ecosystem User Guide

1. Add Device

Open a Matter-compatible App to scan the Matter QR code on the Quick Guide or the device itself to add the device.

Add to Google via Matter

Add to Alexa via Matter

Add to SmartThings via Matter

2. Travel Calibration

Using percentage control requires travel calibration. Please select one of the following two calibration options based on your needs.

Method 1:Automatic calibration

Press and hold the device button for more than 10 seconds until the LED indicator enters breathing mode. The device will then automatically control the motor for calibration.

Method 2:Manual calibration

Press and hold the device button for more than 10 seconds until the LED indicator enters breathing mode. Then, briefly press the device button to enter “Manual Calibration” mode.

8

Manually open the curtains completely, then briefly press the device button until the LED indicator flashes three times.

Wait for the device to automatically close the curtains, then briefly press the device button again until the LED indicator flashes three times. This completes the “Manual Calibration.”

Control the device through the App and check the fully open or fully closed positions. If there is any discrepancy, you can recalibrate.

9

fully open

fully closed

eWeLink Ecosystem User Guide

1. Add Device

Download the eWeLink App

Please download the “eWeLink” App from Google Play Store or Apple App Store.

Scan QR code to add the device

10

Enter “Scan”

Scan the QR code on the device

Select “Add Device”

Power on the device

Long press the button for 5 seconds

Check Wi-Fi LED indicator flashing status (Two short and one long)

11

Search for the device and start connecting

Select the “Wi-Fi” network and enter the password

Device “Added completely”

2. Travel Calibration

Using percentage control requires travel calibration. Please select one of the following two calibration options based on your needs. Users can use the “Travel Calibration” pop-up window in the eWeLink App, or open the “Initial Settings” on the device settings page and then perform “Automatic Calibration” or “Manual Calibration” according to the text instructions in the App.

Method 1:Automatic calibration

12

Click “Start Now” Method 2:Manual calibration

Wait for the automatic calibration to complete

Click “Start Now”

Click “Manual”

Select “Next” to mark the “fully open” position

Select “Done” to mark the “fully close” position

13

Install the Device in the Mounting Box

Factory Reset

Reset the device to factory settings by “Delete device” in the eWeLink App.

FCC compliance statement

1. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

14

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

–Reorient or relocate the receiving antenna. –Increase the separation between the

equipment and receiver. –Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

–Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

EU Declaration of Conformity

Hereby, Shenzhen Sonoff Technologies Co., Ltd. declares that the radio equipment type MINI-RBS is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<https://sonoff.tech/compliance/>

For CE frequency

15

EU Operating Frequency Range

Wi-Fi: 802.11 b/g/n 2412 2472 MHz, 802.11 n40: 2422-2462 MHz BLE: 2402 2480 MHz

EU Output Power

Wi-Fi 2.4G 20dBm BLE 10dBm

WEEE Disposal and Recycling Information

WEEE Disposal and Recycling Information All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

Warning

Under normal use of condition, this equipment should be kept a separation distance of at

least 20 cm between the antenna and the body of the user. Dans des conditions normales d' utilisation, cet équipement doit être maintenu à une distance d' au moins 20 cm entre l' antenne et le corps de l' utilisateur.

Scatola PAP 21 Carta

Manuale PAP 22 Carta

16

RACCOLTA DIFFERENZIATA

Verifica le disposizioni del tuo Comune. Separa le componenti e conferiscile in modo corretto.

Manufacturer: Shenzhen Sonoff Technologies Co., Ltd.

Address: 3F & 6F, Bldg A, No. 663, Bulong Rd, Shenzhen, Guangdong, China

ZIP code: 518000


Service email: support@itead.cc

Website: sonoff.tech

Made in China

17

Documents / Resources

	<p>SONOFF MINI-RBS Smart Roller Shutter Switch [pdf] User Manual</p> <p>MINI-RBS, MINI-RBS Smart Roller Shutter Switch, MINI-RBS, Smart Roller Shutter Switch, Shutter Switch, Switch</p>
---	---

References

- [User Manual](#)

■ SonOFF

🔑 MINI-RBS, MINI-RBS Smart Roller Shutter Switch, Shutter Switch, Smart Roller Shutter Switch, SonOFF, switch

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.

