

# **SONOFF POWR3 WiFi Smart DIY Switch User Manual**

Home » SonOFF » SONOFF POWR3 WiFi Smart DIY Switch User Manual

#### Contents [ hide

- 1 SONOFF POWR3 WiFi Smart DIY
- **Switch**
- 2 Power off
- 3 Wiring instruction
- 4 Download the eWeLink app
- 5 Power on
- 6 Add the device
- **7 EU Declaration of Conformity**
- 8 Documents / Resources
  - 8.1 References
- 9 Related Posts




## **SONOFF POWR3 WiFi Smart DIY Switch**



The product user guide contains product features, how to use, and the operating procedure. Read the user manual carefully to get the best experience and avoid unnecessary damage. Keep this manual for future reference. If you have any questions or comments about the device, please contact the customer line.

- www.alza.co.uk/kontakt
- +44 (0)203 514 4411
- Alza.cz a.s., Jankovcova 1522/53, Holešovice, 170 00 Praha 7, www.alza.cz


## Power off




To avoid electric shocks, please consult the dealer or a qualified professional for help when installing and repairing.

# Wiring instruction

Light fixture wiring instruction:



**Appliance wiring instruction:** 




Make sure all wires are connected correctly.


# Download the eWeLink app



## Power on



After powering on, the device will enter the quick pairing mode (Touch) during the first use. The W-FI LED indicator changes in a cycle of two short and one long flash and release.



The device will exit the quick pairing mode (Touch) if not paired within 3mins. If you want to enter this mode, please long press the pairing button of about 5s until the Wi-Fi LED indicator changes in a cycle of two short and one long flash and release.

#### Add the device



Tap "+" and select "Quick Pairing" then operate following the prompt on the app.

#### **Warranty Conditions**

A new product purchased in the Alza.cz sales network is guaranteed for 2 years. If you need repair or other services during the warranty period, contact the product seller directly, you must provide the original proof of purchase with the date of purchase.

# The following are considered to be a conflict with the warranty conditions, for which the claimed claim may not be recognized:

- Using the product for any purpose other than that for which the product is intended or failing to follow the instructions for maintenance, operation and service of the product.
- Damage to the product by a natural disaster, the intervention of an unauthorized person or mechanically through the fault of the buyer (e.g. during transport, cleaning by inappropriate means, etc.).
- Natural wear and aging of consumables or components during use (such as batteries, etc.).
- Exposure to adverse external influences, such as sunlight and other radiation or electromagnetic fields, fluid
  intrusion, object intrusion, mains overvoltage, electrostatic discharge voltage (including lightning), faulty supply
  or input voltage and inappropriate polarity of this voltage, chemical processes such as used power supplies,
  etc.
- If anyone has made modifications, modifications, alterations to the design or adaptation to change or extend the functions of the product compared to the purchased design or use of non-original components.

### **EU Declaration of Conformity**

Identification data of the manufacturer's / importer's authorized representative: Importer: Alza.cz a.s.

Registered office: Jankovcova 1522/53, Holešovice, 170 00 Prague 7

CIN: 27082440

#### Subject of the declaration:

Title: Wi-Fi Switch Model / Type: POWR3 The above product has been tested in accordance with the standard(s) used to demonstrate compliance with the essential requirements laid down in the Directive(s):

Directive No. (EU) 2014/53/EU

Directive No. (EU) 2011/65/EU as amended 2015/863/EU

#### **WEEE**

This product must not be disposed of as normal household waste in accordance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE – 2012/19 / EU). Instead, it shall be returned to the place of purchase or handed over to a public collection point for the recyclable waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. Contact your local authority or the nearest collection point for further details. Improper disposal of this type of waste may result in fines in accordance with national regulations.

#### **Documents / Resources**



SONOFF POWR3 WiFi Smart DIY Switch [pdf] User Manual POWR3, WiFi Smart DIY Switch, POWR3 WiFi Smart DIY Switch

#### References

- <u>® alza.at</u>
- k alza.co.uk
- 🍇 alza.de
- 🍇 alza.hu
- k alza.sk

Manuals+, home privacy