



SONY CFI-ZCVR1 Wireless Controller User Manual

[Home](#) » [Sony](#) » SONY CFI-ZCVR1 Wireless Controller User Manual 

Contents

- [1 SONY CFI-ZCVR1 Wireless Controller](#)
- [2 FCC and ISED notice](#)
- [3 Use and handling](#)
- [4 Battery](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



SONY CFI-ZCVR1 Wireless Controller



FCC and ISED notice

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that are deemed to comply without testing of specific absorption rate (SAR).

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

If you have questions about this product, visit www.playstation.com/helpme.

Supplier's Declaration of Conformity

Trade Name: SONY

Model No.: CFI-ZCVL1 / CFI-ZCVR1

Responsible Party: Sony Electronics Inc.

Address: 16535 Via Esprillo, San Diego, CA 92127 U.S.A.

Telephone No.: 858-942-2230

This device complies with Part 15 of FCC Rules and Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Use and handling

- When using the controller, be aware of the following points.
 - Before use, make sure that there is plenty of space around you.
 - Firmly grip your controller to prevent it from slipping out of your grasp and causing damage or injury.
 - When using your controller with a USB cable, ensure that the cable cannot hit a person or any object, and do not pull the cable out of the PlayStation® system whilst playing.
- Do not allow liquid or small particles to get into the product.
- Do not touch the product with wet hands.
- Do not throw or drop the product or subject it to strong physical shock.

- Do not put heavy objects on the product.
- Do not touch the inside of the USB connector or insert foreign objects.
- Never disassemble or modify the product.


Battery

Caution – using the built-in battery:

- This product contains a Lithium-Ion rechargeable battery.
- Before using this product, read all instructions for handling and charging the battery and follow them carefully.
- Take extra care when handling the battery. Misuse can cause fire and burns.
- Never attempt to open, crush, heat or set fire to the battery.
- Do not leave the battery charging for a prolonged period of time when the product is not in use.
- Risk of explosion if battery is replaced by an incorrect type.
- Always dispose of used batteries in accordance with local laws or requirements.
- Do not expose the product or battery to high temperatures, high humidity or direct sunlight during operation, transportation and storage.

“ ” is a registered trademark or trademark of Sony Interactive Entertainment Inc. “SONY” and “ ” are registered trademarks or trademarks of Sony Corporation.

Documents / Resources

	<p>SONY CFI-ZCVR1 Wireless Controller [pdf] User Manual CFIZCV1, AK8CFIZCV1, CFI-ZCVR1 Wireless Controller, CFI-ZCVR1, Wireless Controller</p>
---	--

References

-  [PlayStation Support](#)