



# SONY SDXC Memory Card Instruction Manual

[Home](#) » [Sony](#) » SONY SDXC Memory Card Instruction Manual 

## Contents

- 1 SONY SDXC Memory Card
- 2 For the Customers in the U.S.A.
  - 2.1 Supplier's Declaration of Conformity
- 3 SONY LIMITED WARRANTY
- 4 Documents / Resources
  - 4.1 References
- 5 Related Posts

# SONY®

**SONY SDXC Memory Card**



Before operating this card, please read this manual thoroughly.

**WARNING:** To reduce fire or shock hazard, do not expose the unit to rain or moisture.

### For the Customers in the U.S.A.

For question regarding your product or for the Sony Service Center nearest you, call 1-800-222-SONY (7669).

### Supplier's Declaration of Conformity

- **Trade Name:** SONY
- **Model:** SF-G32T/SF-G64T/SF-G128T/SF-G256T
- **Responsible Party:** Sony Electronics Inc.
- **Address:** 16535 Via Esprillo, San Diego, CA 92127 U.S.A.
- **Telephone Number:** 858-942-2230

**CAUTION:** You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## For the Customers in Canada

CAN ICES-3 B/NMB-3 B

## WARNING

1. TO AVOID CHOKING HAZARDS, KEEP OUT OF REACH OF CHILDREN.
2. DO NOT INSERT THIS CARD INTO ANY MEMORY CARD SLOT FOR WHICH IT WAS NOT INTENDED.

- This memory card does not have a write-protect switch.
- For the details of this memory card, please refer to the following URL or the product instruction manual of the compatible products.
- For more information on downloading software, please refer to the following URL  
<http://www.sony.net/memorycard/>

## Precautions on Use

- Please do not use or store this memory card in any environment exceeding the range of specified operating environment described below.
- Abuse or misuse will invalidate product warranty.
- This memory card may become hot after extended use. Use caution when touching it.

Sony shall not be responsible for any damage to or loss of recorded data.

- **Operating voltage:** 2.7 V to 3.6 V 1.7V to 1.95V for UHS-II
- **Operating environment:** -25 °C to +85 °C (-13 °F to +185 °F) (non-condensation)
- **Dimensions (W × L × T):** Approx. 24 mm × 32 mm × 2.1 mm
  - (31/32 in. × 1 9/32 in. × 3/32 in.)
- **Mass:** Approx. 2 g (0.07 oz)

Design and specifications are subject to change without notice. SDHC and SDXC Logos are trademarks of SD-3C, LLC.

## SONY LIMITED WARRANTY

SONY ELECTRONICS INC. (for U.S. Sales) and SONY OF CANADA LTD (for Canadian Sales) ("SONY") warrant this memory card product against defects in material or workmanship for a period of five (5) years from date of original purchase. Pursuant to this Limited Warranty, SONY will replace the product with a new or refurbished product. For purposes of this Limited Warranty, "refurbished" means a product or part that has been returned to its original specifications. In the event of a defect, this is your exclusive remedy.

**LIMITATION ON DAMAGES:** SONY SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OR CONDITION ON THIS PRODUCT. DURATION OF IMPLIED WARRANTIES: EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. Some states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This Limited Warranty gives you specific legal rights and you may have other rights which vary from state to state or jurisdiction to jurisdiction.

**Instructions:** It is your responsibility to back up any data, software or other materials you may have stored or preserved on your unit. It is likely that such data, software, or other materials will be lost or reformatted during service and SONY will not be responsible for any such damage or loss. A dated purchase receipt is required. To obtain warranty service within the United States, you must take the Product, or deliver the Product freight prepaid, in either its original packaging or packaging affording an equal degree of protection, to any authorized SONY service facility. To obtain warranty service within Canada, you must take the Product to the authorized SONY dealer where you purchased the Product, or to a SONY service facility.


In the United States contact: Sony Direct Response Center, 12451 Gateway Blvd., Fort Myers, FL 33913; [www.sony.com/service](http://www.sony.com/service); or (800) 222-7669 (SONY).

In Canada contact: Sony of Canada Ltd. 115 Gordon Baker Road, Toronto, Ontario M2H 3R6

©2022 Sony Corporation

<http://www.sony.net/>

## Documents / Resources

	<a href="#">SONY SDXC Memory Card</a> [pdf] Instruction Manual SDXC Memory Card, SDXC, Memory Card, Card
---	---

## References

-  [Sony Corporation - Memory Media Portal](#)