

SouLine R40 Computer Speaker User Manual

Home » SouLine » SouLine R40 Computer Speaker User Manual




Contents

- **1 Product Description**
- 2 Bluetooth mode
- 3 Specifications
- **4 FCC Caution**
 - 4.1 RF warning for Mobile device:
- **5 Documents / Resources**
- **6 Related Posts**

Product Description

- 1. Left speaker
- 2. Right speaker

- 3. Power & mode switching
 - 1. Long press to turn on / off
 - 2. Short press Bluetooth / aux mode switch
- 4. Light & pause / play adjustment
 - 1. Short press light mode switch
 - 2. Long press pause / play
- 5. Previous & volume+
 - 1. Long press previous song
 - 2. Short press volume+
- 6. Next & volume-
 - 1. Long press next song
 - 2. Short press volume7. FX LED light effects
- 7. 3.5mm audio jack
- 8. USB jack: 5V speaker input power



Bluetooth mode

1. After the speaker is powered on, long press the MODE key to power on. The default mode of power on is aux mode. Short press to switch the Bluetooth / aux mode. Then open the Bluetooth device of the mobile phone or computer, search the corresponding Bluetooth device, name it "R40", and click connect. After pairing and connecting, there will be a prompt tone, you can play music

- 2. after connecting with mobile phone once, Bluetooth has memory function. After turning on the Bluetooth of mobile phone, it can connect automatically or manually according to different types of mobile phones. If it needs to be disconnected, the Bluetooth settings can be disconnected through the mobile phone.
- 3. Insert aux in and press MODE key to switch to aux mode

Note: If the audio cable is connected to the computer or the mobile phone has current noise, please turn the audio cable head to adjust until there is no current noise.

Specifications

• Bluetooth version: V5.0

• Bluetooth receiving distance: ≥ 10m

Output power (RMS): 5W× 2
Speaker size: 2.5 INCH× 2

• Frequency response: 60Hz-20KHz

Power supply: USB 5V/ 1A

Audio input: Bluetooth/3.5 mm AUX
 Product size: W83×D103×H180mm

FCC Caution

FCC ID: A202205R40

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and;
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This

equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Documents / Resources



<u>SouLine R40 Computer Speaker</u> [pdf] User Manual R40, 2A7UBR40, R40 Computer Speaker, Computer Speaker

Manuals+,