




Soundcore AK-A3371211 Infini 2.1 Channel Sound Bar User Manual

[Home](#) » [Soundcore](#) » Soundcore AK-A3371211 Infini 2.1 Channel Sound Bar User Manual 

Contents


- [1 Soundcore AK-A3371211 Infini 2.1 Channel Sound Bar](#)
- [2 What's Included](#)
- [3 At a Glance](#)
- [4 Placement
 - \[4.1 Placing on a TV stand\]\(#\)](#)
- [5 Connecting
 - \[5.1 Option 3\]\(#\)](#)
- [6 Using Your Soundcore Infini 2](#)
- [7 LED Light Guide](#)
- [8 Remote Control](#)
- [9 Reset](#)
- [10 Firmware Update](#)
- [11 Specifications](#)
- [12 Customer Service](#)
- [13 Documents / Resources
 - \[13.1 References\]\(#\)](#)
- [14 Related Posts](#)

soundcore


Soundcore AK-A3371211 Infini 2.1 Channel Sound Bar




What's Included




Soundcore Infini 2




AC Power Cable




Remote Control




Batteries × 2




HDMI 2.0 Cable




AUX Cable



Screws × 2, Anchors × 2




User Manual



- Soundcore Infini 2
- AC Power Cable
- Remote Control
- Batteries × 2
- HDMI 2.0 Cable
- AUX Cable
- Screws × 2, Anchors × 2
- User Manual
- Safety Card
- Brand Card


At a Glance

FRONT PANEL




1. Indicator Light
2. Remote Sensor

TOP PANEL



1. Standby Button
2. Source Button
3. Bluetooth Button
4. Volume Down Button
5. Volume Up Button


REAR PANEL



1. Wall Mount Screw Holes
2. AC IN Socket
3. HDMI Port (ARC IN)
4. USB Port
5. Optical Port
6. AUX Port (LINE IN)


Placement

Placing on a TV stand




Mounting on a Wall


1. Drill two holes (about 6mm in diameter) on the wall. Insert the two anchors into the drilled holes, then insert the two screws into the holes and tighten.



2. Take care to leave 4mm between the screw heads and wall.



3. Hang your Soundcore Infini 2 on the wall.




Connecting


There are 3 ways to connect your Soundcore Infini 2 to a TV or other devices.

Option 1: Connect to TV via Bluetooth

1. Press and hold the Bluetooth button for 2 seconds to enter Bluetooth pairing mode.
2. Turn on the Bluetooth of your TV, and select "Soundcore Infini 2" on the Bluetooth list to connect.




Option 2: Connect to TV via HDMI Cable or Optical Cable(Not Included)




TIP: The optical port cannot be used when a TV is connected to the soundbar via HDMI port.






Option 3

- Connect to Other Devices via AUX Cable or USB Port




Using Your Soundcore Infini 2



	Press to power on or switch to standby
	Press to switch between optical, HDMI ARC, Bluetooth, LINE IN, and USB mode in order
	Press to enter Bluetooth pairing mode
	Volume down
	Volume up

- The soundbar will automatically switch to standby mode when no audio input is received for 20 minutes.
- The soundbar will wake up from standby mode when any button is pressed or source input is received.














LED Light Guide




Standby mode	Solid red
LINE IN mode	Solid green for 10s, then fades out
Bluetooth connected	Solid blue for 10s, then fades out
Bluetooth pairing	Slow blue blinking
Optical mode	Solid yellow for 10s, then fades out
USB mode	Solid cyan for 10s, then fades out
HDMI ARC mode	Solid purple for 10s, then fades out

Remote Control

- Insert the batteries into the remote control. Point the remote control at the remote sensor on the front panel.
- The remote control works within a distance of about 26 ft / 8 m from the sensor and within an angle of about 30 degrees from the left and right sides.

		Standby Button	Press to activate the soundbar or switch to standby
		Mute Button	Mute or unmute
		Volume Up Button	Increase volume
		Volume Down Button	Decrease volume
		Previous	Return to the previous track
		Next	Skip to the next track
		Play / Pause	Pause/Resume playback
		Bluetooth button	Activate Bluetooth pairing mode
		Source Input Button	Press to switch between optical, HDMI ARC, Bluetooth, LINE IN, and USB mode in order
		Movie Mode (Default)	Intensify the bass and enhance the clarity of dialogue
		Music Mode	Enhance the treble and add greater depth to the music
		News Mode	Make the human voice more clear and outstanding for listening

Reset



- If the soundbar isn't working correctly, press and hold the Source Input Button and Volume Up Button on the soundbar simultaneously for more than 8 seconds to reset it.

Firmware Update

- To get the best features and support, update your soundbar with the latest firmware via the USB port.
- <https://support.soundcore.com/s/>

Specifications

Specifications are subject to change without notice.

Input	100-240V~ 50/60Hz 0.5A
Audio output	120.0W
Input port	HDMI ARC × 1 AUX IN (3.5mm stereo mini) × 1 Optical In × 1 USB A × 1
Bluetooth	Version 5.3
Product size	880×64×98mm
Weight (without packaging)	2.18kg

Customer Service


18-month limited warranty

Our warranty is additional to the legal rights consumers have buying this product.

- service@soundcore.com
- support.mea@soundcore.com (For Middle East and Africa Only)
- support@anker.com
- +1 (800) 988 7973 (US) Mon-Fri 6:15AM – 5:00PM (PT)
- +44 (0) 1604 936200 (UK) Mon-Fri 6:00-17:00 Sat-Sun 6:00-14:00
- +49 (0) 69 9579 7960 (DE) Mon-Fri 6:00 – 11:00 Uhr

For FAQs and more information, please visit: soundcore.com/support

Documents / Resources

	Soundcore AK-A3371211 Infini 2.1 Channel Sound Bar [pdf] User Manual AK-A3371211, Infini 2.1 Channel Sound Bar, AK-A3371211 Infini 2.1 Channel Sound Bar
---	---

References

- [🔊 Soundcore EN](#)
- [⚡ Anker \(\) Japan – Anker Japan](#)
- [🔊 Soundcore EN](#)

