




soundcore Motion + Bluetooth Speaker User Guide


[Home](#) » [Soundcore](#) » soundcore Motion + Bluetooth Speaker User Guide

Soundcore Motion + Bluetooth Speaker User Guide






1





2






3




4




AUX


5



6



TWS



Download the Soundcore App



Customer Service



18-month limited warranty



Lifetime technical support



service@soundcore.com



+1 (800)988 7973 (US) Mon-Fir 9:00 – 17:00 (PT)
+44 (0) 1604 936200 (UK) Mon-Fir 6:00-11:00 (GMT)
+49 (0) 69 9579 7960 (DE) Mon-Fir 6:00-11:00

Input: DC 5V= 1A

Anker Innovations Limited

Room 1318-19, Hollywood Plaza, 610 Nathan Road, Mongkok, Kowloon, Hong Kong

For FAQs and more information, please visit :

[soundcore.com / support](https://soundcore.com/support)



Model: A3116 51005001429 V01




Contents [[hide](#)]

[1 Documents / Resources](#)

[2 Related Posts](#)

Documents / Resources



[soundcore Motion + Bluetooth Speaker](#) [pdf] User Guide
Motion Bluetooth Speaker