

SoundCore Icon Portable Speaker A3122 User Manual

Home » Support » SoundCore Icon Portable Speaker A3122 User Manual



Contents

- 1 SoundCore Icon Portable Speaker A3122
- 2 Safety Instructions
- 3 What's Included
- 4 At a Glance
- **5 Using Your Soundcore Icon** 5.1 1. Turn On / Off
- **6 Charging your Soundcore Icon**
- **7 Specifications**
- **8 DOWNLOAD**
- 9 Related Posts

SoundCore Icon Portable Speaker A3122




USER MANUAL

Safety Instructions

- Avoid dropping.
- Do not disassemble.
- Soundcore Icon can be immersed in water up to 1m for up to 30 minutes.
- Avoid extreme temperatures.
- Do not use the device outdoors during thunderstorms.
- Do not use any corrosive cleaner / oil to clean.

What's Included











At a Glance



- 1. Power Indicator
- 2. Power Button
- 3. Volume Button
- 4. Multi-function Button
- 5. Volume + Button
- 6. Bluetooth Button
- 7. Bluetooth Indicator
- 8. Carry-handle
- 9. 3.5mm Audio Input Port
- 10. Micro USB Port

Using Your Soundcore Icon


1. Turn On / Off



ON Press


OFF Press and hold for more than 2 seconds

a. Bluetooth mode



- Flashing Blue Bluetooth Pairing Mode


○ Solid Blue Connected to a device



≯ [⊙3s	Enter True Wireless Stereo Group Mode / Disconnect True Wireless Stereo	
-़ं-	Flashing White	True Wireless Stereo Group Mode
0	Solid White	Connected to True Wireless Stereo Note: When True Wireless Stereo group is successful, the LED indicator on the first speaker will flash in blue, the LED indicator on the second speaker will be solid blue.

NOTE:


With True Wireless Stereo technology, you can pair your Soundcore Icon with another Soundcore Icon to explore the best sound effects with left and right sound channels separated on both speakers.



NOTE:

- When turned on, Soundcore Icon will automatically connect to the last connected device if available. If not, press the Bluetooth pairing button to activate pairing mode.
- To pair a different device, press the Bluetooth button to re-enter pairing mode. Then repeat the pairing steps.
- Having connection problems? Remove Soundcore Icon from your device's Bluetooth history and ensure it's
 less than 3 feet away. Then try pairing again. To get the best sound quality, make sure there is a clear line of
 sight between the connected device and your speaker.

b. AUX-In mode




* SoundLine AUX cable sold separately.

NOTE:

Plugging in an audio cable will automatically switch to AUX mode. When using AUX mode, control audio playback via the connected device.

Charging your Soundcore Icon



-ф-	Slow Flashing Red	Low Battery
	Solid Red	Charging
Off		Fully Charged

NOTE:

Use the included USB cable to charge your Soundcore Icon and make sure it is fully charged before its first use. Disconnect your speaker from the charger when fully charged. Do not charge your speaker for extended periods. When not in use, store your speaker in a cool place.

Specifications

Input:	5 V 1 A
Audio output:	10 W
Battery capacity:	max. 2600 mAh
Charging time:	4.0 hours
Playtime (varies by volume level and music content):	12hrs
Size:	182 x 61 x 62 mm / 7.2 x 2.4 x 2.4 inch
Weight (without packaging):	349 g / 12.3 oz
Bluetooth version:	V5.0
Bluetooth range:	20 m / 66 ft

DOWNLOAD

SoundCore Icon Portable Speaker A3122 User Manual – [Download PDF]

SoundCore Icon Portable Speaker A3122 QSG – [Download PDF]

Manuals+,