



SoundCore Mini 2 Portable Speaker A3107 User Manual

[Home](#) » [Support](#) » SoundCore Mini 2 Portable Speaker A3107 User Manual 

Contents


- [1 SoundCore Mini 2 Portable Speaker A3107](#)
- [2 Safety Instructions](#)
- [3 At a Glance](#)
- [4 Using Your Sound core mini 2](#)
 - [4.1 1. Turn on/ off](#)
- [5 Charge your Soundcore mini 2](#)
- [6 Specifications](#)
- [7 Declaration of Conformity](#)
- [8 Customer Service](#)
- [9 DOWNLOAD](#)
- [10 Related Posts](#)

SoundCore Mini 2 Portable Speaker A3107




USER MANUAL

Safety Instructions




At a Glance




1. Battery indicator
2. Power switch
3. Volume -/+
4. Multi-function button
5. Bluetooth pairing button
6. Status indicator
7. Microphone
8. Micro USB charging port
9. 3.5mm Aux input

Using Your Sound core mini 2

1. Turn on/ off




a. Bluetooth mode



	Flashing blue	Pairing mode
	Steady blue	Connected to a device
		Bluetooth pairing mode
	Flashing white	True Wireless Stereo pairing mode
	Steady white	Connected to True Wireless Stereo

Enter True Wireless Stereo pairing mode/ Disconnect True Wireless Stereo



NOTE: With True Wireless Stereo technology, you can connect your Soundcore mini 2 to another Soundcore mini 2 and explore the best sound effects with left and right sound channels separated on different Bluetooth !

 x1	Play / pause
	Volume up / down
 x2	Next track
 x1	Answer / End call / Put current call on hold and answer incoming call / Switch between held call and active call
 @2s	Reject call / Transfer a call between speaker and mobile phone
 @2s	Activate Siri / other voice control software


 Steady blue On a call

 Flashing blue Incoming call

NOTE:

- When turned on, Soundcore mini 2 will automatically connect to the last connected device if available. If not, press Bluetooth button to activate the pairing mode.
- Having connection problems? Remove Soundcore mini 2 from your device's Bluetooth history, ensure it's less than 3 feet away then try pairing again.
- To get the best sound quality, make sure there is a clear line of sight between the connected device and your speaker.

b. AUX-In mode




 Volume up / down

- Sound Line AUX cable sold separately.

Plugging in an audio cable will automatically switch to Aux mode.
When using AUX mode, control audio playback via the connected device.

Charge your Soundcore mini 2



Flashing red

Low power



Steady red

Charging

Off

Fully charged

Use the included USB cable to charge your Soundcore mini 2 and make sure it is fully charged before first use. : !
Disconnect your speaker from charger when fully charged. Do not charge your speaker for extended periods.

When not in use, store your speaker in a cool place.

Specifications

Specifications are subject to change without notice.

- Input: 5V=1A
- Audio output: 6 W
- Battery capacity: 1850 mAh
- Charging time: 2-3 hours
- Playtime (varies by volume level and content): 15 hours
- Size: 69.5 x 69.5 x 80 mm / 2.7 x 2.7 x 3.1 in
- Weight (without packaging): 207g / 7.3 oz
- Bluetooth version: V 4.2 + EDR
- Range: 20 m / 66 ft

Declaration of Conformity

Hereby, Anker Innovations Limited declares that the radio equipment type A3107 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:
www.soundcore.com.

Maximum output power: 4.0dBm

Frequency band: 2.4G band (2.4000GHz-2.4835GHz)

Anker Innovations Limited

Room 1318-19, Hollywood Plaza, 610 Nathan Road, Mongkok, Kowloon, Hongkong

Customer Service

service@soundcore.com

+ 1 (800) 988 7973 (US) Mon-Fri 9:00- 17:00 (PT)

+44 (0) 1604 936200 (UK) Mon-Fri 6:00- 11:00 (GMT)

+49 (0) 69 9579 7960 (DE) Mon-Fri 6:00- 11:00

+81034455 7823 | B:\$:) ,El -,1,9:00-11:00

+86 400 0550 036 | '1'00 | f.'il-'l'f.'illi 9:00- 17:30

For FAQs and more information, please visit :

soundcore.com/support

DOWNLOAD

SoundCore Mini 2 Portable Speaker A3107 User Manual – [[Download PDF](#)]
