



## soundmaster AD6SW Connection to older Android device to Micro-USB User Manual

[Home](#) » [soundmaster](#) » soundmaster AD6SW Connection to older Android device to Micro-USB User Manual 



Competence in electronics since 1968  
AD6SW Connection to older Android device to Micro-USB  
User Manual

### Contents

- [1 AD6SW Connection to older Android device to Micro-USB](#)
- [2 USB-C is always RIGHT WAY!](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)


### AD6SW Connection to older Android device to Micro-USB

Art-Nº AD6SW – Connection to an iPhone

**Right !**




**Wrong !**




Art-Nº AD6SW – Connection to a USB-device

**Right !**



**Wrong !**



Art-Nº AD6SW – Connection to newer Android device, or other devices to USB-C

**USB-C is always RIGHT WAY!**



You can't do anything wrong with USB-C no matter how around, it is always "right" around.



**Art-Nº AD6SW – Connection to older Android device to Micro-USB**

# Right!




# Wrong!



weitere Infos unter [www.soundmaster.de](http://www.soundmaster.de)

## Documents / Resources

	<p><a href="#">soundmaster AD6SW Connection to older Android device to Micro-USB</a> [pdf] User Manual AD6SW, Connection to older Android device to Micro-USB, AD6SW Connection to older Android device to Micro-USB</p>
------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

[Manuals+.](#)