



SOUNDMAX SM-PS5067B Portable Audio System with Bluetooth Instruction Manual

[Home](#) » [SOUNDMAX](#) » SOUNDMAX SM-PS5067B Portable Audio System with Bluetooth Instruction Manual 

Contents

- [1 SOUNDMAX SM-PS5067B Portable Audio System with Bluetooth](#)
- [2 Product Information](#)
- [3 Description Overview](#)
- [4 Specifications](#)
- [5 Description](#)
- [6 Connection diagram](#)
- [7 Important safeguards](#)
- [8 Maintenance and care](#)
- [9 Accessories](#)
- [10 Specifications](#)
- [11 QR SCAN](#)
- [12 Documents / Resources](#)
- [13 Related Posts](#)

SOUNDMAX

SOUNDMAX SM-PS5067B Portable Audio System with Bluetooth



Product Information

- **Product Name:** Portable Audio System with Bluetooth
- **Model Number:** SM-PS5067B

Description Overview

The Portable Audio System with Bluetooth (model SM-PS5067B) is a versatile audio device that allows you to enjoy music and connect external devices for a seamless audio experience. It features various input options, including Bluetooth connectivity, TF (microSD) card slot, USB port, AUX input, and microphone input. The LED display provides clear visual feedback, and the volume knob allows you to adjust the audio output easily. The system also supports TWS (True Wireless Stereo) function and has EQ and ECHO control buttons. Additionally, it comes with an RGB light feature, FM radio capability, and a built-in li-ion battery for portable use.

Specifications

- **Output Power:** 45 W
- **Nominal Power Consumption:** 5 W
- **Voltage Input:** AC 220V/50-60Hz
- **Voltage Output:** DC 5V/1.0A
- **FM Radio Frequency Range:** 87.5 – 108 MHz
- **Battery Type:** Li-ion, 3.7V, 3000 mAh
- **Music Playtime:** Up to 10 hours*
- **Net Weight:** 1.85 kg
- **Unit Dimensions:** 368(L) * 135(W) * 195(H) mm


The built-in battery life is approximate and may vary depending on usage conditions.

Dear customer!|

Thank you for purchasing our product. For safety, it is strongly recommended to read this manual carefully before connecting, operating and/or adjusting the product and keep the manual for reference in future.


Description

Overview



1. Power ON/OFF switch
2. DC 5V USB Type-C charging port
3. Charging indicator
4. TF (microSD) card slot
5. LED display
6. USB port
7. AUX input 3.5mm mini jack
8. Microphone input 6.35mm jack
9. Volume knob
10. (PREVIOUS) button
11. (PLAY/PAUSE)/SCAN button
12. MODE button
13. (NEXT) button
14. TWS button
15. EQ button
16. ECHO- button
17. REC/DEL button
18. (LIGHT) button
19. ECHO+ button
20. Microphone volume knob

Connection diagram



Important safeguards

- The instruction manual contains important operating and maintenance instructions. For your safety, it is necessary to refer to the manual. Keep the manual for future use.
- Do not hit or drop the unit.
- Do not expose the unit to vibration, direct sunlight, too high or low temperatures or humidity.
- Do not disassemble the unit yourselves. Refer servicing to qualified service personnel.
- Insert the charging cable into the DC IN socket on the unit.
- Connect the charging cable to the power adapter (not included). Plug the adapter to the power source.
- The battery charging indicator will light up in red when charging and switch to blue when the battery is fully charged.
- For best results, try to fully charge the battery before each use. If the battery is drained, please allow it to recharge for a few hours.
- Put the power switch to the ON position to switch the unit on. Put it into the OFF position to switch off.

All the illustrations in this manual are schematic images, which may differ from actual objects.

Power supply



- The unit operates on an internal rechargeable Li-ion battery and 220V mains via a DC adapter (not included).
- The battery can be recharged with the provided USB charging cable. Before first plugging the appliance check that voltage indicated on the rating label corresponds to the mains voltage in your home.

General operations



Bluetooth wireless playback

- This unit can wirelessly playback audio from any device with Bluetooth A2DP function.
- The wireless range is approximately within 10 meters in direct line of sight.
- Wireless audio streaming requires pairing of a Bluetooth device (e.g. smartphone).

HOW TO PAIR YOUR DEVICE TO THIS UNIT:

- Make sure the Bluetooth function is switched on in your device (e.g. smartphone, tablet).
- Switch on the unit and press the MODE button repeatedly to select the Bluetooth mode (selected by default).
- Once the Bluetooth function is selected, you will find the unit listed in the Bluetooth connections list of your device (as SM-PS5067B).
- If asked for a passcode, enter "0000".
- The initial setup is required only once per device. The unit will automatically pair to the last paired device.
- When playing files, you can press the Play/Pause button to pause and resume playback.
- Press the  or  button to go to a previous or next track. Rotate the volume knob to adjust volume

External device connection

- You can connect the audio output of an external device to this unit, to listen to the audio playback of that device through the speaker.
- To connect an external audio device, please use an AUX audio cable with 3.5mm to 3.5 mm plugs (not included) to connect the headphone out or audio line-out of the external device to the AUX input of this unit.
- Press MODE to select the AUX mode.
- Turn on the external device. You can press the  or  to select a previous or a next track. Rotate the volume knob to adjust volume




Equalizer

- In USB/TF/AUX/Bluetooth modes press the EQ button to switch among 6 equalizer presets.


USB/TF operation

Playback


Turn on the device.

- Insert a USB drive into the USB port or a TF card into the TF slot. Press MODE to select the USB/TF mode.
- When playing, you can press Play/Pause to play/pause the playback.
- During the playback you can press the  or  button to go to a previous or next track. Rotate the volume knob to adjust volume.
-  It may take up to 60 seconds to open and verify a large USB drive/TF card with many files.



General USB/TF notes

- This unit is equipped with a USB port that can read and play MP3 files stored on standard USB drives and TF cards with capacity up to 32 GB.
- FAT and FAT32 file system is supported by this unit.
-  Never remove USB drives or TF cards from the unit during playback, always stop playback, then press the MODE button to switch to another mode before removing the storage to prevent damage to your files and drives themselves.

TWS function

- If you have two units at your disposal, you can pair them to each other and enable the True Wireless Stereo (TWS) sound.
- Turn the both units on and switch them into the Bluetooth mode. Press the TWS button on any of the units. Make sure the other unit is not paired to any bluetooth devices. The units are paired successfully. To unpair, press and hold TWS on any of the units.
-  TWS works only in Bluetooth mode and only in featured models.


FM radio

- Turn on the device.
- Press the MODE button repeatedly to select the FM mode.
- Press and hold Play/Pause to automatically scan and save all available radio stations. The procedure will take several minutes and cannot be interrupted.
- Once the search is finished, you can press the  or  button to go to a previous or a next saved station. Rotate the volume knob to adjust volume.

Microphone

- You can connect the microphone for karaoke or other purposes into this unit by connecting it to the 6.35mm microphone input jack. Please do not plug the microphone when the unit is charging.
- While connected, you can control the microphone volume by rotating the MIC knob, and echo effect by pressing the corresponding ECHO-/ + buttons on the top panel
- Press the REC/DEL button to enable recording with the microphone. During the recording, the echo effect should be set to the minimum. Press and hold REC/DEL to delete the recorded file. USB adapter (not included): Voltage input: AC 220V/50-60Hz Voltage output: 5V \geq 1.0A Music playtime

RGB Light

Press the  button repeatedly to switch among three RGB light modes or switch it off.

Maintenance and care

Switch off the unit, unplug from the power supply. The outside of the appliance can be cleaned with a slightly damp cloth.

Accessories

- **Audio system:** 1 pc
- **USB Type C cable:** 1 pc
- **Wired microphone:** 1 pc
- **Carrying strap:** 1 pc
- **Instruction manual:** 1 pc

Specifications

Output power	45 W
USB adapter (not included):	Voltage input: AC 220V/50-60Hz
	Voltage output: 5V ≥1.0A
Nominal power consumption	5 W
FM radio	87.5 – 108 MHz
Battery power supply	Li-ion, 3.7V, 3000 mAh
Music playtime	up to 10 hours*
Net weight	1.85 kg
Unit dimensions	368(L) * 135(W) * 195(H) mm


QR SCAN



The built-in battery life is approximate, depending on the conditions and nature of use (number of recharge cycles of the built-in battery, environmental conditions, use of lighting effects, sound volume level, playback source, type of content being played). Specifications and functions are subject to change without notice. It is connected with continuous improvement of the device.

MANUFACTURED AND DISTRIBUTED BY TECHNO ELECTRIC LIMITED,
Legal address: 801 Luk Yu Building, 24 – 26 Stanley Street, Central, China

Documents / Resources

 <p>PORTABLE AUDIO SYSTEM WITH BLUETOOTH ПОРТАТИВНА АУДИОСИСТЕМА С BLUETOOTH</p> <p>SM-PS5067B</p> <p>Instruction manual Инструкція по використанню</p>	SOUNDMAX SM-PS5067B Portable Audio System with Bluetooth [pdf] Instruction Manual SM-PS5067B Portable Audio System with Bluetooth, SM-PS5067B, Portable Audio System with Bluetooth, System with Bluetooth
--	---