



SOUNDMAX SM-PS5081B Portable Audio System with Bluetooth Instruction Manual

[Home](#) » [SOUNDMAX](#) » SOUNDMAX SM-PS5081B Portable Audio System with Bluetooth Instruction Manual 

SOUNDMAX SM-PS5081B Portable Audio System with Bluetooth



Dear customer!

Thank you for purchasing our product. For safety, it is strongly recommended to read this manual carefully before connecting, operating and/or adjusting the product and keep the manual for reference in future.

Contents

1 Description

1.1 Overview

2 Connection diagram

3 Important safeguards

4 Power supply

5 General operations

5.1 Bluetooth wireless playback

5.2 External device connection

6 USB operation

6.1 Playback

6.2 General USB notes

7 TWS function

8 FM radio

9 RGB Light


10 Specifications

11 Documents / Resources

12 Related Posts

Description


Overview



1. Backward/Volume Down
2. Forward/Volume Up
3. RGB Light
4. Play/Pause
5. Mode Button
6. TWS Button
7. Power On/Off
8. MIC Port
9. USB Port

10. AUX Port
11. Type-C Charging Port
12. Reset Button

Connection diagram



Important safeguards

- The instruction manual contains important operating and maintenance instructions. For your safety, it is necessary to refer to the manual. Keep the manual for future use.
- Do not hit or drop the unit.
- Do not expose the unit to vibration, direct sunlight, too high or low temperatures or humidity.
- Do not disassemble the unit yourselves. Refer servicing to qualified service personnel.

All the illustrations in this manual are schematic images, which may differ from actual objects.

Power supply

- The unit operates on an internal rechargeable Li-ion battery and 220V mains via a DC adapter (not included).
- The battery can be recharged with the provided USB charging cable. Before first plugging the appliance check that voltage indicated on the rating label corresponds to the mains voltage in your home.
- Insert the charging cable into the DC IN socket on the unit.
- Connect the charging cable to the power dapter (not included). Plug the adapter to the power source.
- For best results, try to fully charge the battery before each use. If the battery is drained, please allow it to recharge for a few hours.
- Press and hold the power button to switch the unit on. Press and hold it again to switch off.

General operations

Bluetooth wireless playback

- This unit can wirelessly playback audio from any device with Bluetooth A2DP function.

- The wireless range is approximately within 10 meters in direct line of sight.
- Wireless audio streaming requires pairing of a Bluetooth device (e.g. smartphone).

HOW TO PAIR YOUR DEVICE TO THIS UNIT:

- Make sure the Bluetooth function is switched on in your device (e.g. smartphone, tablet).
- Switch on the unit and press the M button repeatedly to select the Bluetooth mode (selected by default).
- Once the Bluetooth pairing indicator begins flashing, you will find the unit listed in the Bluetooth connections list of your device (as SM-PS5081B).
- If asked for a passcode, enter "0000".
- The initial setup is required only once per device. The unit will automatically pair to the last paired device.
- The LED indicator will flash when searching for a Bluetooth device and stay on when the devices are paired.
- When playing files, you can press the Play/Pause button to pause and resume playback.
- Press and hold the – or + button to go to a previous or next track. Shortly press these buttons to decrease or increase volume, respectively.

External device connection

- You can connect the audio output of an external device to this unit, to listen to the audio playback of that device through the speaker.
- To connect an external audio device, please use an AUX audio cable with 3.5mm to 3.5 mm plugs to connect the headphone out or audio line-out of the external device to the AUX input of this unit.
- The AUX mode will be selected automatically.
- Turn on the external device. You can press the – and + to adjust the volume level.



Slight noise during playback pauses is not a construction defect, it is determined by the factory presets of the dynamic noise reduction system.

USB operation

Playback

- Turn on the device.
- Insert a USB drive into the USB port

The playback mode will be selected automatically.

- When playing, you can press Play/Pause to play/pause the playback.
- During the playback you can press and hold the – or + button to go to a previous or next track. Shortly press these buttons to decrease or increase volume, respectively.



It may take up to 60 seconds to open and verify a large USB drive with many files.

General USB notes

- This unit is equipped with a USB port that can read and play MP3, WAV, WMA, FLAC, AMR files stored on standard USB drives up to 32 GB.
- FAT and FAT32 file system is supported by this unit.

Never remove USB drives from the unit during playback, always stop playback, then press the **M** button to switch to another mode before removing the storage to prevent damage to your files and drives themselves.

TWS function

- If you have two units at your disposal, you can pair them to each other and enable the True Wireless (TWS) stereo sound.
- Turn the both units on and switch them into the Bluetooth mode. Press the TWS button on any of the units. Make sure the other unit is not paired to any bluetooth devices. The TWS button will light up, indicating that the units are paired successfully.




TWS works only in Bluetooth mode and only in featured models.

FM radio

- Turn on the device.
- Press the M button repeatedly to select the FM mode
- Press and hold Play/Pause to automatically scan and save all available radio stations. The procedure will take several minutes and cannot be interrupted.
- Once the search is finished, you can press and hold the **– or +** button to go to a previous or next saved station. Shortly press these buttons to decrease or increase volume, respectively.

RGB Light

Press the  button repeatedly to switch among four RGB light modes or switch it off.

Specifications

Peak music power output	30 W
Input voltage	5V 1A
Nominal power consumption	5 W
FM radio	87.5 – 108 MHz
Battery power supply; Mains power supply	Li-ion, 3.7V, 3000 mAh; AC 220V
Net weight	1.96 kg
Unit dimensions	360(L) * 135(W) * 155(H) mm


Specifications and functions are subject to change without notice. It is connected with continual improvement of the device.

MANUFACTURED AND DISTRIBUTED BY TECHNO ELECTRIC LIMITED, Legal address: 801 Luk Yu Building, 24 – 26 Stanley Street, Central, China



SOUNDMAX

Documents / Resources

 <p>SOUNDMAX</p> <p>PORTABLE AUDIO SYSTEM WITH BLUETOOTH ПОРТАТИВНАЯ АУДИОСИСТЕМА С БЛУETOOTH</p> <p>SM-PS5081B</p> <p>Instruction manual Руководство по эксплуатации</p>	<p>SOUNDMAX SM-PS5081B Portable Audio System with Bluetooth [pdf] Instruction Manual SM-PS5081B Portable Audio System with Bluetooth, SM-PS5081B, Portable Audio System with Bluetooth, Portable Audio System, Audio System</p>
--	---