

SP CONNECT MAN062 Universal Interface Instructions

Home » SP CONNECT » SP CONNECT MAN062 Universal Interface Instructions

Contents

- 1 SP CONNECT MAN062 Universal Interface
- **2 Product Information**
- 3 Specifications
- 4 FAQ
- **5 Assembly Instructions**
- 6 Documents / Resources
 - **6.1 References**



SP CONNECT MAN062 Universal Interface



Product Information

- There are two versions of the mount: v1a and v1b. Choose the appropriate version for your setup.
- For v1a and v1b, use the M5x16 screw and tighten it to 3 Nm.
- For v2, use the M5x20 screw and tighten it to 3 Nm.
- Insert the appropriate adapter ring into the mount.
- Available sizes:
- Optional components can be added as needed.
- Attach the mount to the handlebar and tighten it to 3 Nm.
- Ensure the mount is securely fastened.

Specifications


Component	Specification
Screw	M5x16 or M5x20
Tightening Torque	3 Nm
Adapter Ring Sizes	Ø 1.25", Ø 1.125", Ø 1.063", Ø 1.000", Ø 0.875"

FAQ

- What is the correct torque for tightening the screws?
 - The screws should be tightened to 3 Nm.

- · What are the available adapter ring sizes?
 - The available sizes are Ø 1.25", Ø 1.125", Ø 1.063", Ø 1.000", and Ø 0.875".
- · Can I add optional components?
 - Yes, optional components can be added as needed.

Assembly Instructions



For More Information: www.sp-connect.com

Documents / Resources



SP CONNECT MAN062 Universal Interface [pdf] Instructions MAN062 Universal Interface, MAN062, Universal Interface, Interface

References

• User Manual

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.