Home » SPACES PLUS » SPACES PLUS A23 RF Remote Control Instructions

# **SPACES PLUS A23 RF Remote Control Instructions**

#### Contents

- 1 SPACES PLUS A23 RF Remote
- Control
- 2 Specifications
- 3 Battery Installation
- **4 Operating the Lamp**
- 5 FAQs
- 6 Documents / Resources
  - **6.1 References**
- **7 Related Posts**

# **SPACES PLUS**

#### **SPACES PLUS A23 RF Remote Control**

# **Specifications**


- Model: Remoto
- Battery: A23 (not included)
- Lighting Modes: Middle, High, Low, Boost

## **Battery Installation**

- 1. Open the battery compartment.
- 2. Insert one A23 battery (not included) into the compartment.

# **Operating the Lamp**

To operate the lamp and adjust brightness levels, follow these steps:



- 1. Press the button on the lamp.
- 2. Toggle through the following lighting modes:
  - Middle lighting: Press once for middle brightness.
  - High lighting: Press again for high brightness.
  - Low lighting: Press once more for low brightness.
  - Boost: Press to activate boost mode.

#### **FCC WARNING**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

**Note**: This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC

Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and usedbyh the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Note**: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be colocated or conjunction with any other antenna or transmitter.

## Q: What type of battery does the Remoto lamp use?

A: The Remoto lamp uses an A23 battery, which is not included in the package. Please ensure you have this type of battery before use.

## Q: How do I change the brightness levels of the lamp?

A: You can adjust the brightness levels by pressing the button on the lamp to cycle through middle, high, low, and boost modes.

#### **Documents / Resources**



<u>SPACES PLUS A23 RF Remote Control</u> [pdf] Instructions A23, A23 RF Remote Control, RF Remote Control, Remote Control

#### References

User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.