



Sparwan PDA-GS0533W Terminal Mobile Android User Manual

[Home](#) » [Sparwan](#) » Sparwan PDA-GS0533W Terminal Mobile Android User Manual 

Contents

- 1 Sparwan PDA-GS0533W Terminal Mobile Android
- 2 Product Information
- 3 Product Usage Instructions
- 4 Key buttons Instruction
- 5 Status Icon
- 6 Apps & Notifications
- 7 Home page management
- 8 Wireless and network
- 9 Security & Location
- 10 About Phone
- 11 USB connection
- 12 Maintenance and Layup
- 13 Safety Information
- 14 Environmental Safety
- 15 System Update Security
- 16 Documents / Resources
 - 16.1 References



Sparwan PDA-GS0533W Terminal Mobile Android



Product Information

• Specifications:

- **Power button:** Long press to turn on the device. Press 1 second to lock/unlock the interface. Long press 10 seconds to force shutdown. Press 2 seconds to restart and take a screenshot.
- **Volume button:** Press up/down to adjust media, call, and notifications volume. Go to settings to adjust the ring and alarm volume.
- **Barcode scanning button:** Long press any of the scanning buttons for 3 seconds to activate the scanner. Short press to scan codes.
- **Physical buttons:** F1 (long press to open Google search, short press to open settings), F2 (long press to view current items, short press to open camera), Home button (short press to go back to home screen).
- **Combination key:** Press the volume down key and the power key at the same time for two seconds to take a screenshot.
- **Touch buttons:** From right to left – Recent Apps button, Home screen button, Return button.
- **SIM card and TF card installation:** Turn off the device before installing or removing SIM cards or TF cards. Slide the switch to the right to unlock the battery cover, remove the battery, and insert the SIM card in the indicated direction. SIM card type is a Micro SIM card. Both SIM 1 and SIM 2 support 4G LTE. After inserting the SIM card, close the battery cover and slide the switch to the left to lock it.
- **Status Icons:** E (GSM), 3G (WCDMA), 4G (4G LTE), Call forwarding, Missed call, New SMS or MMS, Alarm Clock, Vibration mode, Bluetooth, Connect to PC, Connected earphone, Notification, Play music, Connected WLAN, Calling out, Airplane mode, Silent, Battery capacity, Barcode reader on charging.
- **Apps & Notifications:** Tap and slide up from the homepage to find all related apps. Tap the return icon at the bottom of the screen to return to the homepage. In Settings, go to Apps & Notifications to check recently opened apps and default apps. Set up app permissions like location, microphone, camera, etc.
- **Notifications:** Notifications include new messages, calendar events, or ongoing events like caller diverting or calling status. Open notifications to check phone operator or open message, reminder, or events notifications. To interact with a notification, tap it to open the related app. Slide it down and tap and press the bottom to slide up and shut down the notification.
- **Unknown sources:** In Settings, go to Apps & Notifications -> Special app access -> Install unknown apps to allow or disallow downloading applications from non-electric markets. Be cautious as allowing unknown sources may make your phone and personal data vulnerable to attacks from unknown

applications.

Product Usage Instructions

• Power Button

- Long press the Power button to turn on the device. It will take some time to finish initial settings like language, time zone, and wifi.
- In any interface, press the power button for 1 second to lock or unlock the interface. Long press the power button for 10 seconds to force shutdown. Press the power button for 2 seconds to find restart and take a screenshot.

• Volume Button

- Press the volume up/down buttons to adjust the media, call, and notification volume. To adjust the ringtone and alarm volume, go to Settings.

• Barcode Scanning Button

- There are 2 barcode scanning buttons on the left and right sides of the device, indicated by the orange colour.
- When the scanner is off, long press any of the scanning buttons for 3 seconds to activate the scanner.
- Short press the scanning button to scan codes. Before scanning, open a dialogue box and put it in the typing status to view the code information in the dialogue box.

• Physical Buttons

- F1: Long press to open Google search, short press to open settings.
- F2: Long press to view current items, short press to open the camera.
- Home button: Short press to go back to the home screen.

• Combination Key

- Press the volume down key and the power key at the same time for two seconds to take a screenshot.

• Touch Buttons

- Recent Apps button: Press this icon to see the most recently used applications.
- Home screen button: Press to go back to the home screen.
- Return Back button: Press to go back to the last interface or exit the current program.

• SIM Card and TF Card Installation

- Before installing or removing SIM cards or TF cards, turn off the device. Slide the switch to the right to unlock the battery cover, remove the battery, and insert the SIM card in the indicated direction (Micro SIM card type). Both SIM 1 and SIM 2 support 4G LTE.
- After inserting the SIM card, close the battery cover and slide the switch to the left to lock it.

• Status Icons

- E: GSM, 3G: WCDMA, 4G: 4G LTE, Call forwarding, Missed call, New SMS or MMS, Alarm Clock, Vibration mode, Bluetooth, Connect to PC, Connected earphone, Notification, Play music, Connected WLAN, Calling out, Airplane mode, Silent, Battery capacity, Barcode reader on charging.

• Apps & Notifications

- When on the homepage, tap and slide up to find all related apps. Tap the return icon at the bottom of the screen to return to the homepage.
- In Settings, go to Apps & Notifications to check recently opened apps and default apps. Set up app permissions like location, microphone, camera, etc.

• Notifications

- Notifications include new messages, calendar events, or ongoing events like caller diverting or calling status.
- Open notifications to check phone operator or open message, reminder, or events notifications. To interact with a notification, tap it to open the related app. Slide it down and tap and press the bottom to slide up and shut down the notification.


- **Unknown Sources**

- In Settings, go to Apps & Notifications -> Special app access -> Install unknown apps to allow or disallow downloading applications from non-electric markets.
- Be cautious as allowing unknown sources may make your phone and personal data vulnerable to attacks from unknown applications.

- **FAQ (Frequently Asked Questions)**

- **Q:** How do I adjust the ringtone volume?
- **A:** Go to Settings and find the volume options. Adjust the ringtone volume from there.
- **Q:** How do I activate the barcode scanner?
- **A:** Long press any of the scanning buttons for 3 seconds to activate the scanner. Short press the scanning button to scan codes.
- **Q:** How do I take a screenshot?
- **A:** Press the volume down key and the power key at the same time for two seconds to take a screenshot.

Key buttons Instruction



Power button

Long press the Power button to turn-on the device. When turned on, it will take a little bit of your time to finish some settings like language, time zone, wifi, etc. In any interface, press the power button one second into the lock and unlock interface. Long press 10seconds power button to force shutdown, and press 2 seconds to find “restart” and “screenshot”.


Volume button

Press up/down to adjust media, call, and notification volume. To adjust the ring, alarm volume etc, go to settings.

Barcode scanning button:

There are 2 barcode scanning buttons on the left and right sides of the device which is orange. When it's off, Long press any of the scanning buttons for 3seconds to activate the scanner. Short press the scanning button to scan codes.

(Note: before scanning, you should open a dialog box and put it in the typing status the code information will show in the dialog box. Please reference the pictures as below)




Physical button from left to right

- **F1** Long press to open Google search, short press to open settings.
- **F2:** Long press to view current items, short press to open camera. If you want to change key functions, go to settings->KeyEvent
- **Home button:** Short press to go back to home screen

Combination key



















1. Press the volume down key and the power key at the same time for two seconds to complete screen shot.
2. Touch buttons (from right to left): Press this icon enter to see the most recently used application.
 - **Home screen:** back to home screen
 - **Return Back:** back to last interface or exit current program.
3. Install SIM card, TF card



- Please turn off the device before you install or take out the SIM cards or TF card.
- Please slide the switch to the right to unlock the battery cover, remove the battery and insert the SIM card in the direction indicated on the label.

- The SIM card type is a Micro SIM card.SIM1 and SIM2 both support 4G LTE.
- After inserting the SIM card, put the battery cover
- Close the battery cover and slide the switch to the left to lock the battery cover.

Status Icon

	E: GSM 3G: WCDMA 4G: 4G LTE		Notification
	Call forwarding		Play music
	Miss calling		Connected WLAN
	New SMS or MMS		Calling out
	Alarm Clock		Airplane mode
	Vibration mode		Silent
	Bluetooth		Battery capacity
	Connect to PC		Barcode reader on
	Connected earphone		Charging

Apps & Notifications

Apps

- When in homepage, tab and slide up to find all related apps. Tab return icon on the bottom of the screen to return to homepage.
- Setting->apps & notifications, check recently opened apps and default apps. Setting up app permissions like location, microphone, camera, etc.

Notifications

- Notification will include new message, Calendar events or ongoing events, such as in caller diverting or in calling status.
- You could also open notification to check phone operator or open message, reminder or events notification.

When there is a new notification.

- Below operations could be done after you slide it down to open the notification
- Tap the notification to open relating app.
- Tap and press the bottom then slide up to shut down the notification.

Unknown sources

- Setting->apps¬ifications-> special app access->install unknown apps, setting if it's allowed to download application from non-electric market.
- When your setting is allowed, your phone and personal data will be easy to be attacked by applications of unknown sources, you will be responsible for the loss because of these applications.

Home page management

Expand the homepage

- Main interface to go beyond the screen width for more spaces in which new shortcuts, widgets and more other items can be added.
- In addition, users can horizontally swipe their fingers at the homepage screen to move to the left or right of the expanded the homepage interface.
- Choosing widgets, add whichever one you want to show in the homepage, it will automatically in the blank space of homepage.
- When in homepage interface, tap and pin any app icon, to drag it to the blank space of homepage.

Move homepage interface icons:

1. Tap and hold the icon till device vibration
2. Stay still of your finger and drag the icon to the place where you want it to be on the homepage.

Remove homepage interface icons.

1. Tapping and pin the icon till device vibration
2. Stay still of your finger, drag the icon to "remove" When all the icons and widgets in the homepage been deleted, this homepage will be deleted automatically.

Wireless and network

SIM:

- Setting SIM1 or SIM 2 card turn on/off which in the menu settings Network&internet->SIM cards.
- When in dual standby mode, choose preferred carrier in settings->Network&Internet->Sim cards->preferred sim for

SIM cards application

- Please find the SIM toolkit menu in the main system to understand more information

Wi-Fi

Settings → Network&internet- Wi-Fi- turn on-> choose the Wi-Fi name and input the password to connect to Wi-Fi

Bluetooth

Settings → Connected devices → Connection preferences → Bluetooth → turn on → choose the one of available devices to pair.

More

- **Airplane mode:** there is no any service after you turn on the function.

VPN

- Add VPN in setting->Network&Internet->VPN

Hot spot & Tethering

- Allow the equipment of wireless network without through wireless router connected to each other

Wi-Fi hotspots)

- Share your mobile connection via USB sharing network
- Share phone's internet connection via Bluetooth

Mobile network

Check data usage, open or close 4G/3G service, change network mode,access point name, select a network provider in operators

- **Display:** Setting device display brightness, wallpaper, Auto Rotate Screen, sleeping mode, font size and other display function.
- **Storage:** Check SD card and relevant display information of mobile phone, can download or format SD card.
- **Battery:** Show the usage of battery capacity.
- **Apps&Notification:** Manage and delete installed applications, app permissions, set up app notifications, Check and control storage usage of running service and apps.
- **Gesture: System**→ Gestures, this is for setting up preventing ringing when press Power & Volume up together

Security & Location

- **Setting Security status**
- Security status including the screen lock and Lock screen preferences. Lock the screen with a pattern, PIN, or

password

Privacy

- Privacy are including the Location/Show Passwords/Device admin apps /Encryption and credentials/Trust agents/Screen pinning-related management.
- **Location:** setting the functions related to position positioning.

Enryption& credential:

- **Trust Agents:** Allows the application to access security credentials and other credentials. Storage and installation from a mobile phone:After clicked ,you will Install storage encryption certificates from mobile. Clear credentials: Clear all the credential store content.

Accounts

- **Add account:** You can add accounts, add the required account; Through the full synchronization, set all current account into sync. Conventional synchronous Settings to set the background data, automatic synchronization.

Backup & reset options System->Backup & reset options

- Through the factory default, remove all the data on the phone. Remove data including: account, system and application data and Settings, download should be: select the appropriate language, setting the keyboard and select the default input method.
- The application does not delete data including the current system software, SD Calvin parts, such as music or photos.

System->date&time

- setting Automatic date & time, Automatic time zone, Use 24-hour format.

Accessibility

- Adjust miscellaneous function

Printing

- Connected devices->connection preferences
- Can be printed after installation service

About Phone

System-advanced

- Can be checked Status, Legal information, Model
- Number, android version, Energy version, Kernel version, Build Number


USB connection

USB charging


- There is default charging function when you connect the device with your computer.

How to copy your file or pictures from device to your computer?

- Please connect the device with your computer by type-C cable then slip the touch screen from top to low -side then you will see the information as follow pictures.



- Please click the “USB for file transfer” you will get the following picture:



- Choosing transfer files then you will find the file or pictures in your computer.

Maintenance and Layup

User's Manual for Battery

- The rechargeable battery may serve as power source of the mobile phone. Please charge the battery when it becomes low in electricity. It is recommended to use up the battery capacity before charging for the sake of longer battery life.
- Please do not attach the battery charger to any power supply if the charger is not in service. Never attach the charger to the battery for over one week as excessive charging will shorten the battery life.
- The temperature will challenge the chargeable limit of the battery, so the battery may need to be cooled down or warmed up before charging. Charging will fail if the battery temperature is above 550C or below -200C.
- Please only use the battery for its originally-designed purpose to avoid short circuit. A short circuit will occur if the cathode and anode of the battery are connected via a conductor.
- Never use the battery if it has become damaged.
- The battery life will become shortened if the battery is placed in any extremely hot or extremely-cold environment. The mobile phone may not function properly if the battery is exposed to any extremely-hot or extremely cold environment even if the battery is fully charged.
- Do not put the battery in fire. Do not throw away any used batteries. Used batteries shall be sent to battery recycling services and disposed of following local regulations.

Mobile Phone Layup

- The following recommendations will be conducive to layup of your mobile phone:
- Please place the mobile phone and all accessories at any place away from children.
- Please keep the phone dry as liquid will corrode metallic circuit.
- Please keep the phone away from high temperature as high temperatures will shorten life of electronics, melt plastics and damage the battery.
- Do not attempt to open the phone case or disassemble the phone. Non-professional dis-assembly will potentially damage the phone.
- Do not use any detergent containing strong acid or base to clean the phone.
- Always use original accessories, violation of which will void its warranty.

Safety Information

- Always observe safety regulations to protect users and the environment when using the mobile phone.

Traffic Safety

- Unless in emergency, please do not use the mobile phone while driving if no hands-free devices for safety and free movement are attached. Make sure that you are fully concentrated to driving. Please pull up your car to a safe place before you use the phone.
- Related regulations must be observed.
- Some electronics may be affected by radio waves from transmitted by your mobile phone if no sufficient protection is made available.
- It is recommended to use the mobile phone only in vehicles with external antenna.
- Always have qualified technicians install the mobile phone onto your vehicle. Flight Safety
- Please switch off your mobile phone before boarding as mobile phones will challenge the operation of aircraft and entire cellular network.
- It is illegal to use mobile phones on the plane and violation of these safety regulations will be accused or result in network denial-of-service.

Environmental Safety

- Keep in mind to observe existing particular rules and policies at any place. Always remember to switch off your mobile phone where use of mobile phone is prohibited or may result in interference or danger.
- Use of any wireless transmitting equipment, including cellular phones, might interfere with medical device not properly protected. Please ask doctor or medical device manufacturer for advice should you have any questions in this respect.
- Your mobile phone might interfere with hearing aids, pacemakers and other medical electronics. Please follow suggestions from doctor or the manufacturer.
- Users are recommended to switch off their mobile phones at any places where explosions may occur, e.g. gas station and chemical plants. Observe related restrictions on use of wireless devices.

System Update Security

- The mobile phone is typically subject to authorized operating system updates.

- Any unauthorized operating system update might fail the updated operating system to comply with security requirements for mobile intelligent terminals, with a system information security loophole.

FCC REGULATORY STATEMENT

This device complies with part 15 of the FCC Rules. FCC ID:2AQR9-PDA-GS0533W Operation is subject to the condition that this device does not cause harmful interference

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Absorption Rate (SAR) information:

This mobile phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaging over one gram of tissue. This device was tested for typical body-worn operations with the back of the handset kept 1.0cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.0cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with

FCC RF exposure

requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.0 cm must be maintained between the user's body and the handset, including the antenna. Third-party belt clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or approved antenna.

Documents / Resources



[Sparwan PDA-GS0533W Terminal Mobile Android](#) [pdf] User Manual

PDA-GS0533W Terminal Mobile Android, PDA-GS0533W, Terminal Mobile Android, Mobile And
roid, Android

References

- [🌐 Card Nada Horvat s.p.](#)
- [User Manual](#)