

Sphere 12 Channel Receiver Instruction Manual

Home » sphere » Sphere 12 Channel Receiver Instruction Manual



Sphere 12 Channel Receiver



Contents

- 1 Initial Setup
- 2 Programming Wireless

Switches

- **3 Customer Support**
- 4 Documents / Resources
 - 4.1 References

Initial Setup



Please also ensure that your 12 channel receiver is powered up correctly. You can confirm this by switching on and off the lights inside your RV with the wireless lighting switches.

To control your 12 channel receiver Wireless Switch you do not require an active internet connection. Please follow the steps mentioned in the Programming Wireless Switches section of this document.

Programming Wireless Switches

To program wireless switches to the 12 channel receiver, please follow the below steps:

1. Unscrew the plastic housing covering the dip switches



- 2. Locate the channel or channels which you wish to program a wireless switch to.
- 3. Move the desired channel(s) dip switch position to "ON"
- 4. Press and hold the wireless switch button down for ~6 seconds until both the LED on the wireless switch and LED inside the 12 channel receiver housing flash Orange

5. Move all channel dip switches back to "OFF" position

Your wireless switch is now programmed to the selected channel(s)

Please note, the Master OFF buttons need to be programmed to all channels for full control.

To delete a wireless switch from a certain channel:

- 1. Locate the channel or channels which you wish to delete a wireless switch from.
- 2. Move the desired channel(s) dip switch position to "ON"
- 3. Press and hold the wireless switch button down for ~6 seconds until both the LED on the wireless switch and LED inside the 12 channel receiver housing flash Red
- 4. Move all channel dip switches back to "OFF" position

Your wireless switch has now been deleted from the selected channel(s)

Customer Support

More information https://www.caravansplus.com.au



Documents / Resources



<u>Sphere 12 Channel Receiver</u> [pdf] Instruction Manual 12 Channel Receiver, 12, Channel Receiver, Receiver

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.