



Contents [[hide](#)]

- 1 Spider Farmer SF-Inline-Fan-08 Mixed Flow Inline Fan
- 2 SPECIFICATION
- 3 INLINE FAN WITH SPEED CONTROLLER
- 4 OPERATING INSTRUCTIONS
- 5 INLINE FAN WITH GGS CONTROLLER KITS
- 6 SPIDER FARMER GGS CONTROLLER
- 7 HOW TO USE WITH SPIDER FARMER POWER STRIP KITS
- 8 PACKAGE INCLUDES
- 9 SAFETY PRECAUTIONS
- 10 WARRANTY
- 11 SPIDER FARMER APP
- 12 Documents / Resources
 - 12.1 References



Spider Farmer SF-Inline-Fan-08 Mixed Flow Inline Fan




SPECIFICATION

SPECIFICATION OF INLINE FAN

4 Inch/ 100 mm

- **Duct Size:** 4-Inch
- **Fan Airflow:** 205 CFM
- **Noise Level:** 26.8 dBA
- **Input Voltage:** AC 100-240V
- **Power Usage:** 27W±50/0
- **Fan Speed:** 3000 RPM
- **Frequency:** 50/60Hz
- **Operating Temperature:** 50/60HZ


INLINE FAN WITH SPEED CONTROLLER



OPERATING INSTRUCTIONS

With Speed Controller	1. Use the speed controller to adjust the fan's airflow. Turn clockwise to increase the airflow, and turn counterclockwise to decrease it.
	2. Turn the knob and listen for a sound to turn the fan ON or OFF.
With GGS Controller Kits or Power Strip Kits	1. Use the RJ12 cable connect to the GGS Controller, then use the controller to set the fan's operating time and airflow.
	2. Use the RJ12 cable or power cord connect to the Power Strip. Then you can control the inline fan through Spider Farmer APP.


INLINE FAN WITH GGS CONTROLLER KITS



NOTE:

- The GGS Light & Fan Adapter is designed for use with LED grow lights and clip fans.
- One RJ1 2 cable includes a waterproof cap, specifically designed for the GGS Temp & Humidity Sensor.

SPIDER FARMER GGS CONTROLLER




- Use the RJ12 cable to connect to the DEVI or DEV2 port on the GGS Controller, then select Blower(inline fan) in the interface.
- Use(1) to navigate through the interface. Rotate to scroll or move. Press to confirm selections.
- Press (2) to return directly to the home screen.
- Press(3) to return to the previous screen or menu.

OPERATING INSTRUCTIONS





Manual Mode	Manually Adjust Fan Speed (0%~100%). 0% turns it off.
Time Period Mode	Set the fan's start time and end time.
	Set the fan's operating speed and standby speed.
Temperature First Mode	Automatically adjust fan operation based on temperature priority.
Humidity First Mode	Automatically adjust fan operation based on humidity priority.
Standby Speed	Enable standby speed, set the fan speed after the end time.

HOW TO USE WITH SPIDER FARMER POWER STRIP KITS

- If you own a Spider Farmer Power Strip Kit, you can connect the inline fan using either the RJ12 cable or the power cord. Once connected, control the fan through the Spider Farmer App.
- Find the Device—Click ‘Blower’ (inline fan)—Click ‘Auto’ to set the fan—3 Modes Available




PACKAGE INCLUDES

				
Model	SF-4/6Inlinefan	SF-4/6Inlinefan-CP	SF-4/6filterkit	SF-filterkits4/6-CP
Inline Fan	1	1	1	1
Controller	Speed Controller	GGs Controller	Speed Controller	GGs Controller
Carbon Filter	0	0	1	1
RJ12 Cable	0	4	0	4
Strap	2	2	4	4
Ducting	0	0	1	1
Clamp	0	0	3	3
Vent Cover	0	0	2	2
Timer	0	0	1	0
Thermo-hygrometer	0	0	1	0

SAFETY PRECAUTIONS

- Operating temperature range: -200C to 600C (-40F to 1400F).
- Environmental humidity range: RH (can withstand up to 450 °C for 24 hours).
- Keep the fan away from children, especially the blades, electrical parts, and packaging materials.
- Improper use will void the manufacturer's warranty.



WARRANTY

- Spider Farmer offers a warranty in the United States, Canada, the United Kingdom, the European Union, and Australia.

30-Day Return Policy

- Returns or exchanges are accepted within 30 days of delivery if the product is in its original condition, including all original packaging, accessories, and gifts.
- For returns not due to quality issues, customers are responsible for return shipping costs.

2-Year Warranty

First Year:

- Free repair, replacement, and shipping are provided for any quality issues.

Second Year:

- Free replacement parts are provided, but customers are responsible for the shipping costs of the parts.

Important Notice

- Unauthorized repairs, modifications, or improper use will void the warranty.

SPIDER FARMER APP



Android



iOS



Follow Us on Social Media



Email:

- support@spider-farmer.com
- info@spider-farmer.com

Documents / Resources

	Spider Farmer SF-Inline-Fan-08 Mixed Flow Inline Fan [pdf] User Manual SF-Inline-Fan-08 Mixed Flow Inline Fan, SF-Inline-Fan-08, Mixed Flow Inline Fan, Flow Inline Fan, Inline Fan, Fan
	Spider Farmer SF-Inline-Fan-08 Mixed Flow Inline Fan [pdf] User Manual SF-Inline-Fan-08 Mixed Flow Inline Fan, SF-Inline-Fan-08, Mixed Flow Inline Fan, Flow Inline Fan, Inline Fan, Fan

References

- [User Manual](#)

Spider

Farmer

fan, Flow Inline Fan, Inline Fan, Mixed Flow Inline Fan, SF-Inline-Fan-08, SF-Inline-Fan-08 Mixed Flow Inline Fan, Spider Farmer

—

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.